






User Guide

Quality, Design and Innovation



home.liebherr.com/fridge-manuals



LIEBHERR

Contents

| | | | | | |
|----------|--|-----------|------------|---|-----------|
| 1 | Appliance at a glance..... | 3 | 7.1 | Safety lock..... | 38 |
| 1.1 | Scope of supply..... | 3 | 7.2 | Sensors..... | 38 |
| 1.2 | Overview of the appliance and equipment..... | 3 | 7.3 | Interfaces..... | 38 |
| 1.3 | Special features..... | 3 | 8 | Maintenance..... | 39 |
| 1.4 | Range of use of appliance..... | 3 | 8.1 | Maintenance schedule..... | 39 |
| 1.5 | Appliance noise emissions..... | 4 | 8.2 | Defrosting appliance..... | 40 |
| 1.6 | Conformity..... | 4 | 8.3 | Cleaning the appliance..... | 40 |
| 1.7 | SVHC substances according to REACH regulation..... | 4 | 9 | Customer help..... | 41 |
| 2 | General safety instructions..... | 4 | 9.1 | Technical specifications..... | 41 |
| 3 | Functionality of the Touch display..... | 6 | 9.2 | Technical fault..... | 42 |
| 3.1 | Navigation and symbol explanation..... | 6 | 9.3 | Customer Service..... | 42 |
| 3.2 | Menus..... | 6 | 9.4 | Type plate..... | 42 |
| 3.3 | Sleep mode..... | 7 | 10 | Shutting down..... | 43 |
| 4 | Putting into operation..... | 7 | 11 | Disposal..... | 43 |
| 4.1 | Installation conditions..... | 7 | 11.1 | Preparing appliance for disposal..... | 43 |
| 4.2 | Appliance dimensions..... | 8 | 11.2 | Disposing of the appliance in an environmentally friendly manner..... | 43 |
| 4.3 | Transporting appliance..... | 8 | 12 | Additional information..... | 43 |
| 4.4 | Unpacking appliance..... | 8 | 13 | Quick Start Guide for everyday use..... | 45 |
| 4.5 | Installing door handle..... | 8 | | | |
| 4.6 | Installing appliance..... | 8 | | | |
| 4.7 | Setting up the appliance so it is level..... | 8 | | | |
| 4.8 | Installing multiple appliances..... | 9 | | | |
| 4.9 | Sliding the appliance under a worktop..... | 9 | | | |
| 4.10 | After installation..... | 9 | | | |
| 4.11 | Disposing of packaging..... | 10 | | | |
| 4.12 | Replacing the door hinge..... | 10 | | | |
| 4.13 | Aligning the door..... | 20 | | | |
| 4.14 | Connecting the appliance to the power supply..... | 20 | | | |
| 4.15 | Switching on appliance (first use)..... | 21 | | | |
| 5 | Storage..... | 21 | | | |
| 5.1 | Information regarding storage..... | 21 | | | |
| 6 | Controls..... | 21 | | | |
| 6.1 | Control and display elements..... | 21 | | | |
| 6.1.1 | Status display..... | 22 | | | |
| 6.1.2 | Display symbols..... | 22 | | | |
| 6.1.3 | Acoustic signals..... | 22 | | | |
| 6.2 | Appliance functions..... | 22 | | | |
| 6.2.1 | Notes on the appliance functions..... | 22 | | | |
| 6.2.2 | Switching appliance on and off | 22 | | | |
| 6.2.3 | Temperature | 23 | | | |
| 6.2.4 | Temperature recording | 23 | | | |
| 6.2.5 | Lighting *..... | 24 | | | |
| 6.2.6 | Settings menu access protection | 24 | | | |
| 6.2.7 | Access code..... | 25 | | | |
| 6.2.8 | Maintenance interval reminder | 26 | | | |
| 6.2.9 | Language | 26 | | | |
| 6.2.10 | Temperature unit | 27 | | | |
| 6.2.11 | Display brightness | 27 | | | |
| 6.2.12 | Alarm Sound..... | 27 | | | |
| 6.2.13 | Key Sound..... | 27 | | | |
| 6.2.14 | WiFi connection | 28 | | | |
| 6.2.15 | LAN connection | 29 | | | |
| 6.2.16 | Device information | 30 | | | |
| 6.2.17 | Operating hours | 30 | | | |
| 6.2.18 | Software | 30 | | | |
| 6.2.19 | Defrosting | 30 | | | |
| 6.2.20 | Sensor calibration | 31 | | | |
| 6.2.21 | Temperature alarm | 31 | | | |
| 6.2.22 | Door alarm | 32 | | | |
| 6.2.23 | Light alarm *..... | 33 | | | |
| 6.2.24 | Alarm simulation | 34 | | | |
| 6.2.25 | Alarm forwarding | 34 | | | |
| 6.2.26 | Demo mode | 35 | | | |
| 6.2.27 | Resetting to factory settings | 35 | | | |
| 6.3 | Messages..... | 36 | | | |
| 6.3.1 | Warnings..... | 36 | | | |
| 6.3.2 | Reminder..... | 37 | | | |
| 7 | Features..... | 38 | | | |

The manufacturer is continually working on the further development of all types and models. Please be aware that we reserve the right to make changes to the shape, equipment and technology.

| Symbol | Explanation |
|--------|--|
| | Read instructions Please read the information in these instructions carefully to understand all of the benefits of your new appliance. |
| | Additional information on the Internet The digital manual with additional information and in other languages can be found via the QR code on the front of the manual or by entering the service number at home.liebherr.com/fridge-manuals . The service number can be found on the serial tag: <div style="text-align: center;"> </div> <p style="text-align: right;"><i>Fig. Example illustration</i></p> |
| | Check appliance Check all parts for transport damage. If you have any complaints, please contact your agent or customer service. |
| | Differences These instructions apply to a range of models, so differences are possible. Sections that apply to certain models only are marked with an asterisk (*). |
| | Instructions and results Instructions are marked with a ▶. Results are marked with a ▷. |
| | Videos Videos about the appliances are available on the YouTube channels of Liebherr-Hausgeräte. |

Open source licences:

The appliance contains software components that use open source licences. Information on the open source licences used can be found here: home.liebherr.com/open-source-licences

These operating instructions apply to:

- SRTvg 1501
- SRTvg 1511

1 Appliance at a glance

1.1 Scope of supply

Check all parts for transport damage. If you have any complaints, please contact your dealer or Customer Service. (see 9.3 Customer Service)

The delivery comprises the following parts:

- Free-standing appliance
- Equipment *
- Installation materials *
- Operating instructions
- Service brochure
- Quality certificate *
- Mains cable

1.2 Overview of the appliance and equipment




Fig. 1 Example illustration

Equipment

- | | |
|------------------------|--------------------------------------|
| (1) Type plate | (6) Controls and temperature display |
| (2) Shelves | (7) Safety thermostat sensor |
| (3) Adjustable foot | (8) Condensation drainage |
| (4) Interior lighting* | (9) Sensor feedthrough |
| (5) Lock | |




Fig. 2 Example illustration, rear end

Equipment

- | | |
|---------------------------------|---------------|
| (1) LAN/WLAN interface * | (3) Carry aid |
| (2) Potential-free alarm output | |

1.3 Special features

Note

Accessories are available from Customer Service (see 9.3 Customer Service) and the Liebherr-Hausgeräte store at home.liebherr.com/shop/de/deu/zubehor.html.

SmartModule

The appliance can be fitted with a SmartModule.

This is a WiFi and LAN interface for the connection between the appliance and an external documentation and alarm system such as Liebherr SmartMonitoring.

Liebherr SmartMonitoring Dashboard is not available in all countries. Check availability via the QR code (see 6.2.14 WiFi connection) by entering your model.

Retrofitting drawers

Temperature qualification is required when retrofitting drawer systems in Liebherr refrigerators/freezers where these are used for temperature-sensitive materials such as chilled drugs and refrigerated products which are subject to specific standards requirements. Retrofitting drawers in Liebherr refrigerators/freezers can result in the goods stored becoming spoiled or damaged. The retrofitting must therefore be completed exclusively by authorised service providers from the manufacturer of the refrigerator/freezer.

1.4 Range of use of appliance

Intended use

This laboratory refrigerator is suitable for professional storage of products at temperatures between 3 °C and 16 °C.

Typical products to be stored include research samples, reagents, laboratory inventory etc.

The storage of temperature-sensitive substances requires the use of an independent, continuous monitoring alarm system. This alarm system must be designed in such a way that a responsible person can register any alarm status so that appropriate action can be taken.

Foreseeable incorrect use

Do not use the appliance for the following applications:

- Storage and refrigeration of:

General safety instructions

- Chemically unstable, flammable or corrosive substances
- Blood, plasma or other body fluids for the purpose of infusion, application or introduction in the human body.
- Use in potentially explosive atmospheres.
- Use outdoors or in areas exposed to dampness and splashing water.

Improper use of the appliances will result in goods stored being damaged or spoiled.

Climate classes

The applicable climate class for your appliance is printed on the type plate.




Fig. 3 Type plate

(X) This climate class indicates the ambient conditions in which the appliance can be safely operated.

| Climate class (X) | max. room temperature | max. rel. humidity |
|-------------------|-----------------------|--------------------|
| 7 | 35 °C | 75% |

Note

The minimum permitted room temperature at the setup location is 10 °C.

The internal temperature of the appliance never exceeds the ambient temperature at the site of use.

Slight condensation may form at the limit conditions on the glass door and on the side walls.

1.5 Appliance noise emissions

The A-weighted emission sound pressure level during operation of the appliance is under 70 dB(A) (sound power rel. 1 pW).

1.6 Conformity

The coolant circuit has been tested for leak-tightness. The appliance complies with the relevant safety regulations.

| EU Declaration of Conformity | |
|---|--|
| Manufacturer/Exhibitor: | LIEBHERR-HAUSGERÄTE LIENZ GMBH |
| Address: | A-9900 Lienz, Dr. Hans Liebherr Straße 1 |
| The designated product complies with the provisions of the following European directives and regulations: | |
| (EU) 2019/2020, 2014/35/EU, 2014/30/EU, 2011/65/EU | |

EU Declaration of Conformity

The full text of the EU Declaration of Conformity is available at the following web address: www.liebherr.de

1.7 SVHC substances according to REACH regulation

You can check whether your appliance contains SVHC substances according to REACH regulation at the following link: home.liebherr.com/de/deu/de/liebherr-erleben/nachhaltigkeit/umwelt/scip/scip.html

2 General safety instructions

Please keep these operating instructions in a safe place so you can refer back to them at any time.

If you pass the appliance on, please hand these operating instructions to the next user.

Read these operating instructions carefully before use to ensure safe and correct use of the appliance. Follow the instructions, safety instructions and warning messages included at all times. They are important for ensuring you can operate and install the appliance safely and without any problems.

Danger for the user:

- This appliance may only be used by specialist and laboratory personnel who have been trained for this purpose and are familiar with all safety measures pertaining to laboratory work. Children and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge must not commission or operate this appliance.
- The socket must be easily accessible so that the appliance can be disconnected quickly from the electricity supply in an emergency. It must not be located in the area behind the appliance.
- When disconnecting the appliance from the supply, always take hold of the plug. Do not pull the cable.
- In the event of a fault pull out the mains plug or deactivate the fuse.
- **WARNING:** Do not damage the mains power cable. Do not operate the appliance with a defective mains power cable.
- **WARNING:** Multiple sockets/distributors and other electronic equipment (such as halogen transformers) must not be placed or operated at the rear of the appliance.
- **WARNING:** Keep ventilation openings, in the appliance enclosure or in the built-in structure, clear of obstruction.

- Only customer service or other specially trained staff may repair or perform other operations on the appliance.
- Only assemble, connect and dispose of the appliance according to the instructions.

Fire hazard

- The coolant used (information on the model plate) is ecofriendly but also flammable. Any leaking coolant may ignite.
 - **WARNING:** Do not damage refrigeration circuit.
 - Do not handle ignition sources inside the appliance.
 - **WARNING:** Do not use electrical appliances in the fridge compartment which do not comply with the design recommended by the manufacturer.
 - If the refrigerant leaks: remove any naked flames or ignition sources from the vicinity of the leakage point. Properly air the room. Inform customer services.
- Do not operate the appliance close to explosive gases.
- Do not store or use petrol or other flammable gases and liquids close to the appliance.
- Do not store any explosive substances, such as aerosol containers with flammable propellant gas, in the appliance. To identify these spray cans, look for the list of contents printed on the can, or a flame symbol. Gases possibly escaping may ignite due to electrical components.
- Keep burning candles, lamps and other items with naked flames away from the appliance so that they do not set the appliance on fire.
- Alcoholic liquids or other containers with alcohol inside must only be stored tightly sealed. Any alcohol that leaks out may be ignited by electrical components.

Danger of tipping and falling:

- Do not misuse the plinth, drawers, doors etc. as a step or for support.

Danger of frostbite, numbness and pain:

- Avoid prolonged skin contact with cold surfaces or refrigerated/frozen goods or take protective measures, e.g. wear gloves.

Danger of injury and damage:

- **WARNING:** Do not use mechanical equipment or other methods to speed up the defrosting process other than those recommended by the manufacturer.

- **WARNING:** Risk of injury due to electric shock! There are live electrical parts under the cover.

Only have the LED interior lighting replaced or repaired by customer service or other suitably trained professionals.*

- **NOTICE:** Appliance must only be used using original manufacturer accessories or using accessories from other providers approved by the manufacturer. The user bears the risk of using accessories which are not approved.

Risk of crushing

- Do not hold the hinge when opening and closing the door. Fingers may get caught.

Specialist personnel qualifications:

The appliance may only be installed, tested, maintained, and commissioned by specialist personnel who are familiar with the installation, commissioning, and operation of the appliance.

Specialist personnel are persons who, on account of their specialist training, knowledge and experience as well as their knowledge of the relevant standards, are able to assess and perform the work assigned to them and identify potential hazards. They must have training, instruction, and authorisation to work on the appliance.


Symbols on the appliance:



This symbol may be located on the compressor. It relates to the oil in the compressor and makes reference to the risk that: **Swallowing or inhaling can be fatal.** This advice is only relevant to recycling. There is no danger in normal operation.



WARNING: Danger of fire / flammable materials. This symbol is located on the compressor and indicates the danger of flammable materials. Do not remove the sticker.






The symbol is located on the back of the appliance near the alarm relay and indicates the following danger: **Electric shock!** Even if an appliance is disconnected from the mains there may still be extraneous voltage. Do not remove sticker.



This or a similar sticker may be located on the rear of the appliance. This sticker indicates that there are vacuum insulation panels (VIP) or perlite panels in the door and/or housing. This advice is only relevant to recycling. Do not remove the sticker.

Please note the warning messages and other specific advice in the other chapters:

Functionality of the Touch display







| | | |
|---|----------------|---|
|  | DANGER | Indicates an immediately hazardous situation which will lead to death or serious injuries if it is not avoided. |
|  | WARNING | Indicates a hazardous situation which will lead to death or serious injuries if it is not avoided. |
|  | CAUTION | Indicates a hazardous situation which will lead to minor or moderate injuries if it is not avoided. |
| | NOTICE | Indicates a hazardous situation which may lead to damage to property if it is not avoided. |
| | Note | Indicates useful instructions and tips. |





3 Functionality of the Touch display

You operate your appliance using the Touch display. You select appliance functions in the Touch display (hereafter referred to as display) by tapping them. If you do not perform any action on the display for 10 seconds, the display either jumps back to the higher-level menu or directly to the status display.

3.1 Navigation and symbol explanation

In the illustrations, different symbols are used to navigate the display. The following table describes these symbols.



| Symbol | Description |
|---|--|
|  | Press the Next navigation arrow: Navigates to the next option in the menu. |
|  | Press the Back navigation arrow: Jumps back one option in the menu. |
|  | Press and hold the Back navigation arrow for 3 seconds: Jumps back to the status display in the main menu or from the Settings menu. |
|  | Press the navigation arrow several times in succession: Navigates in the menu to the desired function. |
|  | Press the Confirm symbol: Activates/deactivates function. Opens submenu. |
|  | Press the Confirm symbol together with the back icon: Jumps back one menu level. |

| Symbol | Description |
|--|---|
|  | Arrow with clock: It takes more than 10 seconds for the following message to appear in the display. |
|  | Arrow with a time indication: It takes the specified amount of time until the following message appears in the display. |
|  | "Open Settings menu" symbol: Navigates to the Settings menu and opens the settings menu. If necessary: Navigate to the desired function in the Settings menu. (see 3.2.1 Opening the Settings menu) |
|  | "Open Advanced menu" symbol: Navigates to the Advanced menu and opens the advanced menu. If necessary: Navigate to the desired function in the Advanced menu. (see 3.2.2 Opening the Advanced menu) |
| No action for 10 seconds | If you do not perform any action on the display for 10 seconds, the display either jumps back to the higher-level menu or directly to the status display. |
| Opening door and closing it again | If you open the door and immediately close it again, the display jumps directly back to the status display. |

Note: Illustrations of the display are shown in the English version.

3.2 Menus

The appliance functions can be found in various menus.

| Menu | Description |
|--|--|
| Main menu | When you switch the appliance on, you are automatically in the main menu. From here you can navigate to the most important appliance functions, to the Settings menu and to the Advanced menu. |
|  Settings menu | The Settings menu contains additional appliance functions for setting up your appliance. (see 3.2.1 Opening the Settings menu) |
|  Advanced menu | The advanced menu contains special appliance functions for setting up your appliance. Access to the Advanced menu is protected by the numerical code 1 5 1 . (see 3.2.2 Opening the Advanced menu) |

3.2.1 Opening the Settings menu




Fig. 4 Example illustration

- ▶ Carry out action steps according to the illustration.
- ▶ Settings menu is open.
- ▶ If necessary: Navigate to the desired function.

3.2.2 Opening the Advanced menu




Fig. 5 Access with numerical code 151

- ▶ Carry out action steps according to the illustration.
- ▶ The expanded menu is open.
- ▶ If necessary: Navigate to the desired function.

3.3 Sleep mode

If you do not touch the display for 1 minute, the display switches to sleep mode. In sleep mode, the display brightness is dimmed.

3.3.1 Ending sleep mode

- ▶ Press any navigation key.
- ▶ Sleep mode is ended.

4 Putting into operation

4.1 Installation conditions



WARNING

Fire hazard due to dampness!

If live parts or the mains lead become damp this may cause short circuits.

- ▶ The appliance is designed for use in enclosed areas. Do not operate the appliance outdoors or in areas where it is exposed to splash water or damp conditions.

4.1.1 Installation location



WARNING

Leaking coolant and oil!

Fire. The coolant contained in the appliance is eco-friendly, but also flammable. The oil contained in the appliance is flammable. Escaping coolant and oil can ignite if the concentration is high enough and in contact with an external heat source.

- ▶ Do not damage the pipelines of the coolant circuit and the compressor.

- Do not install appliance in direct sunlight, next to an oven, radiator or similar.
- The best place for installation is a dry and well ventilated room.
- If the appliance is installed in a very humid environment, condensation can form on the outside of the appliance. Always ensure good airflow and ventilation in the installation location.
- The more refrigerant there is in the appliance, the larger the space it is installed in must be. If the space is too small, any leak may create a flammable mixture of gas and air. For every 8 g of refrigerant, the installation space must be at least 1 m³. Information regarding the refrigerant can be found on the type plate inside the appliance.
- The floor of the location must be horizontal and even.
- The installation location must be able to withstand the weight of the appliance plus weight when stocked to maximum level. (see 9.1 Technical specifications)
- If the appliance is set up at a height, the anti-tipping device must be fitted.
If the appliance is installed on top of another appliance, the connection frame with anti-tipping device (included in the connection frame) must be installed.
If the appliance is placed on a plinth with casters, the plinth must be fitted with an anti-tipping device (included with the plinth).
If the appliance is installed on a foot plinth, the foot plinth must be fitted with an anti-tipping device (included in the foot plinth).
The anti-tipping device is available from the Liebherr-Hausgeräte shop at home.liebherr.com/shop/de/deu/zubehor.html.
- Use in hazardous areas is not permitted.

4.1.2 Electrical connection



WARNING

Danger of fire due to incorrect positioning!

If the mains cable or plug touches the back of the appliance, the vibration can damage the mains cable or the plug resulting in a short circuit.

- ▶ Make sure the mains cable is not trapped under the appliance when you position the appliance.
- ▶ Stand the appliance so that it is not touched by connectors or main cables.
- ▶ Do not connect any appliances to sockets in the area of the back of the appliance.
- ▶ Do **not** place and operate multi-sockets/power distributors and other electronic devices (such as halogen transformers) at the back of the appliances.

Putting into operation

4.2 Appliance dimensions




Fig. 6 Example illustration

- (A) Device height including feet/rollers
- (B) Device width without handle [handle depth = 45 mm (1 6/8 in)]
- (C) Device depth without handle [handle depth = 45 mm (1 6/8 in)]
- (D) Device depth with door open

| | |
|---|----------|
| A | 819 mm |
| B | 597 mm |
| C | 605 mm* |
| D | 1162 mm* |

* On devices with attached wall spacer brackets, this dimension increases by 35 mm.

4.3 Transporting appliance



WARNING

Risk of injury due to broken glass!*

When transporting at an altitude of more than 1500 m, the glass panes of the door may break. This can result in sharp-edged fragments, which can cause serious injuries.

- ▶ Take appropriate protective action.

Note when transporting the appliance:

- ▶ Transport the appliance upright.
- ▶ Use two people to transport the appliance.

During first use:

- ▶ Transport the appliance packaged.

When transporting appliances after initial commissioning (e. g. moving or cleaning):

- ▶ Empty the appliance.
- ▶ Secure the door against unintentional opening.

4.4 Unpacking appliance

- ▶ Check the appliance and the packaging for damage during transport. Contact the supplier immediately if you suspect any damage. Do not connect appliance to the power supply.
- ▶ Remove all packaging materials from the rear or the side walls of the fridge that may prevent proper installation or prevent air flow and ventilation.

4.5 Installing door handle




Fig. 7

- ▶ Attach handle from accessory kit to the door using the screws Fig. 7 (1) supplied.
- ▶ Put on cover Fig. 7 (2).
- ▶ Insert the plug from the accessory pack on the opposite side. *

4.6 Installing appliance



CAUTION

Risk of injury and damage.

- ▶ Use 2 people to install appliance.



CAUTION

Risk of injury and damage.

The door can knock against the wall and become damaged as a result. In the case of glass doors, the damaged glass can cause injuries.

- ▶ Protect the door from knocking against the wall. Attach door stopper, e.g. felt stopper, to the wall.
- ▶ Connect all necessary components (e.g. mains cable) to the back of the appliance and route to the side.

Note

Cables can be damaged.

- ▶ Do not jam the cable when pushing the appliance back.

4.7 Setting up the appliance so it is level

NOTICE

Appliance body is deformed and door does not close.

- ▶ Align appliance horizontally and vertically.
- ▶ Compensate for uneven floors using adjustable feet.



WARNING

Incorrect height adjustment of the adjustable foot!

Can cause severe or even fatal injury. Incorrect height adjustment can cause the bottom part of the adjustable foot to come loose and the appliance to tip over.

- ▶ Do not unscrew the adjustable foot too far.




Fig. 8

Raising appliance:

- Turn adjustable foot clockwise.

Lowering appliance:

- Turn adjustable foot anticlockwise.

4.8 Installing multiple appliances

NOTICE

Risk of damage due to condensation between the side walls.

- Do not install the appliance directly next to another fridge.
- Install appliances with a space 3 cm between appliances.
- Only install multiple appliances up to temperatures of 35 °C and 65% humidity next to one another.
- At higher levels of humidity, increase space between appliances.




Fig. 9 Side-by-side installation

Note

A side-by-side kit is available as an accessory via Liebherr Customer Service. (see 9.3 Customer Service)

4.9 Sliding the appliance under a worktop

You can slide tabletop appliances with a maximum height of 850 mm under a continuous worktop.




Fig. 10

(A) Width of appliance without table top

(B) Niche depth

(C) Niche height

(D1) Ventilation cross-section in the workplate

(D2) Ventilation cross-section between worktop and appliance

| | |
|----------|------------------------------|
| A | at least 600 mm |
| B | at least 550 mm |
| C | at least 825 mm |
| D1 or D2 | at least 200 cm ² |



WARNING

Risk of fire due to short circuit!

- When you set the appliance up: do not kink, jam or damage the mains cable.
- The appliance must not be operated with a defective mains cable.

Ensure that the following requirements are met:

- ☐ The table top has been removed.
- ☐ The socket is easily accessible and is not behind the appliance.
- Slide the appliance under the worktop.

4.10 After installation

- Peel off the protective films. *
- Clean appliance. (see 8.3 Cleaning the appliance)
- If necessary: Disinfect the appliance.
- Keep the invoice so you have the appliance and dealer information available if needed.

Putting into operation

4.11 Disposing of packaging



WARNING

Danger of suffocation due to packing material and plastic film!

- Do not allow children to play with packing material.

The packaging is made of recyclable materials:

- corrugated board/cardboard
- expanded polystyrene parts
- polythene bags and sheets
- polypropylene straps
- nailed wooden frame with polyethylene panel*

- Take the packaging material to an official collecting point.

4.12 Replacing the door hinge

4.12.1 Safety instructions



WARNING

Risk of injury if the door is not reversed correctly!

- Replace the door hinge with specialist personnel.



WARNING

Risk of injury and material damage due to door weight!

- Only change the door hinge if you can carry a weight of 15 kg.
- Change the door hinge with two people.

NOTICE

Live parts!

Damage to electrical components.

- Remove the mains plug before you reverse the door.

4.12.2 Tool



4.12.3 Removing the worktop




Fig. 11

- Loosen the screws.




Fig. 12

- Remove the worktop.

4.12.4 Removing covers

- Open the door.




Fig. 13

- Remove the cover.




Fig. 14

- Remove the cover Fig. 14 (1) and then Fig. 14 (2).




Fig. 15

- Remove the cover.

4.12.5 Removing the front panel




Fig. 16

- Remove the front panel.
- **TIP for further steps:** photograph how the cables are laid.




Fig. 17

- Unplug the plug.




Fig. 18

- Pull the cable with the bracket out the hinge.
- The cable with the bracket is hanging on the door.

4.12.6 Removing the door

NOTICE

Risk of injury if the door tips out!

- Hold the door.




Fig. 19

- Removing the cover Fig. 19 (1).
- Loosen the bolt Fig. 19 (2) anti-clockwise and pull it out.
- Tilt the door Fig. 19 (3) slightly.




Fig. 20

- Remove the door upwards.
- Place the door on a soft surface.

4.12.7 Re-locating the top cover




Fig. 21

- Remove the cover.




Fig. 22

- Insert the cover.

4.12.8 Relocating the stop plate




Fig. 23

- Detach the stop plate.




Fig. 24

- Attach the stop plate on the opposite side.

4.12.9 Converting the handle




Fig. 25

- Remove the covers Fig. 25 (1).
- Loosen the screws Fig. 25 (2).
- Remove the handle.




Fig. 26

- Move the plug to the opposite side.*
- Screw the handle on to the opposite side.
- Push the covers Fig. 26 (1) on.

4.12.10 Removing the cover

- Lock the door.

Putting into operation




Fig. 27

- Detach the locking hook.




Fig. 28

- Remove the covers.

4.12.11 Converting the plug holder




Fig. 29 The installation position for the plug holder can be rotated by 180°.

- Unlatch the plug holder.




Fig. 30

- Engage the plug holder on the opposite side.

4.12.12 Converting the lock




Fig. 31 Example illustration: Foamed door




Fig. 32 Example illustration: Glass door

- Remove the cover.
- Remove the lock.




Fig. 33 Example illustration: Foamed door




Fig. 34 Example illustration: Glass door

- Fit cover on the opposite side.
- Foamed door: Turn the lock 180° and fit it on the opposite side.
- or-
- Glass door: Turn the lock and holder and fit it on the opposite side.

4.12.13 Putting on the cover




Fig. 35

- Fit the covers rotated by 180°. Ensure that the cable runs through the top opening on the small cover.




Fig. 36

- Fit the locking hook.

4.12.14 Converting the top hinge




Fig. 37

- Detach the hinge.




Fig. 38

- Press out the bearing socket.




Fig. 39

- Turn the bearing socket by 180° and press it into the underside.




Fig. 42

- Attach the hinge.

4.12.15 Converting the bottom hinge

NOTICE

Danger of injury due to tensioned spring!

- Do not dismantle the screw connection Fig. 43 (1) on the locking system.




Fig. 40

- Detach the locking bracket.




Fig. 43

- Turn the locking system Fig. 43 (2) until it clicks.
- The locking system pre-tension is released.




Fig. 41

- Turn the locking bracket 180° and fit it on the opposite side.




Fig. 44

- Detach the hinge bracket.




Fig. 45

- Loosen the nut.

Note

When inserting, ensure that the locking system is aligned correctly.




Fig. 46 View from below: Fig. 46 (1)

- Move the locking system in the hinge bracket and secure with the nut.




Fig. 47

- Attach the hinge bracket on the opposite side.

Note

Correct alignment and pre-tension are important for the locking system functions.

Putting into operation




Fig. 48 Left stop (A) / right stop (B)

- Turn the locking system against the resistance until the bar on the locking system Fig. 48 (1) is pointing outwards.
- The locking system remains in this position automatically.
- The locking system is aligned and pre-tensioned.

4.12.16 Fitting the door




Fig. 49

- Place the door on the locking system.




Fig. 50

- Slide the door Fig. 50 (1) onto the top hinge.
- Insert the bolt Fig. 50 (2) and turn it clockwise to tighten.
- Put on the cover Fig. 50 (4).

4.12.17 Putting on the front panel




Fig. 51

- Push the cable holder Fig. 51 (1) into the hinge.
- Lay the cable in the hinge towards the front panel.




Fig. 52

- Plug in the plug.




Fig. 55

- Put on the cover.




Fig. 53

- Put on the front panel.




Fig. 56

- Put on the cover.

4.12.18 Putting on the covers




Fig. 54

- (1) The cover is supplied as standard with the appliance.
- Put on the covers.

4.12.19 Fitting the worktop




Fig. 57

- Put on the worktop.

Putting into operation




Fig. 58

- Screw on the worktop.

4.13 Aligning the door

If the door is not straight, you can adjust it on the lower hinge.




Fig. 59

- Remove the middle screw on the lower hinge.




Fig. 60

- Slightly undo both screws and move the door with the hinge to the left or right.
- Fully tighten the screws (the middle screw is no longer needed).
- The door is now straight.

4.14 Connecting the appliance to the power supply



WARNING

Danger of electric shock and injury due to damaged appliance or damaged mains cable!

Danger of cuts and fatal injuries. If the appliance or the mains cable is damaged during transport, you may be electrocuted. You could also cut yourself on damaged parts of the appliance housing.

- Check the appliance and the mains cable for damage after transport.
- Never put the appliance into operation if the appliance or the mains cable are damaged.
- Contact Customer Service.

You can connect your appliance to the mains using the power cable supplied separately. The mains power cable has an appliance coupler at one end and a mains plug at the other end.

Make sure that the following requirements are fulfilled:

- The appliance and power cable are undamaged.
- The appliance is set up in accordance with the regulations. (see 4.5 Installing door handle)
- Requirements for the electrical connection are met. (see 4.1 Installation conditions)
- Dimensions for connection in accordance with regulations are known and observed.
- Mains voltage and frequency correspond to the specifications on the type plate.
- The socket is earthed according to the regulations and fused.
- The fuse tripping current is between 10 A and 16 A.
- The socket is easily accessible and is not behind the appliance.

NOTICE

Danger of damage to incorrect operation!

Damage to the electrical components of the appliance.

- Only use the supplied mains cable.




WARNING

Danger of fire due to incorrect connection!

Burns.

Damage to the appliance.

- Do not use an extension cable.
- Do not use distributor blocks.



NOTICE

Danger of damage to incorrect connection!

Damage to the appliance.

- Do not connect the appliance to a stand-alone inverter, e.g. solar power systems and petrol generators.

- ▶ Connect the mains cable plug to the power supply. Ensure that the plug is tightly in the socket.
- ▶ If no action occurs within 60 seconds: The standby symbol fades or disappears.
- ▶ The appliance is connected. For information regarding first use, see the following section or the operating instructions.

4.15 Switching on appliance (first use)

Make sure the following prerequisites are met:

- Appliance is installed and connected.
- All adhesive strips, adhesive and protective films and transport locks are removed from inside and outside the appliance.




Fig. 61 Example illustration

The standby symbol flashes until the startup process is complete.

The standby symbol is shown in the display.

If the appliance has been supplied with factory settings, the screen language first needs to be selected when using for the first time.




Fig. 62

- ▶ Carry out action steps according to the illustration.




Fig. 63

- ▶ The appliance is switched on once the temperature appears in the display.
- ▶ The temperature display flashes until the set temperature is reached.

5 Storage

5.1 Information regarding storage




Fig. 64 Example illustration




Fig. 65

When stocking observe the following:

- ❑ If there are adjustable shelves Fig. 64 (1), position them as required.
- ❑ Observe maximum load weight. (see 9.1 Technical specifications)
- ❑ Do not load appliance until storage temperature has been reached (maintain cold chain).
- ❑ Ventilation slots Fig. 65 (2) for recirculation fan in the interior must be kept clear.
- ❑ Refrigerated goods must not touch the rear wall.
- ❑ Refrigerated items do not protrude beyond the shelves.
- ❑ Keep liquids in closed containers.
- ❑ Leave space when storing items for refrigeration to ensure good air circulation.
- ❑ Do not stack refrigerated products above the indicated

height.

This is important for free air circulation and even temperature distribution in the interior.

6 Controls

6.1 Control and display elements

The display provides a quick overview of the current appliance status, the temperature setting, the status of functions and settings as well as alarm and error messages.

It is operated using the navigation arrows and confirmation symbol.

Functions can be activated or deactivated and setting values can be changed.




Fig. 66 Display

(1) Status display

(2) Backwards navigation arrow

(3) Forward navigation arrow

(4) Confirm

Controls

6.1.1 Status display




Fig. 67 Status display with actual temperature

The status display shows the actual temperature and is the home display. You navigate from here to the other functions and settings. The status display may show a range of display symbols.

6.1.2 Display symbols

Display symbols provide information about the status of the appliance.

| Symbol | Appliance status |
|--------|--|
| | Standby Appliance is switched off. |
| | Flashing standby symbol Appliance is starting up. |
| | Flashing temperature Target temperature not yet reached. Appliance cooling to temperature set. |
| | Temperature display Displays the current interior temperature |
| | Display alternating between temperature/defrost symbol with white bar Appliance is in manual defrosting mode |
| | D in the display Appliance is in DemoMode. |
| | Maintenance reminder The time interval set has expired. |
| | Data memory full The data memory (999 hours) is full. From now, the oldest data will be overwritten. |
| | Flashing symbol A fault is still active. |
| | Error symbol Appliance is in error state. |
| | White bar at the bottom Submenu |

| Symbol | Appliance status |
|--------|--|
| | White bar at the top Default, active setting or active value |
| | Increasing bar Press button for 3 seconds to activate setting. |
| | Decreasing bar Press button for 3 seconds to deactivate setting. |

Status display symbols

6.1.3 Acoustic signals

A signal sounds in the following cases:

- If a function or a value is confirmed.
- If a function or a value can either not be activated or not deactivated.
- As soon as an error occurs.
- If there is an alarm message.

The alarms can be switched on and off in the customer menu.

6.2 Appliance functions

6.2.1 Notes on the appliance functions

The appliance functions are set at the factory so that your appliance is fully functional.

Before you alter, activate or deactivate the device functions, make sure that the following requirements are met:

- ☐ You have read and understood the descriptions of how the display works. (see 3 Functionality of the Touch display)
- ☐ You have familiarised yourself with the operating and display elements of your appliance. (see 6.1 Control and display elements)

6.2.2 Switching appliance on and off



Using this setting the entire appliance can be switched on and off.

Switching on appliance

Without activated DemoMode:




Fig. 68

► Carry out action steps according to the illustration.

With activated DemoMode:




Fig. 69

- Carry out action steps according to the illustration.

Note

Deactivate DemoMode before countdown finishes.




Fig. 70

- The temperature appears in the display.

Switching off appliance



Fig. 71




Fig. 72

- Carry out action steps according to the illustration.
- Standby symbol is shown in the display.
- Display switches off after approximately 10 minutes.

6.2.3 Temperature



The temperature depends on the following factors:

- How often the door is opened
- How long the door is open for
- The room temperature of the installation site
- The type, temperature and amount of refrigerated items

Note

The temperature may differ from the temperature displayed in some areas of the interior.

Setting temperature




Fig. 73




Fig. 74 Changing temperature from 5.5 °C to 6.9 °C

- Carry out action steps according to the illustration.
- Temperature is set.



6.2.4 Temperature recording

The appliance displays the minimum and maximum temperatures of the interior. The recording of these temperatures starts automatically after the appliance is switched on; they are recorded at one minute intervals. A note indicating that the data memory is full is displayed after 999 hours (approx. 40 days). The temperature recording should then be reset.

Note

We recommend resetting the temperature recording once **after reaching the set temperature** when the appliance is commissioned. This ensures that the value displayed for the maximum temperature is a meaningful value.

Displaying temperature recording

The temperature recording displays the length of the recording and the minimum and maximum temperatures measured during this period of time.



Fig. 75




Fig. 76

- Status screen with the temperature recordings is displayed.

Resetting temperature recording

The displayed minimum and maximum temperatures can be reset at any time. This deletes the displayed values and the recording interval starts again.



Fig. 77




Fig. 78

- ▶ Carry out steps according to the illustration.
- ▶ Temperature recording is reset.
- ▶ Recording interval starts again.

6.2.5 Lighting



The appliance is fitted with interior lighting.
You can keep the interior lighting on continuously.
(see Switching on lighting*) *
When you open the appliance door, the interior lighting switches on.

Switching off lighting*



Fig. 79




Fig. 80

- ▶ Carry out action steps according to the illustration.
- ▶ Lighting is switched off.

Switching on lighting*



Fig. 81




Fig. 82

- ▶ Carry out action steps according to the illustration.
- ▶ Lighting is switched on.

6.2.6 Settings menu access protection



This setting enables the settings menu access protection via a three-digit PIN code.

Application:

- Prevent settings and functions being changed unintentionally.
- Prevent appliance being switched off unintentionally.
- Avoid unintentional temperature adjustment.

Note

- ▶ In the following examples, the factory-set PIN code: **1 1 1** is used.

Activating the settings menu access protection



Fig. 83




Fig. 84

- ▶ Carry out action steps according to the illustration.
- ▶ Settings menu access protection is activated.

Changing the access protection PIN code for the settings menu

See: (see 6.2.7 Access code)

Deactivating the settings menu access protection



Fig. 85




Fig. 86

- Carry out action steps according to the illustration.
- Settings menu access protection is deactivated.

Opening protected settings menu

If the access protection is active, you must enter the PIN code in order to be able to open the settings menu. As soon as you exit the settings menu, the access protection re-activates automatically.

- Tap navigation arrow repeatedly until corresponding function is displayed.




Fig. 87

- Carry out action steps according to the illustration.
- The PIN code is correct.
- The settings menu opens.

6.2.7 Access code

Various settings are possible.

Application:

- Changing the settings code.
- Resetting the settings code.

Settings menu access protection



Changing the settings code

This setting allows the settings code for settings menu access protection to be changed.

The setting is made in 3 stages:

- Entering the old settings code
- Entering the new settings code
- Confirming the new settings code

Note

- In the following example, the default factory-set settings code **1 1 1** is changed.
- The new settings code is: **2 3 4**



Fig. 88

The access protection for the settings menu must be active. (see 6.2.6 Settings menu access protection)

- Tap the navigation arrow repeatedly until the corresponding function is displayed.




Fig. 89

- Carry out action steps according to the illustration.
- Entry of the old settings code successful.




Fig. 90

- ▶ Carry out action steps according to the illustration.
- ▶ Entry of the new settings code successful.




Fig. 91

- ▶ Carry out action steps according to the illustration.
- ▶ Confirmation of the new settings code successful.
- ▶ The settings code has been changed.

Resetting the settings code

The settings code for the settings menu access protection has been forgotten or is not known.

- ▶ Reset appliance to factory settings (see 6.2.27 Resetting to factory settings).
- ▶ The appliance is reset to the original settings.
- ▶ The factory-set settings code is: **1 1 1**

6.2.8 Maintenance interval reminder



Setting for the time interval after which a maintenance reminder is issued.

The following values can be set:

- 7 days

- 14 days
- 30 days
- 60 days
- 90 days
- 180 days
- 360 days
- 720 days
- 1080 days
- Off

Setting maintenance interval reminder

The following steps describe how the maintenance interval is set.



Fig. 92




Fig. 93

- ▶ Carry out action steps according to the illustration.
- ▶ The time interval, after which the maintenance reminder is issued, is set.
- ▶ The remaining time is displayed.

6.2.9 Language



This setting allows the display language to be set.

Setting language



Fig. 94




Fig. 95

- ▶ Carry out action steps according to the illustration.
- ▶ The selected language is set.

6.2.10 Temperature unit



Use this function to set the temperature unit. You can set degrees Celsius or degrees Fahrenheit as the temperature unit.

Setting the temperature unit




Fig. 96




Fig. 97 Example illustration: Switch from degrees Celsius to degrees Fahrenheit.

- ▶ Carry out action steps according to the illustration.
- ▶ The temperature unit is set.

6.2.11 Display brightness



Use this function to set the display brightness in stages.

You can select the following brightness levels:

- 40 %
- 60 %
- 80 %
- 100 % (pre-setting)

Setting the brightness



Fig. 98




Fig. 99 Example illustration: Switch from 80 % to 60 %.

- ▶ Carry out action steps according to the illustration.
- ▶ The brightness is set.

6.2.12 Alarm Sound



This function enables all alarm sounds, such as door alarm, to be switched on and off.

Activating Alarm Sound




Fig. 100




Fig. 101

- ▶ Carry out action steps according to the illustration.
- ▶ Alarm Sound is activated.

Deactivating Alarm Sound



Fig. 102




Fig. 103

- ▶ Carry out action steps according to the illustration.
- ▶ Alarm Sound is deactivated.

6.2.13 Key Sound



This function makes it possible to switch all confirmation sounds and the Startsound on and off.

Activating Key Sound




Fig. 104




Fig. 105

- ▶ Carry out action steps according to the illustration.
- ▶ Key Sound is activated.

Controls

Deactivating Key Sound



Fig. 106




Fig. 107

- Carry out action steps according to the illustration.
- Key Sound is deactivated.

6.2.14 WiFi connection



Note

Liebherr SmartMonitoring Dashboard is not available in all countries. Check availability via the QR code by entering your model.

Note

Use of the Liebherr SmartMonitoring Dashboard at <https://smartmonitoring.liebherr.com> requires installation of a SmartModule and a commercial MyLiebherr account. When commissioning online you can register using the login data you have, or register again and create a company account.

This setting establishes a wireless connection between the appliance and the internet. The connection is controlled via the SmartModule. The appliance can be integrated via the browser-based [Liebherr SmartMonitoring Dashboard](#) and advanced options as well as customised methods relating to control, administration and monitoring can be used.

Note

Accessories are available from Customer Service (see 9.3 Customer Service) and the Liebherr-Hausgeräte store at home.liebherr.com/shop/de/deu/zubehor.html.




Fig. 108

Make sure that the following requirements are fulfilled:

- ❑ SmartModule Fig. 108 (1) has been inserted.

Establishing connection

You commission and set up your SmartModule online via the [Liebherr SmartMonitoring Dashboard](#) on your web-enabled device.

On the [Liebherr SmartMonitoring Dashboard](#), information is also available about retrofitting the SmartModule.



Fig. 109

- Open the [Liebherr SmartMonitoring Dashboard](#) (see Fig. 109).

On the refrigerator or freezer:




Fig. 110




Fig. 111

- Carry out action steps according to the illustration.
- Continue the set-up procedure on your web-enabled device: [Liebherr SmartMonitoring Dashboard](#)




Fig. 112

- Connection is established.
- WiFi connecting appears. The symbol flashes.
- Follow the [Liebherr SmartMonitoring Dashboard](#) instructions.
- Connection is established.

Disconnecting



Fig. 113




Fig. 114

- Carry out action steps according to the illustration.
- There is no connection.

Resetting connection



Fig. 115




Fig. 116

- Carry out action steps according to the illustration.
- The WiFi settings are restored to the factory settings.

6.2.15 LAN connection



Note

Liebherr SmartMonitoring Dashboard is not available in all countries. Check availability via the QR code by entering your model.

Note

Use of the Liebherr SmartMonitoring Dashboard at <https://smartmonitoring.liebherr.com> requires installation of a SmartModule and a commercial MyLiebherr account. When commissioning online you can register using the login data you have, or register again and create a company account.

This setting establishes a wired connection between the appliance and the internet. The connection is controlled via the SmartModule. The appliance can be integrated via the browser-based [Liebherr SmartMonitoring Dashboard](#) and advanced options as well as customised methods relating to control, administration and monitoring can be used.

Note

Accessories are available from Customer Service (see 9.3 Customer Service) and the Liebherr-Hausgeräte store at home.liebherr.com/shop/de/deu/zubehor.html.




Fig. 117

Make sure that the following requirements are fulfilled:

- ☐ SmartModule Fig. 117 (1) has been inserted.
- ☐ A network cable is connected.
- ☐ The network is connected to the internet.

Establishing connection

You commission and set up your SmartModule online via the [Liebherr SmartMonitoring Dashboard](#) on your web-enabled device.

On the [Liebherr SmartMonitoring Dashboard](#), information is also available about retrofitting the SmartModule.



Fig. 118

- Open the [Liebherr SmartMonitoring Dashboard](#) (see Fig. 118).

On the refrigerator or freezer:



Fig. 119




Fig. 120

- Carry out action steps according to the illustration.
- Connection is established: LAN connecting appears. The symbol flashes.
- Follow the [Liebherr SmartMonitoring Dashboard](#) instructions.
- Connection is established.

Disconnecting



Fig. 121




Fig. 122

- Carry out action steps according to the illustration.
- There is no connection.

6.2.16 Device information



Use this function to indicate the model name, index, serial number and service number of your device. You will need the device information when you contact customer service. (see 9.3 Customer Service)

This function also opens the Advanced menu. (see 3 Functionality of the Touch display)

Indicating the device information



Fig. 123



Fig. 124

- ▶ Carry out action steps according to the illustration.
- ▶ Display indicates device information.

6.2.17 Operating hours



The display shows the appliance operating hours.

Displaying operating hours




Fig. 125



Fig. 126

- ▶ The operating hours appear.

6.2.18 Software



Use this function to indicate the software version of your device.

Indicating the software version




Fig. 127



Fig. 128

- ▶ Carry out action steps according to the illustration.
- ▶ Display indicates software version.

6.2.19 Defrosting



The appliance defrosts automatically in normal operation.

Application:

- If there is heavy icing in the interior, the automatic defrosting function can be started manually.

Starting automatic defrosting manually



Fig. 129




Fig. 130

- ▶ Carry out action steps according to the illustration.
- ▶ Automatic defrosting is started. When the defrosting process is complete, the appliance automatically switches back to normal operation.

Note

If there is still ice in the interior after the automatic defrosting has been started several times, defrost the appliance manually. (see 8.2 Defrosting appliance)

Cancelling a manually started defrosting



Fig. 131




Fig. 132

- ▶ Carry out action steps according to the illustration.
- ▶ Manually started defrosting is cancelled. The appliance automatically switches back to normal operation.



Defrosting info

This setting adjusts the display during an automatic defrosting.

| Display | Description |
|---------|--|
| Def 1 | The temperature display is not being updated. It shows the last temperature before the automatic defrosting process started. |

| Display | Description | |
|--------------|--|--|
| Def 2 | “Automatic defrosting” icon is indicated on the status display. The temperature display is continuously updated and displays the actual temperature. | |
| Def 3 | With software version PW SW lower than TOD 8-800 : | The temperature display is not being updated. It shows the last temperature before the automatic defrosting process started. |
| | With software version PW SW equal to or higher than TOD 8-800 : | The temperature display is continuously updated and displays the actual temperature. |
| Def 4 | With software version PW SW lower than TOD 8-800 : | The temperature display is not being updated. It shows the last temperature before the automatic defrosting process started. |
| | With software version PW SW equal to or higher than TOD 8-800 : | “Automatic defrosting” notice is indicated on the status display. The temperature display is not being updated. It shows the last temperature before the automatic defrosting process started. |

Defrosting Display of the “automatic defrosting” in the status display

Here you can see the software version installed on your appliance PW SW: (see 6.2.18 Software)




Fig. 133




Fig. 134

- Carry out action steps according to the illustration.
- The desired display variant is selected.

6.2.20 Sensor calibration



You can use sensor calibration to compensate for differences between the set temperature and the actual existing temperature. To do this, use calibrated measuring equipment to determine the actual existing temperature. Setting range: +/- 3 Kelvin in 0.1 Kelvin increments.

Calibrating the sensor



Fig. 135




Fig. 136

- Carry out action steps according to the illustration.
- The sensor is calibrated.

Note

The calibrated temperature is indicated on the display within two hours.

6.2.21 Temperature alarm



Use this function to set the temperature alarm. You set the upper and lower temperature limits with a differential offset to the indoor temperature currently set. The temperature alarm is triggered as soon as the indoor temperature leaves the set temperature range and any set delay time has elapsed.

| Example | | Differential value to be set |
|----------------------------|------|------------------------------|
| Current indoor temperature | 5 °C | |
| Lower temperature limit | 2 °C | -3 °C |
| Upper temperature limit | 8 °C | +3 °C |

The following values can be set:

- Differential value for lower temperature limit in 0.1 °C steps
- Differential value for upper temperature limit in 0.1 °C steps
- Alarm delay time from 0 to 60 minutes (setting “0” means no temperature alarm delay.)
- Alarm repetition frequency from 0 to 30 minutes (setting “0” means no alarm repetition after confirming the alarm.)

Setting temperature alarm




Fig. 137




Fig. 138

- Carry out action steps according to the illustration.



Fig. 139




Fig. 140 Example of setting the lower temperature limit based on a set appliance temperature of 5 °C.

- Carry out action steps according to the illustration.
- Lower temperature limit has been set.




Fig. 141 Example of setting the lower temperature limit based on a set appliance temperature of 5 °C.

- Carry out action steps according to the illustration.
- Upper temperature limit has been set.




Fig. 142

- Carry out action steps according to the illustration.
- Alarm delay time has been set.




Fig. 143

- Carry out action steps according to the illustration.
- Alarm repetition interval has been set.
- Temperature alarm has been set.

Displaying set temperature alarm values



Fig. 144




Fig. 145

- Carry out action steps according to the illustration.




Fig. 146




Fig. 147

- Carry out action steps according to the illustration.
- Set temperature alarm values are displayed.

6.2.22 Door alarm



Use this function to activate or deactivate the door alarm. The door alarm sounds if the door is open for too long. The door alarm is activated on delivery. You can set how long the door may be open before the door alarm sounds.

The following values can be set:

- 15 seconds
- 30 seconds
- 60 seconds
- 90 seconds

- 120 seconds
- 150 seconds
- 180 seconds
- Off

Setting the door alarm



Fig. 148




Fig. 150 Example illustration: Switch door alarm from 30 seconds to 60 seconds.

- ▶ Carry out action steps according to the illustration.
- ▶ The door alarm is set.

Deactivating the door alarm




Fig. 151




Fig. 152

- ▶ Carry out action steps according to the illustration.
- ▶ The door alarm is deactivated.



6.2.23 Light alarm *

This setting allows the visual alarm messages in the display to also be emphasised by flashing appliance lighting.

Activating light alarm



Fig. 153




Fig. 154

- ▶ Carry out action steps according to the illustration.



Fig. 155




Fig. 156

- ▶ Carry out action steps according to the illustration.
- ▶ The light alarm is activated.

Deactivating light alarm



Fig. 157



Fig. 158

- ▶ Carry out action steps according to the illustration.



Fig. 159




Fig. 160

- ▶ Carry out action steps according to the illustration.
- ▶ The light alarm is activated.

6.2.24 Alarm simulation



You can use this function to simulate a temperature alarm in the appliance, e.g. to check whether a safety device triggers correctly. The safety device is connected to the potential-free alarm output. (see 7.3 Interfaces)

Starting the alarm simulation



Fig. 161




Fig. 162

► Carry out action steps according to the illustration.




Fig. 163




Fig. 164

► Carry out action steps according to the illustration.
 ► The simulation has been performed.
 ► Connected safety devices should have triggered.

6.2.25 Alarm forwarding



You can use this function to forward one or several alarms to an external alarm receiver. The alarm receiver is connected to the potential-free alarm output on the appliance. (see 7.3 Interfaces)

You can select the following settings:

- Alarm type:
 - Door alarm
 - Temperature alarm
 - Door alarm and temperature alarm
 - All
- Confirm:
 - **Yes:** The alarm is confirmed on the appliance and the external, connected receiver.
 - **No:** The alarm is confirmed on the appliance and remains active on the receiver until the fault is rectified.
- Refresh (only visible if you select “Yes” when confirming):
 - **Yes:** Alarm repeats.
 - Temperature alarm** depending on the set time (see 6.2.21 Temperature alarm)
 (If you set the alarm delay time to “0”, there is no alarm repetition on the alarm relay.)
 - Door alarm** after 1 or 4 minutes* (see 6.2.22 Door alarm)
 - **No:** The alarm is confirmed permanently.

Activating alarm forwarding



Fig. 165




Fig. 166

- ▶ Carry out action steps according to the illustration.
- ▶ Alarm forwarding is set.

6.2.26 Demo mode



Demo mode is a special feature for dealers who want to demonstrate appliance features. If you activate demo mode, all refrigeration functions are deactivated.

If you switch on your appliance and a "D" appears on the status display, demo mode is already activated.

If you activate and then deactivate demo mode, the appliance will be reset to factory defaults. (see 6.2.27 Resetting to factory settings)

Activating demo mode



Fig. 167




Fig. 168

- ▶ Carry out action steps according to the illustration.
- ▶ Demo mode is activated.
- ▶ Appliance is switched off.
- ▶ Switch on the appliance. (see 4.15 Switching on appliance (first use))
- ▶ "D" appears in the status display.

Deactivating demo mode



Fig. 169




Fig. 170

- ▶ Carry out action steps according to the illustration.
- ▶ Demo mode is deactivated.
- ▶ Appliance is switched off.
- ▶ Switch on the appliance. (see 4.15 Switching on appliance (first use))
- ▶ Appliance is reset to factory settings.

6.2.27 Resetting to factory settings



Use this function to reset all settings to factory defaults. All settings you have made so far are reset to their original settings.

Performing a reset



Fig. 171


















Fig. 172












- Carry out action steps according to the illustration.
- Device is reset.
- Device is switched off.
- Restart the device. (see 4.15 Switching on appliance (first use))

6.3 Messages

6.3.1 Warnings



Warnings are issued by means of an audio signal and visually via a symbol on the display. The signal gets louder until the warning is acknowledged.



| Message | Cause | Remedy |
|--|---|---|
|  <p>Door open</p> <p>Door open</p> | <p>This message appears if the door is open for too long.</p> | <p>Close the door.</p> <p>Press the confirmation button.</p> <p>Alarm is ended.</p> <p>Note</p> <p>You can set how long it takes for this message to appear (see 6.2.22 Door alarm).</p>  |
|  <p>Temperature</p> <p>Temperature alarm</p> | <p>This message appears if the temperature does not match the set temperature. Reasons for the differences in temperature can be:</p> <ul style="list-style-type: none"> - Warm items for refrigeration have been placed inside. - Too much warm room air flowed in when rearranging and removing refrigerated products. <p>The power was cut off for a prolonged period.</p> | <p>Press the confirmation button.</p> <p>Warmest temperature is displayed.</p>  <p>Press the confirmation button.</p> <p>The current temperature flashes and the display alternates with the temperature alarm symbol until the set temperature is reached.</p>  <p>Check the quality of the refrigerated goods.</p> |
|  <p>Error</p> <p>Error</p> | <p>The appliance is defective, there is an appliance fault or a component of the appliance is faulty.</p> | <p>Transfer refrigerated goods.</p> <p>Press the confirmation button.</p> <p>Error code is displayed.</p>   <p>Press the confirmation button.</p> <p>If present, another error code is indicated.</p> <p>or</p> <p>Status screen with flashing error symbol is displayed</p> <p>Pressing the navigation buttons indicates error code(s) again.</p> <p>Note the error code(s) and contact customer service.</p>   |
| | <p>Message indicates that the freezer protection mode is active (e.g. due to frequent door openings or loading with goods).</p> | <p>Press the confirmation button.</p> <p>FRZ.PROT. is displayed.</p>   <p>Press the confirmation button.</p> <p>Status screen with flashing error symbol is displayed</p>   <p>Pressing the navigation buttons displays the error code again.</p> <p>The appliance automatically switches to normal operating mode after a few hours and the message disappears. If the message is displayed repeatedly and the causes listed do not apply, contact customer service. (see 9.3 Customer Service)</p> |

| Message | Cause | Remedy |
|---|---|---|
|  <p>Power</p> <p>Power failure</p> | The message appears after an interruption in the power supply if the temperature is above the alarm limit when the power returns. | <p>Press the confirmation button. The warmest temperature is displayed.</p>  <p>Press the confirmation button. Alarm is cancelled and current temperature is indicated. Check the quality of the refrigerated goods.</p>  |
|  <p>WiFi error</p> <p>WLAN error</p> | WLAN connection is interrupted. | <p>Check the connection. Press the confirmation button. Alarm is ended.</p>  |
|  <p>WWW error</p> <p>WLAN WWW error</p> | The message appears if there is no Internet connection via WLAN. | <p>Check the connection. Press the confirmation button. Alarm is ended.</p>  |
|  <p>LAN error</p> <p>LAN error</p> | LAN connection is interrupted. | <p>Check connection and network cable. Press the confirmation button. Alarm is ended.</p>  |
|  <p>WWW error</p> <p>LAN WWW error</p> | The message appears if there is no Internet connection via LAN. | <p>Check the connection. Press the confirmation button. Alarm is ended.</p>  |

6.3.2 Reminder

Reminders appear when you are being asked to do something. They are issued by means of an audio signal and visually via a symbol on the display. Acknowledge the message by pressing the confirmation button.

| Message | Cause | Remedy |
|--|--|--|
|  <p>Maintenance</p> <p>Maintenance reminder</p> | The message appears when the timer for the set maintenance interval has expired. |  <p>Press the confirmation button. Alarm is ended.</p> <p>Note The maintenance interval can be set (see 6.2.8 Maintenance interval reminder).</p> |

| Message | Cause | Remedy |
|--|---|--|
|  <p>Recording reminder</p> | This message appears when the temperature recording memory (999 hours) is full. |  <p>Press the confirmation button. Alarm is ended. The oldest data is overwritten.</p> <p>Note The temperature recording can be reset (see 6.2.4 Temperature recording).</p> |

7 Features

7.1 Safety lock

The lock in the appliance door is equipped with a safety mechanism.

7.1.1 Locking appliance




Fig. 173 Example illustration

- Insert key.
- Turn key anticlockwise by 90°.
- The appliance is locked.

7.1.2 Unlocking appliance




Fig. 174 Example illustration

- Insert key Fig. 174 (1).
- Turn key clockwise by 90° Fig. 174 (2).
- The appliance is unlocked.

7.2 Sensors

The appliance can be equipped with the following sensors for temperature monitoring:

- Safety thermostat sensor
- C sensor

7.2.1 Safety thermostat sensor

The safety thermostat sensor monitors the temperature drop and thus protects against excessively low temperatures (Freeze Protect). If the temperature drops below the threshold value, the appliance regulates the temperature automatically. The error message FRZ. PROT (Freeze Protect) (see 6.3 Messages) appears.

Note

Do not cover the safety thermostat sensor.

7.2.2 C sensor (control sensor)

The C sensor is permanently installed and regulates the interior temperature of the appliance. You can calibrate the C sensor if necessary. (see 6.2.20 Sensor calibration)

7.3 Interfaces

There are various connection options on the back of the appliance.




Fig. 175

Note

Screws secure the plugs. To enable disconnection of the plugs, loosen the screws on the left and right.




Fig. 176

- (1) Potential-free alarm output

7.3.1 Potential-free alarm output



WARNING

Risk of injury due to electric shock!

- The appliance may only be connected to an external alarm device by trained specialist personnel.

These three contacts can be used to connect a visual or an acoustic alarm device. The connection is designed for a maximum of **30 V (DC) - 8 A** from a safety low voltage source SELV (minimum current 150 mA).




Fig. 177

- (1) NO (normally open)**
Connection for indicator lamp, which is active in normal operation or when the appliance is switched off.
- (2) COM (common)**
External voltage source
- (3) NC (normally closed)**
Connection for alarm lamp or audible alarms, which is active when an alarm is triggered or there is a lack of power supply.



WARNING

Short-circuit hazard due to live parts!
Electric shock or damage to the electronics.

- **Switch off the appliance.**
- Pull out mains plug or switch off fuse.

Note

A maintenance reminder function can be activated. (see 6.2.8 Maintenance interval reminder)

Note

We recommend creating a maintenance log in which all work (repairs, checks) performed is documented.

Note

Liebherr recommends yearly maintenance. For an individual offer, please contact Customer Service (see 9.3 Customer Service).

8 Maintenance

8.1 Maintenance schedule

Maintenance work is to be performed at regular intervals to ensure proper appliance function.



CAUTION

Danger of injury and damage due to unprofessional maintenance work!
Personal injury and material damage.

- Maintenance work may only be performed by trained specialist personnel.

| Component | Activity | Maintenance interval |
|---------------------|--|---|
| Sheet metal parts | Check for damage and corrosion. Replace damaged parts: (see 9.3 Customer Service) | Yearly |
| Door, hinges | Check alignment (see 4.13 Aligning the door) , ease of movement, and tight fit. | Yearly |
| Lock, door handle * | Check for ease of movement and tight fit. | Yearly |
| Door seal | Check for damage, wear, and tight fit. A replacement door seal is available via Customer Service (see 9.3 Customer Service) . | Yearly |
| Sensor | Calibrate sensor. (see 6.2.20 Sensor calibration) | Yearly |
| Sensor feedthrough | Check that the sealing compound is intact. | Yearly |
| Surfaces | Cleaning (see 8.3 Cleaning the appliance) | Recommendation: monthly or as required/specified at installation location |

Maintenance

| Component | Activity | Maintenance interval |
|----------------------------------|---|---|
| Surfaces | <p>Disinfection</p> <p>Liebherr has tested the following disinfectants:</p> <p>Dismozon pur 1 % Lösung (Bode Chemie), Suma Quicksan (Diversey), Incidin Extra N (Ecolab Healthcare), Acrylan (Antiseptica chem.-pharm. Produkte), Buraton 10 F (Schülke und Mayr), Frankocid N (Franken Chemie), Apesin DSR 50 (Tana), Nüscosept Spray (Dr. Nüsken), Melsept SF (B. Braun Melsungen), Kohrsolin (Bode Chemie), Neoquat S (Dr. Weigert), Incidin Rapid (Ecolab Healthcare), Bacillocid Spezial (Bode Chemie), Neoform K Spray (Dr. Weigert), Apesin Desinf. Spray (Tana), Nüscosept 100 (Dr. Nüsken), Antisept T (Fink Tec), Apesin AP 100 0,50% Lösung (Tana), Perform Pulver 2% Lösung (Schülke und Mayr)</p> <p>Observe the operating instructions of the respective manufacturer. If disinfectants other than those stated are used, test them on a less exposed area first.</p> | Recommendation: monthly or as required/specified at installation location |
| Installation location, appliance | <p>Decontamination</p> <p>The appliance is suitable for room decontamination with hydrogen peroxide H₂O₂.</p> <p>In this context, the values of the following application specifications must not be exceeded:</p> <p>Concentration: maximum 250 ppm.</p> <p>Humidity: maximum 85%.</p> <p>Maximum permissible room temperature as per climate class. (see 1.4 Range of use of appliance)</p> | Recommendation: as required/specified at installation location, maximum 2x per year |
| Fan air slots | Cleaning | Yearly |
| Alarm relay | | |
| Mains cable | Check for damage. | Yearly or if there is a change of location |
| Tilt angle | Check for proper function and tight fit. | Yearly or if there is a change of location |
| Adjusting feet/castors | Check for proper function, damage, and tight fit. Replace damaged parts. (see 9.3 Customer Service) | Yearly |

8.2 Defrosting appliance



WARNING

Improper defrosting of the appliance!
Injuries and damage.

- Do not use mechanical equipment or other methods to speed up the defrosting process other than those recommended by the manufacturer.
- Do not use electrical heating or steam-cleaning appliances, naked flames or defroster sprays to defrost.
- Do not use sharp objects to remove ice.

Defrosting is performed automatically. The defrost water drains through the opening and evaporates.

To maintain the functionality of the appliance, we recommend defrosting it when there is a high buildup of ice. Icing in the interior is determined by the location (e.g. high humidity), settings on the appliance and incorrect user behaviour.

If the automatic defrosting cycle is insufficient:

- Start automatic defrosting manually.
(see 6.2.19 Defrosting)

If the problem persists, defrost the appliance manually:

- Switch off appliance. (see 6.2.2 Switching appliance on and off)
- Pull out mains plug.
- Store refrigerated items elsewhere.
- Leave appliance door open during defrosting process.
- Soak up remaining defrost water with a cloth, clean drain opening and the appliance.

8.3 Cleaning the appliance

8.3.1 Preparing



WARNING

Short-circuit hazard due to live parts!
Electric shock or damage to the electronics.

- **Switch off the appliance.**
- Pull out mains plug or switch off fuse.



WARNING

Risk of fire

- Do not damage the refrigeration circuit.

- ▶ Empty the appliance.
- ▶ Pull out the mains plug.
- ▶ Observe the notes on transporting the appliance. (see 4.3 Transporting appliance)

8.3.2 Cleaning housing

NOTICE

Improper cleaning!

Damage to the appliance.

- ▶ Only use soft cleaning cloths and ph-neutral all-purpose cleaners.
- ▶ Do not use abrasive sponges or steel wool which may cause scratches.
- ▶ Do not use any sharp or abrasive cleaning agents, nor any that contain sand, chloride or acid.



WARNING

Risk of injury and damage as a result of hot steam!
Hot steam can lead to burns and can damage the surfaces.

- ▶ Do not use any steam cleaners!

NOTICE

Risk of damage due to short circuit.

- ▶ When cleaning the appliance, make sure no water gets into the electrical components.

- ▶ Wipe the housing down with soft, clean cloth. If very dirty, use lukewarm water with a neutral cleaner. Glass surfaces can also be cleaned with glass cleaner.
- ▶ Clean condenser coil each year. If the condenser coil is not cleaned, this significantly reduces the efficiency of the appliance.

8.3.3 Cleaning interior



WARNING

Short-circuit hazard due to live parts!

Electric shock or damage to the electronics.

- ▶ **Switch off the appliance.**
- ▶ Pull out mains plug or switch off fuse.



WARNING

Risk of injury and damage as a result of hot steam!

Hot steam can lead to burns and can damage the surfaces.

- ▶ Do not use any steam cleaners!

NOTICE

Improper cleaning!

Damage to the appliance.

- ▶ Only use soft cleaning cloths and ph-neutral all-purpose cleaners.
- ▶ Do not use abrasive sponges or steel wool which may cause scratches.
- ▶ Do not use any sharp or abrasive cleaning agents, nor any that contain sand, chloride or acid.

Note

- ▶ Defrost water drain (see 1.2 Overview of the appliance and equipment) : Remove deposits using a thin material (for example a cotton bud).

Note

Do not damage or remove the type plate on the inside of the appliance. The type plate is important for Customer Service. (see 9.3 Customer Service)

- ▶ Open the door.
- ▶ Empty the appliance.
- ▶ Clean interior and equipment parts with lukewarm water and a little detergent. Do not use any gritty or acidic cleaning agent or any chemical solvent.

8.3.4 After cleaning

- ▶ Wipe appliance and equipment parts dry.
- ▶ Connect and switch on appliance.
Once the temperature is sufficiently cold:
- ▶ put in items for refrigeration goods.
- ▶ Repeat cleaning regularly.
- ▶ Clean and remove dust from the refrigeration unit with heat exchanger once a year.

9 Customer help

9.1 Technical specifications

Temperature range

| | |
|---------|-----------------|
| Cooling | +3 °C to +16 °C |
|---------|-----------------|

Maximum load per shelf ^{A)}

| Appliance width | 600 mm | 750 mm |
|-----------------------------|--------|--------|
| Grid shelves | 45 kg | 60 kg |
| Glass shelf | 40 kg | 40 kg |
| Drawer (freezer appliances) | 20 kg | 20 kg |

A) Heavier loads may result in a slight bending of the shelves.

Maximum total load and net weight

| Model (see 4.2 Appliance dimensions) | Maximum load | total | Net weight |
|--------------------------------------|--------------|-------|------------|
| SRTvg 1501 | 180 kg | | 35 kg |
| SRTvg 1511 | | | 43 kg |

Net capacity

See net capacity on the type plate. (see 1.2 Overview of the appliance and equipment)

Lighting*

| Energy efficiency class ^{A)} * | Light source* |
|---|---------------|
| This product contains one or more energy efficiency class G light sources | LED |

A) The appliance may contain light sources with different energy efficiency classes. The lowest energy efficiency class is indicated.

Set-up conditions

| | |
|--|-------------------------------|
| Degrees of pollution (surrounding the appliance) | PD2 |
| Ambient temperature | +10 °C to +35 °C |
| Maximum relative ambient moisture | 75%, not condensing |
| Maximum operating elevation (metres above sea level) | 2000 m 1500 m (glass door) |

Electrical values

| | |
|-----------------|-------------|
| Nominal voltage | 220-240 V ~ |
|-----------------|-------------|

| Electrical values | |
|---------------------------|--------|
| Frequency | 50 Hz |
| Connected load | 2,0 A |
| Maximum mains fluctuation | +/-10% |
| Overvoltage categories | II |

a fault occurs during operation, please check whether the fault is due to an operating error. If this is the case, you will be charged for the cost incurred even if this falls within the warranty period.

You can fix the following faults yourself.

9.2.1 Appliance function

9.2 Technical fault

Your appliance is designed and built to ensure it works reliably and has a long service life. In the unlikely event that

| Defect | Cause | Remedy |
|--|--|--|
| The appliance is not working. | → The appliance is not switched on. | ▶ Switch on the appliance. |
| | → The mains plug is not properly plugged into the socket. | ▶ Check the mains plug. |
| | → There is something wrong with the fuse in the socket. | ▶ Check fuse. |
| | → Power cut | ▶ Keep the appliance closed. ▶ If necessary move the refrigerated/frozen items to another fridge or freezer if the power is off for a prolonged period. |
| | → The IEC socket is not plugged into the appliance correctly. | ▶ Check the IEC socket. |
| Temperature is not cold enough. | → The appliance door is not closed properly. | ▶ Close appliance door. |
| | → Ventilation is not sufficient. | ▶ Clear ventilation grille and clean it. |
| | → The ambient temperature is too high. | ▶ Ensure the correct ambient conditions: (see 1.4 Range of use of appliance) |
| | → The appliance was opened too many times or for too long. | ▶ Wait to see if the appliance goes back to the required temperature by itself. If not, contact Customer Service. (see 9.3 Customer Service) |
| | → The temperature is set incorrectly. | ▶ Set a colder temperature and check after 24 hours. |
| | → The appliance is too close to a heat source (oven, radiator, etc). | ▶ Change where the appliance or the heat source are located. |

9.3 Customer Service

First check whether you can remedy the fault yourself. If this is not the case, please contact Customer Service.

You can find the address in the enclosed brochure "Liebherr-Service" or at home.liebherr.com/service.



WARNING

Unprofessional repair!
Injuries.

- ▶ Have any repairs and action - not expressly specified - on the appliance and mains cable carried out by service personnel only. (see 8 Maintenance)
- ▶ A damaged mains cable may only be replaced by the manufacturer, the manufacturer's Customer Service or a similarly qualified person.
- ▶ In the case of appliances with an IEC connector, the change may be made by the customer.

9.3.1 Contacting Customer Service

Make sure you have the following appliance data at the ready:

- ☐ Appliance name (model and index)
- ☐ Service no. (Service)
- ☐ Serial no. (S no.)

- ▶ Access the appliance information via the display (see 6.2.16 Device information).

-or-

- ▶ Refer to the type plate for appliance information. (see 9.4 Type plate)
- ▶ Note down appliance information.
- ▶ Inform Customer Service: Report faults and the appliance information.
- ▶ This will help us to provide a fast and focussed service.
- ▶ Follow any further instructions provided by Customer Service.

9.4 Type plate

The type plate is inside the appliance. See appliance overview.




Fig. 178

- (1) Appliance designation (3) Serial No.
(2) Service No.

10 Shutting down

- ▶ Empty the appliance.
- ▶ Switch off the appliance.
- ▶ Pull the mains plug out of the socket.
- ▶ Remove the IEC socket if required: Pull the IEC socket out of the appliance plug and move it to the left and right at the same time.
- ▶ Clean appliance (see 8.3 Cleaning the appliance).
- ▶ If present: Remove the covers and insulation from the sensor feed-through to prevent mould forming.
- ▶ Leave the door open so that no bad odours form.

Note

Damage to the appliance and malfunctions!

- ▶ After shutting down, only store the appliance at the permitted room temperature of between -10 °C and +50 °C.

11 Disposal

11.1 Preparing appliance for disposal



Liebherr uses batteries in some of its appliances. In the EU, for environmental reasons, legislation obliges the end user to remove these batteries before disposing of old appliances. If your appliance contains batteries, a corresponding notice is attached.

Lamps If you can remove the lamps yourself without destroying them, also remove these before disposal.

- ▶ Take the appliance out of operation.
- ▶ If possible: remove lamps without destroying them.

11.2 Disposing of the appliance in an environmentally friendly manner



The appliance still contains valuable materials and must be disposed of separately from unsorted municipal waste.



Dispose of batteries separately from the old appliance. To do this, you can return the batteries free of charge to retailers as well as recycling centres and collection centres for recyclable materials.

Lamps Dispose of removed lamps via the respective collection systems.

For Germany:

You can dispose of the appliance free of charge via the class 1 collection containers at the local recycling and recyclable material collection centres. When purchasing a new fridge/freezer, if the sales area > 400 m², retailers will also take back the old appliance free of charge.



WARNING

Leaking coolant and oil!

Fire. The coolant contained in the appliance is eco-friendly, but also flammable. The oil contained in the appliance is flammable. Escaping coolant and oil can ignite if the concentration is high enough and in contact with an external heat source.

- ▶ Do not damage the pipelines of the coolant circuit and the compressor.

- ▶ Observe the notes on transporting the appliance. (see 4.3 Transporting appliance)

- ▶ Transport the appliance without damaging it.

- ▶ Dispose of batteries, lamps and the appliance according to the above specifications.

12 Additional information

Further information on warranty conditions can be found in the enclosed service brochure or on the Internet at <https://home.liebherr.com>.



Pass on this info in the event of a device fault:

Model identifier /
Inventory number:

Quick Start Guide for everyday use

Information about using this Quick Start Guide:

- This Quick Start Guide is not a substitute for the full operating instructions nor is it a substitute for appliance training.
- This Quick Start Guide provides support for everyday use and handling the appliance.
- Read the full operating instructions and the safety notes contained therein.

This quick start guide is for: SRTvg 15..



Scanning the QR code will open the full operating instructions:



Intended use

Foreseeable incorrect use

Do not use the appliance for the following applications:

- Storage and refrigeration of:
 - Chemically unstable, flammable or corrosive substances
 - Blood, plasma or other body fluids for the purpose of infusion, application or introduction in the human body
- Use in potentially explosive atmospheres
- Use outdoors or in areas exposed to dampness and splashing water

When stocking, observe the following points:

- ☐ Position grid shelves according to the height required.
- ☐ Observe maximum load.
- ☐ When the storage temperature has been reached, load the appliance (compliance with cold chain).
- ☐ Keep the ventilation slots of the recirculation fan free in the interior.
- ☐ Produce for cooling must not come into contact with the evaporator on the rear wall.
- ☐ Keep liquids in closed containers.
- ☐ Leave space when storing refrigerated goods to ensure good air circulation.

Status display



Fig. 179 Status display with actual temperature

Displaying temperature recording

The temperature recording displays the length of the recording and the minimum and maximum temperatures measured during this period of time.




Fig. 180

Resetting temperature recording




Fig. 181

Unlocking appliance




Fig. 182

- Insert the key. Fig. 182 (1)
- Turn the key clockwise by 90°. Fig. 182 (2)
- The appliance is unlocked.

Locking appliance




Fig. 183

- Insert the key. Fig. 183 (1)
- Turn the key anticlockwise by 90°. Fig. 183 (2)
- The appliance is locked.

Cleaning appliance

- Empty the appliance.
- Pull out the mains plug.
- Observe the information in the operating instructions.
- Dry the appliance and equipment thoroughly after cleaning.
- Connect the appliance.
- Switch on the appliance.
- Load the appliance once the storage temperature is reached.




What should I do if there is a fault?

A message appears in the display if there is a fault. Messages have different meanings:

| Symbol colour in the display | Meaning | Remedy |
|------------------------------|---|---|
| WHITE with black bar | Reminder Reminder of general procedures. You can carry out these procedures to eliminate the message. | Consult the operating instructions and perform the troubleshooting steps. |
| WHITE | Warning Appears when there are malfunctions. You can eliminate simple malfunctions yourself. | Consult the operating instructions and perform the troubleshooting steps. |

If you cannot remedy the fault yourself, contact a competent member of staff or your nearest customer service outlet.



home.liebherr.com/fridge-manuals

EN countertop fridge
ORIGINAL OPERATOR'S MANUAL

Issue date: 20250506

Part number index: 7086641-00

Liebherr Hausgeräte Lienz GmbH
Dr.-Hans-Liebherr-Strasse 1
A-9900 Lienz
Österreich

