

MyLiebherr – your personal customer portal



Your mobile online portal

MyLiebherr is your entry into the Liebherr service world. Through the Liebherr customer portal, you benefit from comprehensive service and additional services relating to the world of construction machinery, concrete technology, mining, Mobile and crawler cranes, drilling rigs, handling technology and maritime cranes.



Scan, log in and immediately into the Liebherr service world.

And these are your advantages at a glance:

- individual management of your machines
- easy contact with your Liebherr service partner, independent of opening hours
- direct insight and secure management of your customer data
- Online access to the latest spare parts documentation for your machine at all times
- direct and convenient ordering option from your Liebherr service partner

Our portal is under constant development. Soon, further modules will help you to generate even more benefits from digital services from your machine.

Customer service



Service by conviction

Good service means customer proximity. With our professional service network, we are at your disposal response times to ensure high machine availability. Reliable machines are the guarantee for your success. Our highly trained service personnel will ensure economical and smooth operation of your Liebherr Liebherr products. We help with commissioning, instruction of machine operators and answer your questions.

Liebherr service partner worldwide

Our customers can rely on a worldwide sales and service network consisting of over 90 service centers (Liebherr companies / partners), 160 service vehicles and 220 qualified service service technicians. Our worldwide service points with all their contacts can be found on the Liebherr website or in the MyLiebherr customer portal.



Service-friendly design

From the very beginning of the design, great importance was attached to servicefriendliness. Wear parts are easy to change, and important areas are easily accessible.





Original Liebherr Spare Parts

Original spare parts from Liebherr are subject to strict quality controls, are quickly available worldwide and guarantee reliable operation and a long service life.





Strong partners - Strong service

The expert team of Liebherr service partners is ready to provide competent and reliable support.



Original Liebherr spare parts

Please pay attention to the truck mixer series 04 or 05. Example: you have a HTM $904F = \text{drum size } 9\text{m}^3 \text{ in series } 04$



Truck mixer drum

Description,	ID-No.
--------------	--------

Truck mixers series 04 and 05 Truck mixer replacement drum with or without painting	available on request from your friendly service partner
Series 904	
Gasket for manhole cover - small D=430mm	970091305
Series 904 from 2015 and 905	
Gasket for manhole cover - large D=510mm	11165598





Drum bearing

Series 904	
Roller seating compl. 6 / 7m³; without fitting screw	940093905
Roller seating compl. $8/9/10/12m^3$; without fitting screw	949337905
Fitting screw 6 / 7m³	941526105
Fitting screw 8 / 9 / 10 / 12m³	956043005
Hexagon nut for fitting screw 6 / 7m³	411902405
Hexagon nut for fitting screw 8 / 9 / 10 / 12m³	411903605
Washer for fixing Bolt 6 / 7m³	421500805
Washer for fixing Bolt 8 / 9 / 10 / 12m³	421703805
Grease nipple for fixing Bolt 941526105 and 956043005	774300105
Series 905	
Roller seating compl. 7-10m³, without fitting screw	949703805
Fitting screw 7-10m³	949804605
Washer for fixing Bolt	421101505
Hexagon nut for fitting screw	11167872
Roller seating compl.	949703805
Distance washer	949703705
Slotted nut	11167613
Lubrication line	774373708
Fitting 6/M10x1	10009258
Grease nipple	774300105
Protective cap for grease nipple	774310005
Adhesive sign for skier positions 2M	11169079





Inlet and outlet hoppers

Description, ID-No.

Series 904	
Inlet hopper with wear plate from 2021	13556602
Inlet hopper with wear plate 6 / 7m³	942271605
Inlet hopper with wear plate 8 / 9 / 10 / 12m³	942272805
Wear plate for all inlet hoppers	949234605
Rubber apron for inlet hopper / increase by 200 mm	947745005
Series 905	
Inlet hopper with wear plate from 2021	13556601
Inlet hopper with wear plate	949704705
Rubber apron for inlet hopper / increase by 200 mm with cutout for water nozzle	949807005
Inlet hopper with wear plate	90411484
Rubber apron for inlet hoper / increase by 200 mm	947745005
Wear plate	949234605
Protective grille at the inlet funnel (driving direction left)	90401308
Series 904	
Discharge hopper, without wear plate	946241805
Discharge hopper, with wear plate right	946241905
Wear plate right	942736505
Series 905	
Discharge hopper, with wear plate right	949707605
Discharge Hopper, with wear plate; LGB-Version	90412631
Wear plate, right for 949707605	949708305
Wear plate, right for 90412631	90412637
Rubber Seal Discharge hopper	949802105
Fastening strip for seal	949802205
Water Nozzle	949910005
Threaded pipe union 1"	11167515
Box Nut for mounting the flat spray nozzle	11168025
Fan Nozzle	11168021
Rubber apron for discharge hopper as all-round splash protection and extension	90415010
Spray tube (in inlet hopper on the side)	90411133
Flat jet nozzle for spray tube	11169358
Strainer hopper	90415139



5



Outlet chute and accessories

Descriptio	n, ID-No.
------------	-----------

Series 904	
Discharge chute with wear plate; L= 1300mm, W= 700mm	944990705
Discharge chute with wear plate for flip over chute; L= 1300mm, W= 700mm	946180405
Discharge chute with wear plate; L= 1570mm, W= 700mm	946183905
Discharge chute with wear plate for flip over chute; L= 1570mm, W= 700mm	946186805
Flip over chute; L= 700mm, steel	946180505
Wear plate for 941468605, 941495605, 941881405, 942519805, 944564505, 945075405 and 959686505	940024305
Wear plate for 942986505, 944189405, 944905205 and 945075205	942986705
Wear plate for 944990705 and 946180405	944992805
Wear plate for 946183905 and 946186805	946186505
Series 905	
Discharge chute with wear plate extendable; L= 1390mm, W= 570mm	949626405
Wear plate for outlet chute 949626405	949627005
Rubber apron (splash guard increase)	949631605
Clamping strip for rubber apron 949631605	949912705
Folding outlet chute with wear plate without folding extension L = 1390 mm, B = 570 mm	949904005
Folding chute 700mm for 949904005	90401230
Detent lever for folding chute	949929005
Wear plate for folding outlet chute 949904005	949627005
Spring bolt for folding chute	10114710
Series 904	
Hydraulic cylinder, single acting	956235305
Hydraulic cylinder, double acting	970257505
Hydraulic hand pump	510107305
Fixing bolts and nuts like crank discharge chute	942932805
Series 905	
Hydraulic cylinder, single acting	11169094
Hydraulic cylinder, double acting	11169499
Hydraulic hand pump	510107305
Pump lever for hydraulic hand pump	942932805
Cylinder cover - Mudguard	942938405
Fixing bolts and nuts like crank discharge chute you will find on page 7	





Outlet chute and accessories

Descri	ption,	ID-No.
--------	--------	--------

Series 904	
Crank discharge chute	955963205
Handle compl.	595603705
Pin	956184205
Pin	956184305
Hexagon nut	11840127
Series 905	
Crank discharge chute, series 905	949808905
Handle compl.	595603705
Pin	956184205
Pin	949809105
Rondelle	11646244
Hexagon nut	11840127
Series 904	
Clamping ring	946230705
Toggle screw	956226205
Square nut	12223693
Limit stop	10818321
Discharge Chute Lock	774209905
Bush 60/65x40	749900905
Bush 40/44x40	749904105
Series 905	
Clamping ring	949707305
Clamping lever	949911605
Ball head for clamping lever	704001805
Limit stop	949707405
Discharge Chute Lock	774209905
Bush 50/55x40	749905005
Bush 40/44x26	11168120
Series 904	
Sealing for flap 942952305 (Series until 03.2006)	956299805
Sealing for flap 946137305 (Series from 03.2006)	946138005
Sealing for flap 948676405 (Serie from 06.2013)	11163749
Series 905	
Pendulum flap complete	90401138
Rubber handle for pendulum flap	940996705
Pressure spring for handle pendulum flap	720001605
Sealing for flap 948676405 and 90401138	11163749
Frame for mounting seal on pendulum flap	948676905
Wash tank retrofit for cleaning on site	90415139





Extension chutes

Series 904	
Extension chute, steel	940015705
Extension chute, plastic	949521205
Plastic channel for 949521205 and 948284205	948357305
Plastic chute	942391505
Plastic channel for 942391505 and 90401001	942391705
Extension chute, aluminium	946322405
Series 905	
Extension chute, steel	941477305
Extension chute, plastic	90400111
Replacement plastic gutter for 90400111 (new series)	948357305
Plastic channel for 90400111	90400105
Plastic chute	90401001
Plastic channel for 942391505 and 90401001	942391705
Series 904	
Chute holder for steel chute	940996505
Chute holder for plastic chute	942847705
Tension spring for chute hook 940996505 and 942847705	940996805
Clamping pin	432001805
Handle for chute holder	940996705
Profile rubber for chute support	940681505
Profile rubber for chute support	940681505
Series 905	
Chute holder for steel chute / plastic chute	90401216
Tension spring for chute hook 940996505 and 942847705	940996805
Clamping pin	432001805
Handle for chute holder	940996705
Profile rubber for chute support	949911205





Water system

Descri	

ter level gauge; L= 540mm 534908 ter level gauge; L= 650mm 534908 port level gauge; bottom 103273 port level gauge; top 103273 ing (seal for water level glass) 534908 idelle 429906	3305 338 339 3605 0605
port level gauge; bottom 103273 port level gauge; top 103273 ing (seal for water level glass) 534908	338 339 3605 3605
port level gauge; top 103273 ing (seal for water level glass) 534908	339 3605 3605
ing (seal for water level glass) 534908	3605 305
0 1	0605
43000	805
delle 42990l	
ies 905	
ter level gauge; L= 415mm 111688	
ter level gauge; L= 540mm 11168.	125
port level gauge; bottom 103273	338
port level gauge; top 103273	339
delle 429900	0605
le foil to stick on 956152	2805
ies 905	
ter metering counter 10221a	695
ter hose (main line) 11168:	.84
ter hose (secondary lines) 774200	305
trap for water distributor 534714	305
e screen insert for strainer 111638	381
ies 904	
ee-way valve 534702	2305
ssure gauge 511234	705
ssure reducing valve 511234	805
ck valve 534729	5405
ety valve 1/2"; 5 bar 511233	3905
ety valve 1/2"; 3,5 bar 511239	3305
ety valve 1/2"; 2 bar 51123	5505
orflow valve 511235	5605
ies 905	
vay valve 534702	2305
ndle for 3-way tap 53472	1705
ssure gauge 511234	705
ssure regulating valve for control unit and fluid tank 111678	380
eck valve 534725	5405
ety valve 1/2"; 5 bar 511233	3905
ety valve 1/2"; 3,5 bar 511239	5305
ety valve 1/2"; 2 bar 51123	5505



Attention

*After the replacement of the safety valve, the system should only be put back into operation when it was reviewed by an authorized body (according to the guidelines in your country).



Water system

Series 904	
Water tap 3/4" - inner-/ external thread	10028683
Water tap 1 1/2" - inner-/ external thread	10028684
Water tap 3/4" - inner-/ external thread	534701905
Water tap 1 1/2" - inner-/ external thread, with drain valve	534718605
Repair kit for 534718605	11164909
Water tap 1/4" - inner thread	534724405
Fixed coupling 1 1/2" - IG	534903105
Quick-fitting coupling	511252805
Series 905	
Cover bonnet left	11167986
Cover right	11167987
Adhesive baffle aeration/ deaeration	11168956
Control unit 5 bar complete	949918705
3-way valve	534702305
Handle for 3-way tap	534721705
Pressure regulating valve	11167880
Check valve	534725405
Overflow valve (compressed air supply)	511235605
O-ring for overflow valve	502978705
Front panel valve for pneumatic stopcock Water tank	11168901
Selector switch front panel valve	11168236
Silencer for front panel valve	10350873
Adhesive label "Empty	11168959
Shut-off valve water tank	11168858
Series 905	
Water tap 3/4" - inner-/ external thread	10028683
Water tap 2-1" - inner-/ innerternal thread	534702005
Water tap 1/2" - inner-/ innerternal thread	534702105
Fixed coupling 1" - IG	11167906





Hydraulic system

Series 904	
Filter assembly for oil cooler 10329107	11168017
Filter cartridge for suction filter 11168017	11168018
Filter assembly for oil cooler 10818187	10019515
Filter cartridge for suction filter 10019515	510611105
Filter compl. for oil-cooler 11163250	10114232
Filter element for filter 10114232	10114233
Series 905	
Oil cooler complete incl. fan, control unit and filter package	11168558
Axial fan for oil cooler	11169657
Oil sight glass	11169654
Oil drain valve	11169650
Fan control	11168563
Fan control conversion kit replaces fan control 11169644	90411952
Filter assembly for oil cooler	11169655
Filter cartridge for suction filter 11169655	11169637
Series 904	
Temperature switch 55 / 60°C (ZF-gear box)	595674305
Temperature switch 42 / 50°C (oil cooler 10329107)	10327443
Temperature switch 38 / 50°C (oil cooler 10818187)	11163917
Adapter cable for 10327443 (for elder trucks with old cable set; until march 2009)	10327333
Series 905	
Temperature sensor	11169643
Series 904	
Output filter oil on gearbox PLM 7/9	050041205
Series 905	
Consistency manometer	510539205
Measuring coupling G1/4" max. 630Bar	12740183
Measuring hose	510539305
Console for Künsitenz pressure gauge	90401133











Ladder platform, frame and accessories

Descri	

Series 904	
Flap part (3 step)	942363705
Extension ladder	943725405
Ladder lock	726601905
Ladder catch	726602005
Hex screw	11642261
Washer	12228709
Hexagon nut	11656731
Washer	10179993
Split pin	433001905
Pin	451301005
Buffer	726902905
Support	956282205
Buffer	726905205
Hexagon nut	10875619
Washer	10875645
Series 905	
Extension ladder complete without fixing material	949815205
Fixing material for pedestal (pedestal installation)	949818005
Extension ladder	949803705
Spring bolt	11168085
Plain bearing bush 30 x 40	949910905
Plain bearing bush 35 x 45	949818405





Drum control / pump adjustment

Series 904	
Double rack transmitter compl.	595605605
Single rack transmitter compl. (drivers cab)	595615805
Rack transmitter compl. for gas	595617105
Single rack transmitter compl. for pump	595621005
Rack transmitter compl. MC	10011761
Series 905	
Single rack transmitter compl. for pump	595621005
Series 904 / 905	
Control lever for rack transmitter pump	595612705
Control lever for rack transmitter gas	595609705
Tapered handle	595609805





Drum control / pump adjustment

Descri	ntion.	ID-No.

Series 904	
Remote operation for pump; 5,50m	595607505
Remote operation for pump; 6,00m	595606505
Remote operation for pump; 6,50m	595615305
Remote operation for pump; 7,00m	595606705
Remote operation for pump; 7,80m	595605705
Remote operation for pump; 8,60m	595606805
Remote operation for pump; 9,20m	595607705
Remote operation for pump MC; drivers cab; 4,60m	10227942
Remote operation for pump drivers cab; 4,00m	595607905
Remote operation for pump drivers cab; 4,50m	595607805
Remote operation for pump drivers cab; 5,00m	595606405
Series 905	
Remote operation for pump; 6,50m	595615305
Series 904	
Remote operation for gas; 6,00m	595605805
Remote operation for gas; 6,60m	595614905
Remote operation for gas; 8,20m	595613905
Remote operation for gas; 9,00m	595604705
Remote operation for gas; 9,50m	595605005
Remote operation for gas drivers cab; 7,50m	595607605
Series 904 / 905	
Pivoting rod end remote operation for pump, all versions	595607105
Pivoting rod end remote operation for gas, all versions	595608405
Ball joint, all versions	595613005
Rubber gaitor for gas, all versions	726008205
Rubber gaitor for pump, all versions	726008305
Series 904 / 905	
3 position switch	606005805
4 position switch	606006005
Control knob; series until 2011	606005905
Control knob; series starting from 2011	10819623
Push button, green	11163063
Push button, red	11163064
Push button, black	11163065
Contact element	11163066
Stopper plug	11163067
Protective collar	11163068
Reducer ring 30,5mm - 22,5 mm	10114350





Electronic control systems

Descri	ntınn	ID-No

Series 904 / 905	
EMC Control station cpl., outside	10330077
EMC Control station cpl., drivers cab	10330078
"EMC Control station comfort - R (without emergency stop module and control lever)"	10330080
EMC / EDC Emergency stop module	10330081
Control lever for 10330077	10330082
EDC Control station without control lever	11168091
Seal for control lever 10330082	11164046
EMC Key flaps compl.	10330083
EDC Key flaps compl.	11168772
Protective cover for protecting housing EMC 10819438 / EDC 11168152	10819437
Protecting housing EMC	10819438
Protecting housing EDC	11168152
Stainless steel protective housing for EMC cpl. with cover	90411552
Stainless steel protective housing for EDC cpl. with cover	90414924
Series 904	
TME Contol station outside	696053005
TME Contol station drivers cab	696053105





Electronic components and accessories

Description, ID-No.

Series 05	
Working lights / auxiliary reversing lights LED	11166886
Small relay for worklights	630170505
Relay plug-in socket	630161105
Flat fuse holder	604204705
Flat plug fuse 5A	604005505
Pull switch 1S 10A 12/24V DC ON/OFF	10027571



Safety retrofits

According to DIN standard EN ISO 12609 / EU Machinery Directive 2006/42/EC	
Retrofit kit rear view camera incl. monitor all models	13575802
Nachrüstung des Arbeitsscheinwerfer HTM 05 am Podest ohne FFST	13575805
Retrofitting the HTM 05 worklight on the pedestal with FFST	13575807
Retrofitting the HTM 05 worklight on the platform for interchangeable bodies	13575808
Retrofit of HTM 04 worklight with EMC control system	13575811
Retrofitting of the HTM 04 worklight with EDC control system	13575812
Retrofitting of the safety device folding ladder (schraubbaur) series 04	13593662
Retrofitting the safety device extension ladder (schraubbaur) series 04	13593666
Retrofitting the safety device ladder platform (schraubbaur) series 05	13597526
Retrofitting the appearance for underride guard	90416779




Safety and warning stickers

Description, ID-No.

Series 904 / 905	
LIEBHERR lettering adhesive label	970310605
Adhesive sign Danger of shearing off	10114587
Adhesive label drum rotation direction RE	10819492
Adhesive label drum fuse	11166635
Adhesive label sound level	10006577
Adhesive sign protective clothing	12741715
Adhesive sign warning	10818888
Adhesive sign Danger of falling	773194914
Adhesive label red bar (inlet hopper)	10819648
ECE-Reflector tape-red, material sold by the metre	11005399
ECE-Reflector tape-white, material sold by the metre	11005400







ETM - Fully electric

Description, ID-No.

Series - ETM	
On-board charger	12740691
PDU	914007005
Charging inlett (built-in socket)	12740832
Main battery switch	12741799
Bypass valve (3-way)	12741735
Hydraulic unit (chute adjustment, drum cover)	12740422
Rear display	11634293
Display cap	12741729
Fuse holder 32V/200A	12742959
Circulation pump vertical EMP	12741728
Circulation pump	12741731
Magnetic filter	12742394
Membrane	12744247



Oils and lubricants

Liebherr hydraulics 37, 5 liter canister	10664865
Liebherr Hydraulics 37, 20 liter canister	10664867
Liebherr hydraulics 37, 210 liter drum	10664712
Liebherr hydraulics 37, 1000 liters container	10664856
Liebherr special grease CTK, 0.95 kg tube	11167586
Liebherr special grease CTK, 24 x 400gr. ex. Europe	10819780
Liebherr gear oil Hypoid90EP/ SAE 85W-90, 5 liter canister	10664874
Liebherr gear oil Hypoid90EP/ SAE 85W-90, 20 liter drum	10664875
Liebherr gear oil Hypoid90EP/ SAE 85W-90, 210 liter drum	10664876
Liebherr gear oil Hypoid90EP/ SAE 85W-90, 1000 liter tank	10441636







Concrete numps















So that your Liebherr remains a Liebherr.

- Handover and instruction by experienced service technicians.
- Worldwide service network with over 90 support points
- Technical support worldwide
- Fast availability of spare parts
- Professional maintenance and services

Manufacturer Service:

+49 (0) 7583 - 949 -800 • CS.LMT@Liebherr.com www.MyLiebherr.com

Subject to changes

Liebherr-Mischtechnik GmbH · Postfach 145 · D-88423 Bad Schussenried +49 7583 9 49-800 · www.liebherr.com · cs.lmt@liebherr.com

