

Quality, Design and Innovation





# LIEBHERR

Con	tents	-	-)
<b>1</b> 1.1	Appliance at a glance	<b>3</b> 3	
1.2 1.3	Overview of the appliance and equipment	3	ر اX
1.4 1.5	Appliance range of use	/.	
1.6 1.7	SVHC substances according to REACH regulation. EPREL database	4 4	ervice N lodel desc erialit:
1.8	Spare parts		sw.xx sw.xx
2	General safety instructions	~ =	
<b>3</b> 3.1 3.2 3.3	Functionality of the Touch display  Navigation and symbol explanation  Menus  Sleep mode	6 6 6 7	\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\
4	Putting into operation		
4.1	Switching on appliance (first use)	7	(3
<b>5</b> 5.1	Storage	7 7	.3
5.2	Fridge compartment	0 7	'.3 '.3
5.3 5.4	BioFreshFreezer compartment		.3
5.5	Storage times	8 <b>8</b>	3
6	Saving energy	7	3.2 3.2
7	Controls		3.3
7.1	Controls and displays		3.4
7.1.1	Status display		3.5
7.1.2	Display symbols		3.6
7.2 7.2.1	Appliance functions		3.7
	Notes on the appliance functions Switching the appliance off and on	10 8	3.8 3.9 3.1
<u>(</u> ) -18 ℃	Switching temperature zone off and on	. 10 9	
• ))	WiFi	11 9	2.2 2.3
<b>5</b> °c	Temperature	12 9 9	9.4 9.5
°C/F	Temperature unit	12 <b>1</b>	.6 . <b>0</b>
B5	BioFresh B-Value	15 1	0.0
D1	D-Value	13 1	0.0
*	SuperCool		.1
***	SuperFrost	13 1	2.
*\( \)	Start defrosting cycle		-h
ŢŅĬ	PartyMode	14 d	le ve
<u>~</u>	HolidayMode	15	ne Sy
<b>W</b>	SabbathMode		
$\Box$	E-Saver	16	
	CleaningMode	16	

-o	Display brightness	. 16
	Door alarm	17
×lm	Input lock	17
Service No: Model Index:	Device information	. 18
Securit:	Software	.18
Software 5	Reminder	. 18
(S)	Demo mode	.18
<u> </u>	Resetting to factory settings	. 19
7.3	Messages	19
7.3.1	Overview of warnings	
7.3.2	Ending warnings	
7.3.3	Overview of reminders	
7.3.4	Ending reminders	
8	Features	21
8.1	Door rack	21
8.2	Shelves	22
0.2		~~
8.3	Dividing shelf	22
8.3 8.4	Dividing shelf	22
8.3 8.4 8.5	Space for baking tray	22
8.4	Dividing shelf	
8.4 8.5	Space for baking trayAdjustable bottle shelf	22 22
8.4 8.5 8.6 8.7 8.8	Space for baking tray	22 22 23
8.4 8.5 8.6 8.7 8.8 8.9	Space for baking tray	22 22 23 24 25 25
8.4 8.5 8.6 8.7 8.8 8.9 8.10	Space for baking tray	22 23 24 25 25 25
8.4 8.5 8.6 8.7 8.8 8.9	Space for baking tray	22 22 23 24 25 25
8.4 8.5 8.6 8.7 8.8 8.9 8.10	Space for baking tray	22 23 24 25 25 25
8.4 8.5 8.6 8.7 8.8 8.9 8.10 8.11	Space for baking tray	22 23 24 25 25 25 25
8.4 8.5 8.6 8.7 8.8 8.9 8.10 8.11	Space for baking tray	22 23 24 25 25 25 25 25
8.4 8.5 8.6 8.7 8.8 8.9 8.10 8.11 <b>9</b> 9.1 9.2 9.3	Space for baking tray	22 22 23 24 25 25 25 25 26 26 26 26 27
8.4 8.5 8.6 8.7 8.8 8.9 8.10 8.11 <b>9</b> 9.1 9.2 9.3 9.4	Space for baking tray	222 233 244 255 255 256 266 276 277 277
8.4 8.5 8.6 8.7 8.8 8.9 8.10 8.11 <b>9</b> 9.1 9.2 9.3 9.4 9.5	Space for baking tray	222 233 244 255 255 256 266 267 277 277
8.4 8.5 8.6 8.7 8.8 8.9 8.10 8.11 <b>9</b> 9.1 9.2 9.3 9.4	Space for baking tray	222 233 244 255 255 256 266 276 277 277
8.4 8.5 8.6 8.7 8.8 8.9 8.10 8.11 <b>9</b> 9.1 9.2 9.3 9.4 9.5	Space for baking tray	222 233 244 255 255 256 266 267 277 277
8.4 8.5 8.6 8.7 8.8 8.9 8.10 8.11 <b>9</b> 9.1 9.2 9.3 9.4 9.5 9.6 <b>10</b>	Space for baking tray	22 22 23 24 25 25 25 26 26 26 27 27 27 28 28 28
8.4 8.5 8.6 8.7 8.8 8.9 8.10 8.11 <b>9</b> 9.1 9.2 9.3 9.4 9.5 9.6 <b>10</b> 10.1 10.2	Space for baking tray	222 233 244 255 255 256 266 267 277 278 288 288 288 288
8.4 8.5 8.6 8.7 8.8 8.9 8.10 8.11 <b>9</b> 9.1 9.2 9.3 9.4 9.5 9.6 <b>10</b> .1 10.2 10.3	Space for baking tray	222 233 244 255 255 256 266 277 277 288 288 288 299
8.4 8.5 8.6 8.7 8.8 8.9 8.10 8.11 <b>9</b> 9.1 9.2 9.3 9.4 9.5 9.6 <b>10</b> 10.1 10.2 10.3 10.4	Space for baking tray	222 233 244 252 252 262 262 272 272 282 282 282 293 30
8.4 8.5 8.6 8.7 8.8 8.9 8.10 8.11 <b>9</b> 9.1 9.2 9.3 9.4 9.5 9.6 <b>10</b> 10.2 10.3 10.4 10.5	Space for baking tray	222 232 242 252 252 252 252 262 262 272 272 282 282 282 293 303
8.4 8.5 8.6 8.7 8.8 8.9 8.10 8.11 <b>9</b> 9.1 9.2 9.3 9.4 9.5 9.6 <b>10</b> 10.1 10.2 10.3 10.4 10.5 <b>11</b>	Space for baking tray	22223 24425 2525 2525 2626 2626 2727 2728 2828 2829 300 300 300
8.4 8.5 8.6 8.7 8.8 8.9 8.10 8.11 9 9.1 9.2 9.3 9.4 9.5 9.6 10.1 10.2 10.3 10.4 10.5 11	Space for baking tray	22223 24425 2525 2525 2626 2626 2727 2828 2829 300 300 31
8.4 8.5 8.6 8.7 8.8 8.9 8.10 8.11 <b>9</b> 9.1 9.2 9.3 9.4 9.5 9.6 <b>10</b> 10.1 10.2 10.3 10.4 10.5 <b>11</b>	Space for baking tray	22223 24425 2525 2525 2626 2626 2727 2728 2828 2829 300 300 300

The manufacturer is continually working on the further development of all types and models. Please be aware that we reserve the right to make changes to the shape, equipment and technology.

Symbol	Explanation
	Read instructions
	Please read the information in these instructions carefully to understand all of the benefits of your new appliance.

#### Symbol

#### Explanation



#### Additional information on the Internet

The digital manual with additional information and in other languages can be found via the QR code on the front of the manual or by entering the service number at home.liebherr.com/fridge-manuals.

The service number can be found on the serial




Fig. Example illustration



#### Check appliance

Check all parts for transport damage. If you have any complaints, please contact your agent or customer service.



#### **Differences**

These instructions apply to a range of models, so differences are possible. Sections that apply to certain models only are marked with an asterisk (\*).



#### Instructions and results

Instructions are marked with a >. Results are marked with a  $\triangleright$ .



#### Videos

Videos about the appliances are available on the YouTube channels of Liebherr-Hausgeräte.

#### Open source licences:

The appliance contains software components that use open source licences. Information on the open source licences used can be found here: home.liebherr.com/ open-source-licences

These operating instructions apply to:

ICBN(S).. 56..

#### Note

If your appliance has an N in its appliance designation, it is a NoFrost appliance.

# 1 Appliance at a glance

# 1.1 Scope of delivery

Check all parts for transport damage. Contact your dealer or customer service in the event of complaints. (see 10.4 Customer Service)

Your new appliance comes with the following parts:

- Built-in appliance
- Features (depending on the model)
- Installation materials (depending on the model)
- "Quick Start Guide"
- "Installation Guide"
- Service Brochure

# 1.2 Overview of the appliance and equipment




Fig. 1 Example illustration

# Temperature range

- (A) Fridge section
- (B) BioFresh
- (C) Freezer section (D) Coldest area

#### Equipment

- (1) Controls
- (9) Drain opening
- (2) Fan with FreshAir activated charcoal filter
- (10) Meat & Dairy-Safe
- (3) Divisible shelf

table-Safe

- (11) Freezer drawer
- (4) Shelf
- (12) VarioSpace
- (5) Variable bottle rack
- (13) Type plate
- (6) Space for baking tray (7) Lid for Fruit & Vege-
- (14) Door racks (15) Bottle holder
- (8) Fruit & Vegetable-Safe

# 1.3 SmartDevice

SmartDevice is the networking solution for your fridgefreezer.

If your appliance SmartDevice-enabled or compatible, you can quickly and easily connect your appliance to your WiFi. With the SmartDevice app, you can operate your appliance from a mobile device. Additional functions and setting options are available in the SmartDevice SmartDevice app.

SmartDeviceance:

Your appliance is compatible for use compatible appli- with the SmartDeviceBox. You must first purchase and install the Smart-DeviceBox. In order to connect your appliance to the WiFi, you need to download the SmartDevice app.

# **General safety instructions**



about SmartDe-

information smartdevice.liebherr.com

vice:

Purchasing SmartDeviceBox in the Liebherr-

the home.liebherr.com/shop/de/deu/ smartdevicebox.html

Hausgeräte store: Downloading SmartDevice app:



After installing and configuring the SmartDevice, you can connect your appliance to the WiFi using the SmartDevice app and the WiFi appliance function (see WiFi).

#### Note

The SmartDevice function is not available in the following countries: Russia, Belarus, Kazakhstan.

You cannot use the SmartDeviceBox.

# 1.4 Appliance range of use

#### Intended use

The appliance is only suitable for cooling food products in a domestic or household-like environment. This includes, for example, use:

- in staff kitchens, bed and breakfast establishments,
- by guests in country houses, hotels, motels and other accommodation.
- for catering and similar services in the wholesale trade.

All other types of use are not permitted.

### Foreseeable misuse

The following applications are expressly forbidden:

- Storing and refrigerating medicines, blood plasma, laboratory preparations or similar substances and products based on the Medical Device Directive 2007/47/EC
- Use in areas at risk of explosions

Misusing the appliance may lead to damage to the goods stored or they may spoil.

## Climate classifications

Depending on the climate classification the appliance is designed to operate in restricted ambient temperatures. The climate classification applying to your appliance is printed on the rating plate.

#### Note

► Keep to the specified ambient temperatures in order to guarantee that the appliance works properly.

Climate classification	for ambient temperatures of	
SN	10 °C to 32 °C	
N	16 °C to 32 °C	
ST	16 °C to 38 °C	
Т	16 °C to 43 °C	
SN-ST	10 °C to 38 °C	
SN-T	10 °C to 43 °C	

# 1.5 Conformity

The refrigerant circuit has been tested for leaks. When installed, the appliance complies with the applicable safety regulations and with the corresponding directives.

The full text of the EU Declaration of Conformity is available on the following website: www.Liebherr.com

The BioFresh compartment meets the requirements of a cold storage compartment as set out in DIN EN 62552:2020.

# 1.6 SVHC substances according to **REACH regulation**

You can check whether your appliance contains SVHC substances according to REACH regulation at the following link: home.liebherr.com/de/deu/de/liebherr-erleben/nachhaltigkeit/umwelt/scip/scip.html

# 1.7 EPREL database

Details about energy labelling and ecodesign requirements will be available on the European product database (EPREL) from 1st March 2021. You can access the product database at the following link: https://eprel.ec.europa.eu/ You will be asked to enter the model ID. You can find the model ID on the nameplate.

# 1.8 Spare parts

The spare parts availability for functional parts and stockable parts of the equipment is 15 years.

# 2 General safety instructions

Please keep these operating instructions in a safe place so you can refer back to them at any time.

If you pass the appliance on, please hand these operating instructions to the next user.

Read these operating instructions carefully before use to ensure safe and correct use of the appliance. Follow the instructions, safety instructions and warning messages included at all times. They are important for ensuring you can operate and install the appliance safely and without any problems.

# Danger for the user:

- This device can be used by children and people with impaired physical, sensory or mental abilities or with a lack of experience and knowledge provided that they are supervised or have received instruction in the safe use of this device, and about the resulting hazards.
  - Children must not play with this appliance. Cleaning and user maintenance work must not be carried out by children without adult supervision. Children aged between 3 and 8 are allowed to load and unload the appliance. Children below the age of 3 must be kept away from the appliance unless they are under continuous adult supervision.
- The socket must be easily accessible so that the appliance can be disconnected quickly from the electricity in an emergency. It must not be located in the area behind the appliance.
- When disconnecting the appliance from the supply, always take hold of the plug. Do not pull the cable.
- In the event of a fault pull out the mains plug or deactivate the fuse.
- Do not damage the mains power cable. Do not operate the appliance with a defective mains power cable.
- Only customer service or other specially trained staff may repair or perform other operations on the appliance.
- Only install, connect and dispose of the appliance according to the instructions.
- Only use the appliance when is installed.

#### Fire hazard:

- The coolant used (information on the model plate) is ecofriendly but also flammable.
   Any leaking coolant may ignite.
  - Do not damage the refrigerant circuit pipes.
  - Do not handle ignition sources inside the appliance.
  - Do not use electrical appliances inside the appliance (e.g. steam cleaners, heaters, ice cream makers, etc.).
  - If the refrigerant leaks: remove any naked flames or ignition sources from the vicinity of the leakage point. Properly air the room. Inform customer services.
- Do not store explosives or sprays using combustible propellants such as butane, propane, pentane, etc. in the appliance. To identify these spray cans, look for the list of contents printed on the can, or a flame

- symbol. Gases possibly escaping may ignite due to electrical components.
- Keep burning candles, lamps and other items with naked flames away from the appliance so that they do not set the appliance on fire.
- Please be sure to store alcoholic drinks or other packaging containing alcohol in tightly closed containers. Any alcohol that leaks out may be ignited by electrical components.

# Danger of tipping and falling:

 Do not misuse the plinth, drawers, doors etc. as a step or for support. This applies particularly to children.

# Danger of food poisoning:

- Do not consume food which has been stored too long.

# Danger of frostbite, numbness and pain:

 Avoid prolonged skin contact with cold surfaces or refrigerated/frozen goods or take protective measures, e.g wear gloves.

# Danger of injury and damage:

- Hot steam can lead to injury. Do not use electrical heating or steam cleaning equipment, open flames or defrosting sprays to defrost.
- Do not use sharp implements to remove the ice.

## Risk of crushing:

- Do not hold the hinge when opening and closing the door. Fingers may get caught.

## Symbols on the appliance:



This symbol may be located on the compressor. It relates to the oil in the compressor and makes reference to the risk that: Swallowing or inhaling can be fatal. This advice is only relevant to recycling. There is no danger in normal operation



This symbol is located on the compressor and indicates the danger of flammable materials. Do not remove the sticker.



This or a similar sticker may be located on the rear of the appliance. This sticker indicates that there are vacuum insulation panels (VIP) or perlite panels in the door and/or housing. This advice is only relevant to recycling. Do not remove the sticker.

Please note the warning messages and other specific advice in the other chapters:

# Functionality of the Touch display

À	DANGER	indicates an immediately hazardous situation which will lead to death or serious injuries if it is not avoided.
À	WARNING	indicates a hazardous situation which may lead to death or serious injuries if it is not avoided.
<u> </u>	CAUTION	indicates a hazardous situation which may lead to minor or moderate injuries if it is not avoided.
	NOTICE	indicates a hazardous situation which may lead to damage to property if it is not avoided.
	Note	indicates useful instructions and tips.

# 3 Functionality of the Touch display

You operate your appliance using the Touch display. You select appliance functions in the Touch display (hereafter referred to as display) by tapping them. If you do not perform any action on the display for 10 seconds, the display either jumps back to the higher-level menu or directly to the status display.

# 3.1 Navigation and symbol explanation

In the illustrations, different symbols are used to navigate the display. The following table describes these symbols.

Symbol	Description
	Press the Next navigation arrow:  Navigates to the next option in the menu.
	Press the Back navigation arrow:  Jumps back one option in the menu.
	Press the navigation arrow several times in succession: Navigates in the menu to the desired function.
	Press the Confirm symbol: Activates/deactivates function. Opens submenu.
Back S	Press the Confirm symbol together with the back icon: Jumps back one menu level.
<b>→</b> ⊗	Arrow with clock: It takes more than 10 seconds for the following message to appear in the display.

Symbol	Description	
2s 5s 10s	Arrow with a time indication: It takes the specified amount of time until the following message appears in the display.	
	"Open Settings menu" symbol:	
<u>={Ö}</u>	Navigates to the Settings menu and opens the settings menu.	
	If necessary: Navigate to the desired function in the Settings menu.	
	(see 3.2.1 Opening the Settings menu)	
	"Open Advanced menu" symbol:	
	Navigates to the Advanced menu and opens the advanced menu.	
	If necessary: Navigate to the desired function in the Advanced menu.	
	(see 3.2.2 Opening the Advanced menu)	
No action for 10 seconds	If you do not perform any action on the display for 10 seconds, the display either jumps back to the higher-level menu or directly to the status display.	
Opening door and closing it again	If you open the door and immediately close it again, the display jumps directly back to the status display.	

Note: Illustrations of the display are shown in the English version.

# 3.2 Menus

The appliance functions can be found in various menus.

Menu	Description		
Main menu	When you switch the appliance on, you are automatically in the main menu.		
	From here you can navigate to the most important appliance functions, to the Settings menu and to the Advanced menu.		
Settings	The Settings menu contains additional appliance functions for setting up your appliance. (see 3.2.1 Opening the Settings menu)		
Settings menu			
Advanced menu	The advanced menu contains special appliance functions for setting up your appliance. Access to the Advanced menu is protected by the numerical code <b>1 5 1</b> . (see 3.2.2 Opening the Advanced menu)		

## 3.2.1 Opening the Settings menu




Fig. 2 Example illustration

- ► Carry out action steps according to the illustration.
- Settings menu is open.
- ▶ If necessary: Navigate to the desired function.

#### 3.2.2 Opening the Advanced menu




Fig. 3




Fig. 4 Example illustration, access with numerical code **151** 

- Carry out action steps according to the illustration.
- ▶ The expanded menu is open.
- ▶ If necessary: Navigate to the desired function.

# 3.3 Sleep mode

If you do not touch the display for 1 minute, the display switches to sleep mode. In sleep mode, the display brightness is dimmed.

### 3.3.1 Ending sleep mode

- Press any navigation key.
- ▶ Sleep mode is ended.

# 4 Putting into operation

# 4.1 Switching on appliance (first use)

Make sure that the following requirements are fulfilled:

- The appliance is properly installed and connected according to the installation instructions.
- All adhesive strips, adhesive and protective films and transport locks are removed from inside and on the appliance.
- ☐ All marketing leaflets are removed from the drawers.
- You are familiar with the functionality of the Touch display. (see 3 Functionality of the Touch display)

#### Switch on the appliance using the Touch display:

- ► If the display is in sleep mode: Press the confirmation symbol.
- ► Carry out action steps according to the illustration.




Fig. 5 Example illustration

- > Status display appears.
- ▶ The appliance cools to the temperature set at the factory.
- ➤ The appliance starts in demo mode (status display with DEMO appears): If the appliance starts in demo mode, you can deactivate demo mode within the next 5 minutes. (see Demo mode)

#### More information:

 Start the SmartDevice for the first time. (see 1.3 Smart-Device) and (see WiFi)

#### Note

The manufacturer recommends:

- Stock with food: Wait for around 6 hours until the set temperature is reached.
- ▶ Store frozen foods at -18 °C or colder.
- Observe the notes on storing food. (see 5.1 Information regarding storage)

#### Note

Accessories can be purchased from the Liebherr-Hausgeräte store at home.liebherr.com/shop/de/deu/zubehor.html.

# 5 Storage

# 5.1 Information regarding storage



# WARNING

Risk of fire

Do not use any electrical appliances in the food area of the appliance unless recommended by the manufacturer.

#### Note

The energy consumption increases and the cooling power goes down if ventilation is not sufficient.

Always keep air slots clear.

Observe the following specifications for storage:

- Keep the air vents on the fan free.
- In the freezer compartment: Package food properly.
- Package or cover foods that readily take on or give off odours or taste in closed containers.
- Package raw meat or fish in clean, closed containers.
   This will prevent meat or fish from touching or dripping onto other food.
- Keep liquids in closed containers.
- Leave space between goods to ensure good air circulation.
- Store food according to the instructions on the packaging.
- Always observe the best-before date indicated on the packaging.

#### Note

Failure to follow these guidelines can lead to foodstuffs spoiling.

# 5.2 Fridge compartment

The air circulation in the appliance creates different temperature zones. You will find the different temperature zones in the appliance and equipment overview. (see 1.2 Overview of the appliance and equipment)

# 5.2.1 Arranging your food properly

- ▶ Upper area and door: Store butter, cheese, tinned food and tubes.
- Coldest temperature zone: Store perishable foods such as pre-cooked meals.

# 5.3 BioFresh

BioFresh will extend the storage time for some fresh foods compared to traditional refrigeration.

#### Note

If the temperature drops below 0 °C foods may freeze.

▶ Store cold-sensitive produce such as cucumbers, aubergines, courgettes and tropical fruit in the fridge compart-

# 5.3.1 Fruit & Vegetable safe 🔘 🥖





This safe creates a storage climate of close to 0 °C. The compartment lid ensures constant levels of humidity. This storage climate is suitable for storing unpackaged food with high intrinsic moisture (for example, lettuce, vegetables,

The humidity in the compartment depends on the moisture content of the chilled goods placed in it, and also depends on how often the compartment is opened. You can regulate the humidity level.

#### Arranging your food properly

- ► Store unpackaged fruit and vegetables. If the humidity is too high:
- Regulate the humidity.

# 5.3.2 Meat & Dairy safe 🕮 🔎 💠





This safe creates a storage climate of close to 0 °C. This storage climate is suitable for more sensitive foods (e.g. dairy products, meat, fish, sausage).

#### Arranging your food properly

► Store dry or packaged food.

# 5.4 Freezer compartment

Here, a dry, frosty storage climate is created at -18 °C. The frosty storage climate is suitable for storing frozen food for several months, for making ice cubes or freezing fresh food.

### 5.4.1 Freezing food

### Freezing quantity

The maximum amount of fresh food that you can freeze within 24 hours is specified on the type plate (see 10.5 Model plate) under "Freezing capacity ... kg/24h".

To ensure that food quickly freezes through, adhere to the following quantities per package:

- Fruit and vegetables up to 1 kg
- Meat up to 2.5 kg

#### Freezing food using SuperFrost

Depending on the quantity to be frozen, you can activate SuperFrost before freezing in order to achieve lower freezing temperatures. (see SuperFrost)

► Activate SuperFrost if the amount of food you have to freeze is more than approx. 2 kg.

The time at which you activate SuperFrost depends on the amount of food you have to freeze:

Freezing quan- tity	Time at which you should activate SuperFrost		
Small amount of food to freeze	Activate SuperFrost about 6 hours before freezing.		
	You can place the food in the freezer as soon as the appliance automatically deactivates SuperFrost.		
Maximum amount of food	Activate SuperFrost about 24 hours before freezing.		
to freeze	You can place the food in the freezer as soon as the appliance automatically deactivates SuperFrost.		

#### Arranging your food properly



## CAUTION

Risk of injury from broken glass!

Bottles and cans with beverages can burst during freezing. This applies in particular to carbonated beverages.

Only freeze bottles and cans with beverages if you have activated the BottleTimer function in the SmartDevice app.

Freezing quantity	Arranging your food properly		
Small amount of food to freeze	Distribute packaged groceries throughout all drawers.		
	If possible, place groceries at the back of the drawer near the rear wall.		
Maximum amount of food to freeze	Distribute packaged groceries throughout all drawers.		
	If possible, place groceries at the back of the drawer near the rear wall.		

#### 5.4.2 Defrosting food



#### WARNING

Risk of food poisoning!

- ▶ Do not re-freeze thawed food.
- Use defrosted foodstuff as soon as possible.

You can defrost food in several ways:

- In the fridge compartment
- In the microwave
- In the oven/fan-assisted oven
- At room temperature
- ► Take out only as much food as necessary.

# 5.5 Storage times

Refer to the specified storage times as a guide.

In the case of foods with a minimum shelf life, the date indicated on the packaging still applies.

## 5.5.1 Fridge section

Always follow the best-before date stated on the packaging.

#### 5.5.2 BioFresh

Recommended storage periods in the Meat & Dairy-Safe			
Butter	at 1 °C	up to 90 days	
Hard cheese	at 1 °C	up to 110 days	
Milk	at 1 °C	up to 12 days	
Sausage, cold meats	at 1 °C	up to 8 days	
Poultry	at 1 °C	up to 6 days	
Pork	at 1 °C	up to 6 days	
Beef	at 1 °C	up to 6 days	
Game	at 1 °C	up to 6 days	

#### Note

► Remember that high-protein foods perish quicker; shell-fish and crustaceans do not last as long as fish, and fish does not last as long as meat.

Recommended storage periods in the Fruit & Vegetable- Safe			
Vegetables, salads			
Artichokes	at 1 °C	up to 14 days	
Celery	at 1 °C	up to 28 days	
Cauliflower	at 1 °C	up to 21 days	
Broccoli	at 1 °C	up to 13 days	
Chicory	at 1 °C	up to 27 days	
Lettuce	at 1 °C	up to 19 days	
Peas	at 1 °C	up to 14 days	
Kale	at 1 °C	up to 14 days	
Carrots	at 1 °C	up to 80 days	
Garlic	at 1 °C	up to 160 days	
Turnip	at 1 °C	up to 14 days	
Lettuce	at 1 °C	up to 13 days	
Herbs	at 1 °C	up to 13 days	
Leeks	at 1 °C	up to 29 days	
Mushrooms	at 1 °C	up to 7 days	
Radishes	at 1 °C	up to 10 days	
Brussels sprouts	at 1 °C	up to 20 days	
Asparagus	at 1 °C	up to 18 days	
Spinach	at 1 °C	up to 13 days	
Savoy	at 1 °C	up to 20 days	
Fruit			
Apricots	at 1 °C	up to 13 days	
Apples	at 1 °C	up to 80 days	
Pears	at 1 °C	up to 55 days	
Blackberries	at 1 °C	up to 3 days	
Dates	at 1 °C	up to 180 days	
Strawberries	at 1 °C	up to 7 days	
Figs	at 1 °C	up to 7 days	
Blueberries	at 1 °C	up to 9 days	

Recommended storage periods in the Fruit & Vegetable- Safe		
Raspberries	at 1 °C	up to 3 days
Currants	at 1 °C	up to 7 days
Sweet cherries	at 1 °C	up to 14 days
Kiwis	at 1 °C	up to 80 days
Peaches	at 1 °C	up to 13 days
Plums	at 1 °C	up to 20 days
Cranberries	at 1 °C	up to 60 days
Rhubarb	at 1 °C	up to 13 days
Gooseberries	at 1 °C	up to 13 days
Grapes	at 1 °C	up to 29 days

## 5.5.3 Freezer compartment

Recommended storage period for various types of food		
Ice cream	at -18 °C	2 to 6 months
Sausages, ham	at -18 °C	2 to 3 months
Bread, baked goods	at -18 °C	2 to 6 months
Game, pork	at -18 °C	6 to 9 months
Fatty fish	at -18 °C	2 to 6 months
Lean fish	at -18 °C	6 to 8 months
Cheese	at -18 °C	2 to 6 months
Poultry, beef	at -18 °C	6 to 12 months
Vegetables, fruit	at -18 °C	6 to 12 months

# 6 Saving energy

- Pay attention to good ventilation. Do not cover ventilation holes or grids.
- Always keep the fan air slits clear.
- Do not install the appliance in direct sunlight or near radiators or similar sources of heat.
- If the appliance is installed directly next to an oven, the energy consumption may increase slightly. This is dependent on the service life and usage intensity of the
- Energy consumption depends on the installation conditions, e.g. the ambient temperature (see 1.4 Appliance range of use). A warmer ambient temperature can increase the energy consumption.
- Open the appliance for as short a time as possible.
- The lower the temperature is set the higher the energy consumption.
- Sort your food: home.liebherr.com/food.
- Keep all food properly packed and covered. This prevents frost from forming.
- Only take food out for as long as necessary so that it doesn't warm up too much.
- Inserting warm food: allow to cool down to room temperature first.
- Thaw frozen food in the refrigerator.
- For longer periods of absence, use HolidayMode (see HolidayMode) .

# 7 Controls

# 7.1 Controls and displays

# 7.1.1 Status display




Fig. 6

- (1) Temperature display of the fridge section
- (2) Freezer compartment temperature display

The Status display shows the set temperature and is the home display. From there, you can navigate to the options and settings.

# 7.1.2 Display symbols

Display symbols provide information on the current appliance status:

Symbol	Appliance status
$\bigcirc$	<b>Standby</b> The appliance or temperature zone is switched off.
-\frac{1}{5}\sqrt{0}	Flashing number Appliance is working. Temperature flashes until the set value is reached.
-5-	<b>Flashing symbol</b> Appliance is working. Setting is made.
	Bar grows steadily Function is activated.

# 7.2 Appliance functions

# 7.2.1 Notes on the appliance functions

The appliance functions are set at the factory so that your appliance is fully functional.

Before you alter, activate or deactivate the device functions, make sure that the following requirements are met:

- You have read and understood the descriptions of how the display works. (see 3 Functionality of the Touch display)
- You have familiarised yourself with the operating and display elements of your appliance.



# Switching the appliance off and on

Use this function to switch the entire appliance off and on.

#### Switching off the appliance

When you switch the appliance off, then the previously saved settings are saved.

Make sure that the following requirements are fulfilled:

☐ Handling instructions (see 11 Shutting down) are carried out.



Fig. 7




Fig. 8

- ► Carry out action steps according to the illustration.
- ▶ Appliance is switched off.
- ▶ The standby symbol appears in the display.
- Display turns black.

#### Switching on the appliance

If the display is in sleep mode:

Press any navigation key.




Fig. 9 Example illustration

- ► Carry out action steps according to the illustration. When the appliance starts in demo mode:
- ▶ Deactivating demo mode. (see Deactivating demo mode)
- ▶ The appliance is switched on.
- ▶ Previous settings are restored.
- ▶ The appliance cools to the target temperature set.

#### <u>(</u>) -18 ℃

# -18 Switching temperature zone off and on

You can switch temperature zones of the appliance off independently.

#### Application:

- Cleaning
- Defrosting

#### Switching the fridge compartment off

Make sure that the following requirements are fulfilled:

☐ Refrigerator compartment has been emptied.




Fig. 10 Example illustration

- ► Carry out action steps according to the illustration.
- ▶ Refrigerator compartment is switched off.

#### Switching the fridge compartment on




Fig. 11 Example illustration

- ► Carry out action steps according to the illustration.
- ▶ Refrigerator compartment is switched on.
- ▶ The appliance cools to the last set temperature.



Use this function to connect your appliance to WiFi. You can then operate it via the SmartDevice app on a mobile device. You can also use this function to disconnect or reset the WiFi connection.

To connect your device to WiFi, you need the SmartDeviceBox.

More information on the SmartDevice: (see 1.3 SmartDevice)

#### Note

The SmartDevice function is not available in the following countries: Russia, Belarus, Kazakhstan.

You cannot use the SmartDeviceBox.

#### Establishing the WiFi connection for the first time

Make sure that the following requirements are fulfilled:

- ☐ You have purchased and inserted a SmartDeviceBox. (see 1.3 SmartDevice)
- You have installed the SmartDevice app (see apps.home.liebherr.com).
- ☐ Registration in the SmartDevice app is completed.



Fig. 12




Fig. 13

- ► Carry out action steps according to the illustration.
- ▶ Connection is established.

#### Disconnecting from the WiFi



Fig. 14




Fig. 15

- Carry out action steps according to the illustration.
- ▶ There is no connection.

#### Resetting the WiFi connection



Fig. 16




Fig. 17

- ► Carry out action steps according to the illustration.
- WiFi connection and other WiFi settings are reset to factory settings.

#### Showing information about the WiFi connection



Fig. 18




Fig. 19

► Carry out action steps according to the illustration.

# 5 ° Temperature

Use this function to set the temperature.

The temperature depends on the following factors:

- Frequency of door opening
- Duration of door opening
- Room temperature of the installation site
- Type, temperature and quantity of food

Temperature zone	Factory-set temperature	Recommended setting
5 · Fridge section	5 °C	4 °C
-18℃ Freezer section	-18 °C	-18 °C
0 ° BioFresh	0 °C	B-Value (see BioFresh B- Value)

#### Setting the temperature in the fridge section




Fig. 20 Example illustration

- ► Carry out action steps according to the illustration.
- ▶ Temperature is set.

#### Setting the temperature in the freezer section




Fig. 21 Example illustration

- ► Carry out action steps according to the illustration.
- ▶ Temperature is set.

## Setting the temperature in BioFresh

Set the temperature using the **BioFresh B-Value**. (see BioFresh B-Value)

# Temperature unit

Use this function to set the temperature unit. You can set degrees Celsius or degrees Fahrenheit as the temperature unit.

## Setting the temperature unit



Fig. 22




Fig. 23 Example illustration: Switch from degrees Celsius to degrees Fahrenheit.

- ► Carry out action steps according to the illustration.
- ▶ The temperature unit is set.



### BioFresh B-Value

Use this function to set the BioFresh B-Value. With the BioFresh B-Value, you can set BioFresh slightly warmer or colder if necessary due to higher or lower ambient temperatures. The BioFresh B-Value is pre-set to value B5 as delivered. If you change the B-Value, refer to the following table:

Value	Description
B1	Lowest temperature
B1-B4	The temperature can drop below 0 °C which means foods can easily freeze.
B5	Pre-set temperature
В9	Highest temperature

#### Setting the BioFresh B-Value



Fig. 24




Fig. 25 Example illustration: Switch from B5 to B6.

- Carry out action steps according to the illustration.
- The BioFresh B-Value is set.



The D-Value is pre-set for your appliance and is not permitted to be changed.



# SuperCool

You can use this function to activate or deactivate Super-Cool. If SuperCool is activated, then the appliance increases the cooling capacity. It allows you to achieve lower cooling temperatures. You can activate SuperCool when you would like to cool a large quantity of food quickly.

If the function is active, the appliance operates at higher power. As a result, the appliance's operating noise may be temporarily louder and energy consumption will increase.

# Activating SuperCool

Time for activation of the function:

When you would like to store fresh food in the fridge section: Activate the function when inserting food.



Fig. 26




Fig. 27

- ► Carry out action steps according to the illustration.
- ➤ SuperCool is activated.

#### **Deactivating SuperCool**

SuperCool is deactivated automatically after 18 hours. However, you can also deactivate SuperCool manually at any time:




Fig. 28




Fig. 29

- Carry out action steps according to the illustration.
- ➤ SuperCool is deactivated.
- The appliance continues to run in normal mode.
- The appliance cools to the temperature set previously.



# **SuperFrost**

You can use this function to activate or deactivate SuperFrost. If SuperFrost is activated, then the appliance increases the freezing capacity. It allows you to achieve lower freezing temperatures.

#### Application:

- Quickly freeze fresh food through to the core. This ensures that the nutrition, appearance and taste of frozen food is maintained.
- Increase the cold reserve in stored frozen food before defrosting the appliance.

If the function is active, the appliance operates at higher power. As a result, the appliance's operating noise may be temporarily louder and energy consumption will increase.

## Activating SuperFrost

Make sure that the following requirements are fulfilled:

■ Freezing quantity and time for activation of SuperFrost are taken into account. (see Freezing food using SuperFrost)



Fig. 30

# **Controls**




Fig. 31

- ► Carry out action steps according to the illustration.
- ➤ SuperFrost is activated.

#### **Deactivating SuperFrost**

SuperFrost is automatically deactivated after 56 to 72 hours depending on the quantity of the food inserted. However, you can also deactivate SuperFrost manually at any time:




Fig. 32



Fig. 33

- ► Carry out action steps according to the illustration.
- ➤ SuperFrost is deactivated.
- ▶ The appliance continues to run in normal mode.
- ▶ The appliance cools to the temperature set previously.



# Start defrosting cycle

Use this function to start the automatic defrosting cycle manually if it does not start automatically in the event of a fault.

### Starting defrosting cycle



Fig. 34




Fig. 35

- ► Carry out action steps according to the illustration.
- Defrosting cycle has started: Icon flashes until defrosting cycle is automatically completed.
- ▶ When defrosting cycle is finished: The device continues to run in normal mode.

#### Cancelling defrosting cycle

The defrosting cycle will be stopped automatically. However, you can also cancel the defrosting cycle at any time during the defrosting process:




Fig. 36

- ► Carry out action steps according to the illustration.
- ▶ Defrosting cycle is cancelled.
- ▶ The device continues to run in normal mode.



# **PartyMode**

You can use this function to activate or deactivate Party-Mode. PartyMode activates various functions that are useful for a party.

PartyMode activates the following functions:

- SuperCool (see SuperCool)
- SuperFrost (see SuperFrost)

You can adjust all listed functions individually and flexibly. When you deactivate PartyMode, all changes are discarded.

If the function is active, the device operates at higher power. As a result, the device's operating noise may be temporarily louder and energy consumption will increase.

# **Activating PartyMode**



Fig. 37




Fig. 38

- ► Carry out action steps according to the illustration.
- ▶ PartyMode and the associated functions are activated.
- ▶ The current temperature flashes until the target temperature is reached.

#### **Deactivating PartyMode**

The PartyMode is automatically deactivated after 24 seconds. However, you can also deactivate PartyMode manually at any time:



Fig. 39




Fig. 40

- Carry out action steps according to the illustration.
- ▶ PartyMode is deactivated.

▶ The appliance cools to the temperature set previously: The current temperature flashes until the target temperature is reached.



# HolidayMode

You can use this function to activate or deactivate Holiday-Mode. If you activate Holiday-Mode, the fridge section is set to 15 °C. This saves you energy during longer periods of absence and prevents bad odours and growth of mould.

#### Appliance status when HolidayMode is active

Fridge section cools to 15 °C.

BioFresh cools to 15 °C.

The set temperature is maintained in the freezer section.

PartyMode is deactivated.

SuperCool is deactivated.

#### Activating HolidayMode

- ► Empty the fridge section completely.
- ► Empty BioFresh completely.




Fig. 41



Fig. 42

- ► Carry out action steps according to the illustration.
- ▶ HolidayMode is activated.
- > Temperature display shows HolidayMode symbol.

#### **Deactivating HolidayMode**




Fig. 43



Fig. 44

- ► Carry out action steps according to the illustration.
- ▶ HolidayMode is deactivated.
- ▶ The appliance cools to the temperature set previously.



# SabbathMode

You can use this function to activate or deactivate SabbathMode. If you activate this function, some electronic functions are switched off. As a result, your device meets the religious requirements for Jewish holidays such as Sabbath and complies with STAR-K Kosher certification.

#### Device status when SabbathMode is active

The status display shows SabbathMode permanently.

All functions on the display are locked except for the **Deactivate SabbathMode function**.

Active functions remain active.

The display remains bright when you close the door.

The interior lighting is deactivated.

Reminders are not implemented. The set time interval stops.

Reminders and warnings are not displayed.

There is no door alarm.

There is no temperature alarm.

The defrosting cycle operates only for the specified time, without considering the appliance consumption.

After a power failure, the appliance returns to SabbathMode.

Device status

#### Note

This appliance has certification from the "Institute for Science and Halacha". (www.machonhalacha.co.il)

You can find a list of STAR-K-certified appliances at www.star-k.org/appliances.

#### **Activating SabbathMode**



#### WARNING

Danger of food poisoning from spoiled food!

If you have SabbathMode activated and a power failure occurs, no message appears in the status display about the power failure. Once the power is restored, the appliance continues to operate in SabbathMode. The power failure may mean that food spoils and the consumption of this food could lead to food poisoning.

After a power failure:

▶ Do not consume food that was frozen and has thawed out.



Fig. 45



Fig. 46

- Carry out action steps according to the illustration.
- ➤ SabbathMode is activated.
- > The status display shows SabbathMode permanently.

# Controls

#### **Deactivating SabbathMode**

The SabbathMode is automatically deactivated after 80 hours. However, you can also deactivate SabbathMode manually at any time:




Fig. 47

- ► Carry out action steps according to the illustration.
- ➤ SabbathMode is deactivated.



#### E-Saver

You can use this function to activate or deactivate Energy saving mode. If energy saving mode is activated, the energy consumption decreases and the temperature in the device increases. The food remains fresh, but the shelf life is shortened.

Temperature zone	Recommended setting (see Setting the temperature in the fridge section)	Temperature with active E- Saver
5 · Fridge section	4 °C	7 °C
-18° Freezer section	-18 °C	-16 °C

Temperatures

#### **Activating E-Saver**




Fig. 48



Fig. 49

- ► Carry out action steps according to the illustration.
- ▶ Energy saving mode is activated.

#### **Deactivating E-Saver**



Fig. 50



#### Fig. 51

- ► Carry out action steps according to the illustration.
- ▶ Energy saving mode is deactivated.



# CleaningMode

You can use this function to activate or deactivate Cleaning-Mode. CleaningMode enables the appliance to be cleaned conveniently.

This setting applies to the fridge section.

#### Application:

- Clean the fridge section. (see 9.6 Cleaning the appliance)

#### Device status when CleaningMode is active

The status display shows CleaningMode permanently.

The fridge section is switched off.

Interior lighting is activated.

The reminders and warnings are not displayed. No signal tone sounds.

Device status

#### **Activating Cleaning Mode**



Fig. 52




Fig. 53

- ► Carry out action steps according to the illustration.
- ▶ CleaningMode is activated.
- ▶ The status display shows CleaningMode permanently.

#### **Deactivating Cleaning Mode**

CleaningMode is deactivated automatically after 60 minutes. However, you can also deactivate Cleaning-Mode manually at any time:



Fig. 54

- ► Carry out action steps according to the illustration.
- CleaningMode is deactivated.
- ▶ The appliance cools to the temperature set previously.



## Display brightness

Use this function to set the display brightness in stages.

You can select the following brightness levels:

- 40 %
- 60 %
- 80 %
- 100 % (pre-setting)

#### Setting the brightness



Fig. 55




Fig. 56 Example illustration: Switch from 80 % to 60 %.

- Carry out action steps according to the illustration.
- ▶ The brightness is set.



## Door alarm

Use this function to activate or deactivate the door alarm. The door alarm sounds if the door is open for too long. The door alarm is activated on delivery. You can set how long the door may be open before the door alarm sounds.

The following values can be set:

- 1 minute
- 2 minutes
- 3 minutes
- Off

#### Setting the door alarm



Fig. 57




Fig. 58 Example illustration: Change door alarm from 1 minute to 3 minutes.

- ► Carry out action steps according to the illustration.
- ▶ The door alarm is set.

## Deactivating the door alarm



Fig. 60




Fig. 61

- ► Carry out action steps according to the illustration.
- ▶ The door alarm is deactivated.



# Input lock

You can use this function to activate or deactivate the input lock. The input lock prevents the appliance being operated accidentally, e.g. by children.

#### Application:

- Avoid unintentional modification of functions.
- Avoid unintentional switching off of the device.
- Avoid unintentional temperature setting.

#### Activating the input lock

If you activate the input lock, you can continue to navigate in the menus but you cannot select or change other functions.



Fig. 62




Fig. 63

- ► Carry out action steps according to the illustration.
- ▶ Input lock is activated.

#### Deactivating the input lock



Fig. 64




Fig. 65

- ► Carry out action steps according to the illustration.
- ▶ Input lock is deactivated.

# **Controls**



#### **Device information**

Use this function to indicate the model name, index, serial number and service number of your device. You will need the device information when you contact customer service. (see 10.4 Customer Service)

This function also opens the Advanced menu. (see 3 Functionality of the Touch display)

#### Indicating the device information



Fig. 66



Fig. 67

- ► Carry out action steps according to the illustration.
- Display indicates device information.



# Software

Use this function to indicate the software version of your device.

#### Indicating the software version



Fig. 68



Fig. 69

- ► Carry out action steps according to the illustration.
- Display indicates software version.



# Reminder

Use this function to activate or deactivate the reminders. The function is activated on delivery.

If the function is activated, the following reminders will appear:

 Replace the FreshAir activated carbon filter (see Replace the FreshAir activated carbon filter)

#### Activating the reminder



Fig. 70




Fig. 71

- Carry out action steps according to the illustration.
- ▶ Reminder is activated.

#### Deactivating the reminder



Fig. 72




Fig. 73

- ► Carry out action steps according to the illustration.
- ▶ Reminder is deactivated.



#### Demo mode

Demo mode is a special feature for dealers who want to demonstrate appliance features. If you activate demo mode, all refrigeration functions are deactivated.

If you switch on your appliance and "Demo" appears in the status display, then demo mode is already activated.

If you activate and then deactivate demo mode, the appliance will be reset to factory defaults. (see Resetting to factory settings)

#### Activating demo mode



Fig. 74





Fig. 75

- Carry out action steps according to the illustration.
- ▶ Demo mode is activated.
- > Appliance is switched off.
- Switch on the appliance. (see 4.1 Switching on appliance (first use))
- ▶ "DEMO" appears in the status display.

#### Deactivating demo mode



Fig. 76



#### Fig. 77

- ► Carry out action steps according to the illustration.
- Demo mode is deactivated.
- ▶ Appliance is switched off.
- Switch on the appliance. (see 4.1 Switching on appliance (first use))
- ▶ Appliance is reset to factory settings.

# $\bigcirc$

# Resetting to factory settings

Use this function to reset all settings to factory defaults. All settings you have made so far are reset to their original settings.

#### Performing a reset



Fig. 78




Fig. 79

- Carry out action steps according to the illustration.
- Device is reset.
- ▶ Device is switched off.
- ➤ Restart the device. (see 4.1 Switching on appliance (first use))

# 7.3 Messages

There are two categories of messages:

Category	Importance
Warning	Warnings appear in the event of a door alarm or malfunction.
	Simple warnings can be cancelled by yourself. In the event of serious malfunctions, you must contact customer service. (see 10.4 Customer Service)
Reminder	Reminders remind you of general processes. You can carry out these operations to end the message.

# 7.3.1 Overview of warnings

Behaviour of the appliance in the event of warnings:

- Warning appears on the display.
- The alarm tone sounds at an ever-increasing volume.
- The interior lighting pulsates for some warnings.

	Exit the nessage
is open for st	Carry out action steps (see Door alarm) .

# Controls

Cause	Exit the message
if the freezing temper- ature does not corre- spond to the set	steps (see Tempera-
temperature.	
if there is an appliance	steps
	if the freezing temperature has risen due to a power failure.  The message appears if the freezing temperature does not correspond to the set temperature.  The message appears if there is an appliance error. A component of the appliance has a

# 7.3.2 Ending warnings

#### Door alarm



Fig. 80 Example illustration

- ► Carry out action steps according to the illustration.
- ► Close the door.
- ▶ The display returns to the status indicator.

You can set how long the door may be open before the door alarm sounds. (see Setting the door alarm)

#### Power outage alarm

When the power failure has ended, the appliance cools down to the previously set target temperature.




Fig. 81 Example illustration

- Press the confirmation symbol.
- ▶ Warmest freezing temperature is displayed.
- ▶ If the freezing temperature was below -9 °C: Food can still be consumed.
  - If the freezing temperature has risen above -9 °C:
- ► Check the food.
- ► Press the confirmation symbol.
- ▶ The display returns to the status indicator: Current temperature and target temperature are displayed.

#### Temperature alarm

Temperature differences can be caused by:

- You have put in warm, fresh food.
- Too much warm air has got in while you were sorting out the freezer or removing items.
- There has been a longer power failure.
- The appliance is faulty.
- ► Eliminate causes.
- ▶ The appliance cools to the target temperature set previously.




Fig. 82 Example illustration

- ► Press the confirmation symbol.
- ▶ Warmest freezing temperature is displayed.
- ▶ If the freezing temperature was below -9 °C: Food can still be consumed.

If the freezing temperature has risen above -9 °C:

- ► Check the food.
- Press the confirmation symbol.
- ▶ The display returns to the status indicator: Current temperature and target temperature are displayed.

#### Error




Fig. 83 Example illustration

- Press the confirmation symbol.
- ▶ Error code is displayed.
- Note the error code.
- ▶ Press the confirmation symbol.
- > The display returns to the status indicator.
- ► Contact Customer Service. (see 10.4 Customer Service)

#### 7.3.3 Overview of reminders

Behaviour of the appliance during reminders:

- Reminder appears on the display.
- Alarm tone sounds.
- The interior lighting pulsates for some reminders.

Message	Cause	Exit the message
FreshAir  Replace the FreshAir activated carbon filter	appears when the	Carry out action steps (see Replace the FreshAir acti- vated carbon filter) .

## 7.3.4 Ending reminders

#### Replace the FreshAir activated carbon filter

Liebherr recommends: Replace the FreshAir activated carbon filter every 6 months.

#### Note

FreshAir activated charcoal filters can be purchased from the Liebherr-Hausgeräte store at home.liebherr.com/shop/de/deu/zubehor.html.



Fig. 84 Example illustration

- ▶ Press the confirmation symbol.
- ► Replace the activated carbon filter. (see 9.1 FreshAir carbon filter)
- ▶ Activated carbon filter ensures optimum air quality in the cooling unit.
- ▶ Reminder appears again after 6 months.

If you no longer wish to receive this reminder, you can deactivate it. (see Deactivating the reminder)

# 8 Features

## 8.1 Door rack

Door racks are suitable for storing drinks and food. You can move door racks for your own individual use and take them apart for cleaning. However, Liebherr recommends using the door racks in the position in the door as delivered from the factory.




Fig. 85 Example illustration, Door rack

# (1) Shelf




Fig. 86 Example illustration, Door rack with bottle holder
(1) Shelf
(2) Bottle holder

The following table shows examples of what can be stored in each door rack. Do not exceed the maximum loading weight of the door.

Door rack	Food			
Door rack (see Fig. 85)	Butter, tubes	cheese,	tinned	food,

Door rack	Food
Door rack with beholder (see Fig. 86)	Bottles The sliding bottle holder secures the bottles in the door rack.

# 8.1.1 Removing the door rack




Fig. 87 Example illustration

- ► Push the door rack upwards.
- ▶ Pull the door rack forward.

# 8.1.2 Inserting the door rack




Fig. 88 Example illustration

- ► Slide in the door rack.
- ► Press the door rack down.

# 8.1.3 Removing the bottle holder




Fig. 89

- ▶ Slide the bottle holder to the side as far as the recess.
- ► Remove the bottle holder forwards.

# 8.1.4 Inserting the bottle holder




Fig. 90

► Insert the bottle holder in the recess.

▶ Push the bottle holder to the desired position to the side.

# 8.2 Shelves

# 8.2.1 Adjusting/removing the shelves

The shelves are prevented from being pulled out accidentally by pull out stops.




Fig. 91

- Lift the shelf and pull forward.
- ▶ Line up the side runner.
- ► Adjust the height of the shelf: Lift or lower it to the desired height and slide it in.

-or-




Fig. 92

- ▶ Remove the shelf completely: Pull it out to the front.
- ► Easier removal: Set the shelf at an angle.
- Insert the shelf again: Slide it in all the way.
- ▶ The pull-out stoppers point downwards.
- ▶ The pull-out stoppers are behind the front support.

# 8.3 Dividing shelf

### 8.3.1 Using the dividing shelf

The shelves are prevented from being pulled out accidentally by pull out stops.




Fig. 93

▶ Push the dividing shelf underneath as shown.




Fig. 94

#### Adjusting the height:

- ▶ Pull the glass panels out Fig. 94 (1) from the front, one at a time.
- Release the support rails and click in at the height you want.
- Slide in the glass panels one at a time.
- > Flat pull-out stoppers at the front, right behind the support rails.
- ▶ High pull-out stoppers at the back.

#### Using both shelves:

- ▶ Hold the glass panel with one hand and pull it to the front.
- ▶ The glass panel Fig. 94 (1) and trim strip are at the front.
- ▶ The stops Fig. 94 (3) point down.

# 8.4 Space for baking tray

There is space for a baking tray Fig. 1 (6) above the drawers.




Fig. 95

Ensure that the following conditions are met:

- Max. baking tray dimensions are adhered to (see 10.1 Technical specifications).
- Baking tray is cooled to room temperature.
- ☐ The lowest door rack is set at least one position higher.

With the door open to 90°:

▶ Slide the baking tray onto the lower side runners.

-or-

If baking tray is uneven:

Use the supplied support rails.




Fig. 96

- ► Snap support rails into the lowest runners. With the door open to 90°:
- ► Slide the baking tray in on the support rails.

# 8.5 Adjustable bottle shelf

Either the glass shelf or the variable bottle rack can be used in the bottom section of the refrigerator. The glass shelf is inserted at delivery.




Fig. 97 Example illustration
(1) Variable bottle rack

# 8.5.1 Using the variable bottle rack




Fig. 98

- ▶ Lift the glass shelf *Fig. 98 (1)* at the front and remove.
- ▶ Store the glass shelf Fig. 98 (1) in a safe place outside the appliance.




Fig. 99

 Place bottles in the back row with their bases against the back wall. (see Fig. 99)

#### Note

When the bottles protrude over the variable bottle rack at the front:

► Set the lower door rack one position higher.

#### 8.5.2 Using the glass shelf

Ensure that the following requirements are met:

- Bottles have been removed.
- ☐ Variable bottle rack has been cleaned. (see 9.3 Removing / inserting the variable bottle rack) (see 9.6.3 Clean the components)




Fig. 100

- ▶ Place the glass shelf *Fig. 100 (1)* at an angle, sloping it downwards and backwards.
- ▶ Lower the glass shelf Fig. 100 (1) at the front.

### 8.6 Drawers

You can remove the drawers for cleaning.

You can remove the drawers to use VarioSpace.

The way to remove/insert the drawers varies depending on the pull-out system. Your appliance can contain various pull-out systems.

#### Note

The energy consumption increases and the cooling power goes down if ventilation is not sufficient.

- Leave the bottom drawer in the appliance!
- ▶ Always leave the fan air vents clear on the back wall!

# 8.6.1 Drawer on appliance base or glass shelf

The drawer runs directly on the appliance base or on a glass shelf. There are no rails.

When you remove the drawers, you can use the glass shelves below them as storage shelves.

#### Removing drawer




Fig. 101

▶ Remove drawer as shown in the illustration.

#### Inserting drawer




Fig. 102

► Insert drawer as shown in the illustration.

### 8.6.2 Drawer on telescopic rails

The drawer runs on extendible rails (telescopic rails). There are fully extendible telescopic rails and telescopic rails with partial pull-out. Drawers which are fully extendible can be pulled out fully from the appliance. Drawers with partial pull-out cannot be removed fully from the appliance. The system in your appliance depends on the type of appliance.

# Fully extendible\*

If you have fully extendible rails, there is a clamp located at the back on the left and right of the rail.

### Removing drawer




Fig. 103

- ▶ Pull out drawer as far as it will go.
- ▶ Lift left clamp and simultaneously pull drawer forwards on the left. Fig. 103 (1)
- ▶ Lift right clamp and simultaneously pull drawer forwards on the right. Fig. 103 (2)
- ► Remove drawer to the front. Fig. 103 (3)
- ▶ Slide rails in.

#### Inserting drawer




Fig. 104

- ► Slide rails in.
- ▶ Place drawer on rails.
- ▶ Slide in drawer to the back.
- ▶ Drawer latches in audibly at the back.

#### Partial pull-out fridge compartment\*

#### Removing drawer





Fig. 105

- ▶ Pull out drawer half-way. Fig. 105 (1)
- ▶ Push the drawer down at the front. Fig. 105 (2)
- ▶ Push the left rail in by about 2 cm. Fig. 105 (3)
- ▶ Push the right rail in by about 2 cm. Fig. 105 (4)
- Remove drawer to the front. Fig. 105 (5)



#### Fig. 106

If the rails are not yet fully inserted after removing the drawer:

▶ Push rails in completely.

#### Inserting drawer




Fig. 107

- ► Slide rails in.
- Place drawer on rails.
- ▶ Slide in drawer to the back.

# 8.7 Compartment lid for Fruit & Vegetable Safe

The compartment lid ensures constant levels of humidity.

The compartment lid is directly on the drawer and can be covered by shelves or additional drawers.




Fig. 108 Example illustration, compartment lid for Fruit & Vegetable Safe

- (1) Fruit & Vegetable Safe
- (2) Compartment lid for Fruit & Vegetable Safe
- (3) Variable bottle rack

# 8.7.1 Reducing the air humidity in the drawer




Fig. 109

- Pull out the drawer Fig. 109 (1).
- ► Grasp the recessed grip Fig. 109 (2) on the compartment lid and pull the compartment lid forwards at the same time.
- When the drawer is closed, there is a small gap between the compartment lid and the drawer.

# 8.7.2 Increasing the air humidity in the drawer




Fig. 110

- ▶ Pull out the drawer Fig. 110 (1).
- ► Grasp the recessed grip Fig. 110 (2) on the compartment lid and push the compartment lid backwards at the same time
- ▶ When the drawer is closed, the compartment lid seals with the drawer.

# 8.7.3 Using Fruit & Vegetable Safe as Meat & Dairy Safe

You can use the Fruit & Vegetable Safe as Meat & Dairy Safe. To do this, you must reduce the humidity in the drawer. (see 8.7.1 Reducing the air humidity in the drawer)

### 8.8 Glass shelves

You can remove the glass shelves under the drawers for cleaning.

You can remove the glass shelves under the drawers to use VarioSpace.

## 8.8.1 Removing / inserting the glass shelf

Make sure that the following requirements are fulfilled:

□ Glass shelf under the drawer: The drawer has been removed. (see 8.6 Drawers)

## Removing glass shelf




Fig. 111 Example illustration, glass shelf

- ► Lift the glass shelf forwards.
- ► Remove the glass shelf forwards.

#### Inserting glass shelf




Fig. 112 Example illustration, glass shelf

- ▶ Place the glass shelf at an angle behind the stoppers.
- Lower glass shelf.
- ► Slide in glass shelf to the back.

# 8.9 VarioSpace




Fig. 113

You can remove drawers and glass panels from your appliance. This provides more room for large food items such as poultry, joints of meat, large game, and tall baked products. You can then freeze these items whole for later preparation.

▶ Note the weight limits on the drawers and glass panels (see 10.1 Technical specifications).

## 8.10 Bottle holder

#### 8.10.1 Using the bottle holder




Fig. 114

- ▶ Push the bottle holder onto the bottles.
- ▶ The bottles are prevented from falling over.

### 8.11 FlexCube

The FlexCube has different sized openings, so you can store small items such as tubes, open yoghurt pots or quail eggs in it. The FlexCube fits into all Liebherr door racks, for example. If necessary, you can also set up several FlexCubes next to each other.

# **Maintenance**




Fig. 115 Example illustration

#### Note

These accessories can be purchased from the Liebherr-Hausgeräte shop at home.liebherr.com/shop/de/deu/zubehor.html.

#### 8.11.1 Using the FlexCube




Fig. 116 Example illustration

► Insert the FlexCube in the door rack.

-or-




Fig. 117 Example illustration

- ▶ Place FlexCube on shelf.
- ► Sort small parts into the FlexCube for storage.

# 9 Maintenance

# 9.1 FreshAir carbon filter

The FreshAir carbon filter is in the compartment above the fan

It guarantees the best air quality.

- □ Replace the carbon filter every 6 months. When the reminder is set, a message on the display prompts you to change it.
- The carbon filter can be disposed of with the regular household waste.

#### Note

FreshAir activated charcoal filters can be purchased from the Liebherr-Hausgeräte store at home.liebherr.com/shop/de/deu/zubehor.html.

# 9.1.1 Removing the FreshAir carbon filter




Fig. 118

- ▶ Pull out the compartment Fig. 118 (1).
- ▶ Remove the carbon filter Fig. 118 (2).

# 9.1.2 Inserting the FreshAir carbon filter




Fig. 119

- ▶ Insert the carbon filter as shown in the diagram Fig. 119 (1).
- ▶ The carbon filter clicks into place.
  If the carbon filter is pointing downwards:
- ▶ Push the compartment in Fig. 119 (2).
- ▶ The carbon filter is now ready for use.

# 9.2 Disassembling / assembling pullout systems

# 9.2.1 Notes on disassembly

You can disassemble some of the pull-out systems for cleaning. Your appliance can contain a variety of pull-out systems.

The following pull-out systems can be disassembled or cannot be disassembled:

Pull-out system	can be disassembled / cannot be disassembled
Drawer on appliance base or glass shelf	cannot be disassembled
Fully extendible*	cannot be disassembled*
Fridge section partial pull-out*	cannot be disassembled*

# 9.3 Removing / inserting the variable bottle rack

The variable bottle rack can be removed for cleaning.

### 9.3.1 Removing the variable bottle rack

Ensure that the following requirements are met:

- Bottles have been removed.
- ☐ Glass shelf has been removed. (see 8.5.1 Using the variable bottle rack)




Fig. 120

- ▶ Lift the variable bottle rack at the front and pull it out.
- ▶ The compartment lid is visible.

#### Note

Liebherr recommends:

Do not place any items on the compartment lid below.

# 9.3.2 Inserting the variable bottle rack




Fig. 121

- Push the variable bottle rack in to the end stop and press it down.
- ► Insert the glass shelf. (see 8.5.2 Using the glass shelf)
- ► Use the variable bottle rack for bottles.

# 9.4 Compartment lid for Fruit & Vegetable Safe

You can remove the compartment lid for cleaning.

## 9.4.1 Removing the compartment lid

Ensure that the following requirements are met:

- ☐ The glass shelf directly above the variable bottle rack has been removed.
- ☐ The variable bottle rack has been removed.
- □ The drawer directly below the compartment lid has been removed. (see 8.6 Drawers)




Fig. 122

- Push the compartment lid backwards.
- Lift the compartment lid forwards.
- ▶ Remove the compartment lid forwards and upwards at an angle.

## 9.4.2 Inserting the compartment lid




Fig. 123

If the THIS SIDE UP lettering is at the top:

- Insert the rear retaining parts into the relevant rear openings.
- ▶ Push the compartment lid backwards.
- ► Lower the compartment lid forwards and engage the front retaining parts into the openings.
- ► Move the compartment lid into the required position.

# 9.5 Defrosting the appliance

## 9.5.1 Defrosting the fridge compartment

Defrosting is performed automatically. The water from the thawing process drains through the outlet and evaporates.

► Clean the drain opening at regular intervals. (see 9.6 Cleaning the appliance)

# 9.5.2 Defrosting the freezer compartment with NoFrost

Defrosting is performed automatically with the NoFrost system. The moisture is deposited on the evaporator, is periodically defrosted and evaporates.

The appliance does not have to be defrosted.

# 9.6 Cleaning the appliance

# 9.6.1 Ready



#### WARNING

Danger of electric shock!

Remove the refrigerator connector or interrupt the power supply.



## **WARNING**

Risk of fire

- ▶ Do not damage the refrigeration circuit.
- ► Empty the appliance.
- ► Remove mains connector.

-or-

► Activate CleaningMode. (see CleaningMode)

## 9.6.2 Cleaning the interior

#### **NOTICE**

Improper cleaning!

Damage to the appliance.

- ▶ Only use soft cleaning cloths and ph-neutral all-purpose cleaners.
- ▶ Do not uses abrasive sponges or steel wool which may cause scratches.
- ▶ Do not use any sharp or abrasive cleaning agents, nor any that contain sand, chloride or acid.
- ▶ Plastic surfaces: clean by hand with a soft clean cloth, lukewarm water and a little detergent.
- ► Metal surfaces: clean by hand with a soft clean cloth, lukewarm water and a little detergent.
- ► Drain hole: remove deposits using a thin item (for example a cotton bud).

### 9.6.3 Clean the components

# NOTICE

Improper cleaning!

Damage to the appliance.

- Only use soft cleaning cloths and ph-neutral all-purpose cleaners.
- Do not uses abrasive sponges or steel wool which may cause scratches.
- ▶ Do not use any sharp or abrasive cleaning agents, nor any that contain sand, chloride or acid.

# Clean with a soft, clean cloth, lukewarm water and some detergent:

- Door rack
- Shelf
- Dividing shelf
- Compartment lid for Fruit & Vegetable Safe
- Drawer
- Adjustable bottle shelf

#### Clean with a damp cloth:

- Retractable rails

Please note: The grease in the tracks is used for lubrication and must not be removed!

#### Wash in the dishwasher up to 60 °C:

- Bottle rack
- Holder of the dividing shelf
- Ice cube tray
- FlexCube
- To disassemble components: see the relevant section.
- ► Clean the components.

### 9.6.4 After cleaning

- ▶ Wipe the appliance and the components dry.
- ► Connect and switch on the appliance.
- Activate SuperFrost (see 7.2 Appliance functions). The temperature is cold enough:
- ▶ Place the food inside.
- ► Repeat cleaning regularly.

# 10 Customer help

# 10.1 Technical specifications

Temperature range		
Cooling 3 °C to 9 °C		
BioFresh	0 °C to 3 °C	
Freeze	-26 °C to -15 °C	

Maximum	ice cube q	uantit	ty / 24	hours		
Freezer ment	compart-	see capa	type city/	plate ′ 24 h"	under	"Freezing

Maximum component capacity				
Features	Appliance width 550 mm (see installation instructions, appliance dimensions)	Appliance width 600 mm (see installation instructions, appliance dimensions)	Appliance width 700 mm (see instal- lation instruc- tions, appli- ance dimen- sions)	
Drawer on glass shelf (see 8.6.1 Drawer on appliance base or glass shelf)	12 kg	15 kg	-	

Maximum size baking tray		
Width 466 mm		
Depth	386 mm	
Height	50 mm	

Lighting	
Class <sup>1</sup>	Light source
This product contains one or more energy efficiency class G light sources.	LED

<sup>&</sup>lt;sup>1</sup> The appliance may contain light sources with different energy efficiency classes. The lowest energy efficiency class is indicated.

# 10.2 Operating noises

The appliance makes different noises when it is on.

- At higher temperatures the appliance uses less energy but works for longer. It is quieter.
- At lower temperatures the food is cooled faster. It is louder.

#### Examples:

Functions on (see 7.2 Appliance functions)

- Fan running
- Food recently added
- High ambient temperature
- Door open for a while

Noise	Possible cause	Type of noise
Bubbling and splashing	Coolant flowing into the cooling circuit.	
Hissing	Coolant sprays into the cooling circuit.	
Humming	The appliance is cooling. The volume depends on the cooling output.	
Suction noises*	Soft-closing door is being opened and closed.*	
Humming and rustling	The fan is running.	Normal operating noise
Clicking	Components are switched on and off.	

Noise	Possible cause	Type of noise
Rattling or humming	Valves or flaps are working.	Normal switching noise

Noise	Possible cause	Type of noise	Lifting
Vibration	Improper installation	Defective noise	Check the installation. Level the appliance.
Rattling	Components, items inside the appliance	Defective noise	Secure components. Leave enough space between the items.

# 10.3 Technical fault

Your appliance is designed and built to ensure it works reliably and has a long service life. In the unlikely event that a fault occurs during operation, please check whether it is due to an operating error. If so, you will be charged for the callout and repair costs even if it falls within the warranty period.

You can fix the following faults yourself.

# 10.3.1 Appliance function

Defect	Cause	Remedy
The appliance is	→ The appliance is not switched on.	► Switch the appliance on.
not working.	→ The power plug is not properly plugged into the socket.	► Check the power plug.
	→ There is something wrong with the power outlet fuse.	► Check the fuse.
	→ Power cut	<ul> <li>Keep the appliance closed.</li> <li>Safeguarding food: Place cold packs on top of food or use another freezer if the power cut lasts longer.</li> <li>Do not re-freeze defrosted food,</li> </ul>
	→ The IEC socket is not plugged into the appliance correctly.	► Check the IEC socket.
Temperature is not cold enough.	→ The appliance door is not closed properly.	Close the appliance door.
	→ Not enough ventilation.	► Keep ventilation grille clear, and clean it.
	→ The ambient temperature is too high.	▶ Problem solution: (see 1.4 Appliance range of use)
	→ The appliance was opened too many times or for too long.	► Wait to see if the required temperature corrects itself. If not, contact Customer Service. (see 10.4 Customer Service)
	→ Too much fresh food was placed inside without SuperFrost.	► Solution: (see SuperFrost)
	→ The temperature is set incorrectly.	► Turn down the temperature and check after 24 hours.
	→ The appliance is too close to a heat source (oven, radiator, etc).	► Move the appliance or the heat source.
	→ The appliance was not correctly installed in the recess.	► Check if the appliance was installed correctly and that the door closes properly.

# **Shutting down**

Defect	Cause	Remedy
The door seal is defective or needs to be replaced for another reason.	→ The door seal can be replaced. It can be replaced without the need for special tools.	► Contact Customer Service. (see 10.4 Customer Service)
The appliance builds up too much ice or condensation.	→ The door seal may have slipped out of its groove.	► Check that the door seal is well fitted in the groove.

#### 10.3.2 Features

Defect	Cause	Remedy
The internal light	→ The appliance is not switched on.	► Switch the appliance on.
does not come on.	→ The door was open for longer than 15 minutes.	▶ Interior lighting switches off automatically after about 15 minutes when the door is open.
	→ The LED interior light is faulty or the lid is damaged.	► Contact Customer Service. (see 10.4 Customer Service)

## 10.4 Customer Service

First check whether you can rectify the fault yourself (see 10 Customer help) . If you cannot rectify the problem, contact Customer Service.

You can find the address in the enclosed brochure "Liebherr-Service" or at home.liebherr.com/service.



### WARNING

Unprofessional repair! Injuries.

- ► Have any repairs and action not expressly specified on the appliance and mains cable carried out by service personnel only. (see 9 Maintenance)
- ► A damaged mains cable may only be replaced by the manufacturer, the manufacturer's Customer Service or a similarly qualified person.
- ▶ In the case of appliances with an IEC connector, the change may be made by the customer.

#### 10.4.1 Contacting Customer Service

Make sure that the following appliance information is available:

- Appliance name (model and index)
- ☐ Service no. (Service)
- ☐ Serial no. (S no.)
- Call up the appliance information via the display. (see Device information)

-or-

- ► Refer to the type plate for appliance information. (see 10.5 Model plate)
- ▶ Note down the appliance information.
- Notify customer service: Report errors and the appliance information.
- This will help us to provide you with a faster, more accurate service.
- ► Follow further instructions from Customer Service.

# 10.5 Model plate

The model plate is behind the drawers on the inside of the appliance.



Fig. 124

- (1) Appliance description
- (3) Serial no.
- (2) Service no.
- ▶ Note the data on the model plate.

# 11 Shutting down

- Empty the appliance.
- ► Switch off appliance. (see Switching the appliance off and on)
- ▶ Pull the mains plug out of the socket.
- ▶ Remove the IEC socket if required: Pull the IEC socket out of the appliance plug and move it to the left and right at the same time.
- Clean appliance. (see 9.6 Cleaning the appliance)
- ▶ Leave the door open, so that no unpleasant odours arise.

# 12 Disposal

# 12.1 Preparing appliance for disposal



Liebherr uses batteries in some of its appliances. In the EU, for environmental reasons, legislation obliges the end user to remove these batteries before disposing of old appliances. If your appliance contains batteries, a corresponding notice is attached.

Lamps

If you can remove the lamps yourself without destroying them, also remove these before disposal.

- ► Take the appliance out of operation.
- ► If possible: remove lamps without destroying them.

# 12.2 Disposing of the appliance in an environmentally friendly manner



The appliance still contains valuable materials and must be disposed of separately from unsorted municipal waste.





Dispose of batteries separately from the old appliance. To do this, you can return the batteries free of charge to retailers as well as recycling centres and collection centres for recyclable materials.

Lamps

Dispose of removed lamps via the respective collection systems.

For Germany:

You can dispose of the appliance free of charge via the class 1 collection containers at the local recycling and recyclable material collection centres. When purchasing a new fridge/freezer, if the sales area > 400 m², retailers will also take back the old appliance free of charge.



#### WARNING

Leaking coolant and oil!

Fire. The coolant contained in the appliance is eco-friendly, but also flammable. The oil contained in the appliance is flammable. Escaping coolant and oil can ignite if the concentration is high enough and in contact with an external heat source.

- ▶ Do not damage the pipelines of the coolant circuit and the compressor.
- ▶ Observe the notes on transporting the appliance.
- Transport the appliance without damaging it.
- Dispose of batteries, lamps and the appliance according to the above specifications.



home.liebherr.com/fridge-manuals

integrated fridge/freezer with BioFresh

Part number index: 7088609-00

Issue date: 20250520