



## Installation Guide

Quality, Design and Innovation



[home.liebherr.com/fridge-manuals](http://home.liebherr.com/fridge-manuals)



# LIEBHERR

# General safety instructions

## Contents

|           |                                                          |           |
|-----------|----------------------------------------------------------|-----------|
| <b>1</b>  | <b>General safety instructions.....</b>                  | <b>2</b>  |
| <b>2</b>  | <b>Installation conditions.....</b>                      | <b>3</b>  |
| 2.1       | Location.....                                            | 3         |
| 2.2       | Building the appliance into kitchen units.....           | 3         |
| 2.3       | Installing multiple appliances.....                      | 4         |
| 2.4       | Mains connection.....                                    | 4         |
| <b>3</b>  | <b>Installation dimensions.....</b>                      | <b>5</b>  |
| <b>4</b>  | <b>Ventilation requirements.....</b>                     | <b>5</b>  |
| <b>5</b>  | <b>Connection dimensions for the power supply.....</b>   | <b>5</b>  |
| <b>6</b>  | <b>Transporting appliance.....</b>                       | <b>5</b>  |
| <b>7</b>  | <b>Unpacking the appliance.....</b>                      | <b>5</b>  |
| <b>8</b>  | <b>Mounting wall spacers.....</b>                        | <b>5</b>  |
| <b>9</b>  | <b>Setting up the appliance.....</b>                     | <b>6</b>  |
| <b>10</b> | <b>Setting up the appliance so that it is level.....</b> | <b>6</b>  |
| <b>11</b> | <b>After setting up.....</b>                             | <b>6</b>  |
| <b>12</b> | <b>Disposing of packaging.....</b>                       | <b>6</b>  |
| <b>13</b> | <b>What the symbols mean.....</b>                        | <b>7</b>  |
| <b>14</b> | <b>Door hinge change.....</b>                            | <b>7</b>  |
| 14.1      | Removing the door.....                                   | 8         |
| 14.2      | Moving the upper bearing parts to the other side.....    | 9         |
| 14.3      | Moving the lower bearing parts to the other side.....    | 10        |
| 14.4      | Moving the door bearing parts to the other side.....     | 11        |
| 14.5      | Moving the handles to the other side.....                | 11        |
| 14.6      | Fitting the door.....                                    | 12        |
| 14.7      | Aligning the door.....                                   | 12        |
| 14.8      | Fitting the covers.....                                  | 12        |
| <b>15</b> | <b>Connecting the appliance to the power supply....</b>  | <b>13</b> |

The manufacturer is continually working on the further development of all types and models. Please be aware that we reserve the right to make changes to the shape, equipment and technology.

| Symbol | Explanation                                                                                                                                                                                                                                                                                                                                                                         |
|--------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|        | <b>Read instructions</b><br>Please read the information in these instructions carefully to understand all of the benefits of your new appliance.                                                                                                                                                                                                                                    |
|        | <b>Additional information on the Internet</b><br>The digital manual with additional information can be found via the QR code on the front of the manual or by entering the service number at <a href="http://home.liebherr.com/fridge-manuals">home.liebherr.com/fridge-manuals</a> .<br>The service number can be found on the serial tag:<br><br><i>Fig. Example illustration</i> |
|        | <b>Check appliance</b><br>Check all parts for transport damage. If you have any complaints, please contact your agent or customer service.                                                                                                                                                                                                                                          |


| Symbol | Explanation                                                                                                                                                                   |
|--------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|        | <b>Differences</b><br>These instructions apply to a range of models, so differences are possible. Sections that apply to certain models only are marked with an asterisk (*). |
|        | <b>Instructions and results</b><br>Instructions are marked with a ►.<br>Results are marked with a ▷.                                                                          |
|        | <b>Videos</b><br>Videos about the appliances are available on the YouTube channels of Liebherr-Hausgeräte.                                                                    |

### Open source licences:

The appliance contains software components that use open source licences. Information on the open source licences used can be found here: [home.liebherr.com/open-source-licences](http://home.liebherr.com/open-source-licences)

## 1 General safety instructions

- Please keep this assembly manual in a safe place so you can refer back to it at any time.
- If you pass the appliance on, please hand this assembly manual to the next user.
- Read this assembly manual carefully before installation and use to ensure safe and correct use of the appliance. Follow the instructions, safety instructions and warning messages included at all times. They are important for ensuring you can operate and install the appliance safely and without any problems.
- First read the general safety instructions in the “General safety instructions” section of the **operating instructions**, which accompany these installation instructions, and follow them. If you cannot find the **operating instructions**, you can download the **operating instructions** from the internet by entering the service number at [home.liebherr.com/fridge-manuals](http://home.liebherr.com/fridge-manuals). The service number can be found on the serial



tag:

- **Observe the warning messages and other detailed information in the other sections when installing the appliance:**

|  |               |                                                                                                                     |
|--|---------------|---------------------------------------------------------------------------------------------------------------------|
|  | <b>DANGER</b> | identifies a situation involving direct danger which, if not obviated, may result in death or severe bodily injury. |
|--|---------------|---------------------------------------------------------------------------------------------------------------------|

|                                                                                   |         |                                                                                                       |
|-----------------------------------------------------------------------------------|---------|-------------------------------------------------------------------------------------------------------|
|  | WARNING | identifies a dangerous situation which, if not obviated, may result in death or severe bodily injury. |
|  | CAUTION | identifies a dangerous situation which, if not obviated, may result in minor or medium bodily injury. |
|                                                                                   | NOTICE  | identifies a dangerous situation which, if not obviated, may result in damage to property.            |
|                                                                                   | Note    | identifies useful instructions and tips.                                                              |

## 2 Installation conditions



### WARNING

Fire hazard due to dampness!

If live parts or the mains lead become damp this may cause short circuits.

- The appliance is designed for use in enclosed areas. Do not operate the appliance outdoors or in areas where it is exposed to splash water or damp conditions.

Intended use

- Install and use the appliance in indoor spaces only.

### 2.1 Location



### WARNING

Leaking coolant and oil!

Fire. The coolant contained in the appliance is eco-friendly, but also flammable. The oil contained in the appliance is flammable. Escaping coolant and oil can ignite if the concentration is high enough and in contact with an external heat source.

- Do not damage the pipelines of the coolant circuit and the compressor.

- The best place for installation is a dry and well ventilated room.
- If the appliance is installed in a very humid environment, condensation can build up on the outside of the unit. Always ensure good airflow and ventilation in the installation location.
- The more refrigerant there is in the appliance, the larger the space that it is installed in must be. If the space is too small, any leak may create a flammable mixture of gas and air. For every 8 g of refrigerant, the installation space must be at least 1 m<sup>3</sup>. Information regarding the coolant can be found on the serial tag inside the appliance.

#### 2.1.1 Supporting floor

- The floor of the installation site must be horizontal and even.
- The surface supporting the appliance must be at the same level as the surrounding floor.

#### 2.1.2 Positioning

- Do not place the appliance in direct sunlight or near radiators or similar sources of heat.
- You can place the appliance directly next to an oven.

- If the appliance is placed directly next to an oven, the energy consumption may increase slightly. This is dependent on the service life and usage intensity of the oven.
- Install the appliance with the rear panel up against the wall and always use the supplied wall spacers (see below).

### 2.2 Building the appliance into kitchen units

You can install kitchen cabinets around the appliance.




Fig. 1

(1) Top cabinet

(2) Appliance

(3) Kitchen cabinet

(4) Wall

(A) Appliance depth

(B) Door depth

(C) Ventilation cross section

(D) Distance to the back of the appliance

(E) Distance to the side of the appliance

You can place the appliance directly beside the kitchen cabinet Fig. 1 (3).

There must be a ventilation shaft at the depth Fig. 1 (D) of the back of the top cupboard over the entire width of the top cupboard.

The ventilation cross-section Fig. 1 (C) must be maintained under the ceiling.

If the appliance is set up with the hinges next to a wall Fig. 1 (4), the distance between the appliance and the wall must be at least 57 mm. This is how far the handle protrudes when the door is open.

In order to be able to fully open the door, the appliance must protrude by the depth of the door Fig. 1 (B) from the front of the kitchen cabinet. The appliance may protrude further depending on the depth of the kitchen cabinets Fig. 1 (3) and whether wall spacers are used.

# Installation conditions

| Appliances with lever handle: |                          |
|-------------------------------|--------------------------|
| A                             | 675 mm <sup>x</sup>      |
| B                             | 75 mm                    |
| C                             | Min. 300 cm <sup>2</sup> |
| D                             | Min. 50 mm               |
| E                             | Min. 57 mm               |

<sup>x</sup> The use of wall spacers increases the dimensions by 15 mm (see 8 Mounting wall spacers).

Ensure that the following conditions are met:

- Recess dimensions are adhered to.
- Ventilation requirements are complied with (see 4 Ventilation requirements).

## 2.3 Installing multiple appliances

The appliances have been developed for different installation methods. If you wish to install several appliances next to each other or on top of each other, ensure that the following requirements are met:



- ☐ Only install appliances next to or on top of each other if they have been developed for this.
- ☐ Observe notices and the following table.

### NOTICE

Risk of damage due to condensate!

- Do not place the appliance directly next to another cooling/refrigeration unit.

| Model                                                     | Installation method |
|-----------------------------------------------------------|---------------------|
| All models                                                | Standalone          |
| Models with a model designation starting with <b>S...</b> | Side-by-Side (SBS)  |

| Model                            | Installation method                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
|----------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Models without side wall heating |  <p><b>Next to each other:</b> Install with gap <b>A</b> of 70 mm between the appliances.</p> <p><b>Next to each other:</b> Install with gap <b>A</b> of 100 mm between the appliances.</p> <p>If you do not comply with this gap, condensation will form on the side walls between the appliances.</p>  <p><b>On an exterior wall:</b> Install with gap <b>A</b> as with installation next to each other.</p> <p>If you do not comply with this gap, condensation may form on the appliance's side wall.</p> |

### Models and their installation method

Assemble the appliances according to the separate installation instructions.

## 2.4 Mains connection



### WARNING

Danger of fire due to incorrect positioning!

If the mains cable or plug touches the back of the appliance, the vibration can damage the mains cable or the plug resulting in a short circuit.

- Make sure the mains cable is not trapped under the appliance when you position the appliance.
- Stand the appliance so that it is not touched by connectors or main cables.
- Do not connect any appliances to sockets in the area of the back of the appliance.
- Do **not** place and operate multi-sockets/power distributors and other electronic devices (such as halogen transformers) at the back of the appliances.

## 3 Installation dimensions




Fig. 2

| Dimensions with lever handle (mm): |      |     |                  |     |                   |
|------------------------------------|------|-----|------------------|-----|-------------------|
|                                    | h    | a   | b'               | c'  | d'                |
| S/FN/sdh 52..                      | 1855 | 597 | 719 <sup>x</sup> | 654 | 1222 <sup>x</sup> |

<sup>x</sup> For appliances with supplied wall spacers, the dimension must be increased by 15 mm (see 8 Mounting wall spacers) .

## 4 Ventilation requirements

### NOTICE

Danger of overheating due to insufficient air ventilation! The compressor may be damaged if there is insufficient air ventilation.

- ▶ Take care to ensure adequate air ventilation.
- ▶ Observe the ventilation requirements.

If the appliance is integrated into a fitted kitchen, the following ventilation requirements must be adhered to:

- As a rule, the larger the ventilation space the more efficiently the appliance can run.

## 5 Connection dimensions for the power supply

The connection to the power supply is on the rear of the appliance. To connect your appliance safely, ensure that the following requirements are met:

- Dimensions for the connection to the power supply are known and are adhered to. See table below.
- Connection to the power supply according to the instructions. (see 15 Connecting the appliance to the power supply)




Fig. 3 Fridge/freezer combinations / freezers / full-capacity BioFresh appliances

- (a) Maximum available length of the mains connection cable
- (b) Maximum available length of the mains connection cable
- (c) Maximum available vertical length of the mains connection cable
- (d) Gap between appliance plug and floor
- (G) Appliance plug

| For 600 mm wide appliances: |           |
|-----------------------------|-----------|
| a                           | ~ 1800 mm |
| b                           | ~ 1400 mm |
| c                           | ~ 2100 mm |
| d                           | ~ 200 mm  |

## 6 Transporting appliance

### Note when transporting the appliance:

- ▶ Transport the appliance upright.
- ▶ Use two people to transport the appliance.

### During first use:

- ▶ Transport the appliance packaged.

### When transporting appliances after initial commissioning (e. g. moving or cleaning):

- ▶ Empty the appliance.
- ▶ Secure the door against unintentional opening.

## 7 Unpacking the appliance

Before you connect the appliance, report any damage immediately to the delivery company.


- ▶ Check the appliance and the packaging for damage during transport. Contact the supplier immediately if you suspect any level of damage.
- ▶ Remove all materials from the back or the side walls of the appliance that may prevent proper installation or ventilation.
- ▶ Remove all protective films from the appliance. Do not use sharp or pointed objects for this.
- ▶ Take the power cable from the rear of the appliance. Remove the cable brackets when you do this, otherwise there will be noise caused by vibrations!

## 8 Mounting wall spacers

With wall spacers, your device achieves the declared energy consumption and no condensation forms in high ambient humidity. The device is fully functional without the spacer brackets, but its energy consumption will be slightly higher.

If you insert the wall spacers, then the device depth increases by approx. 15 mm.

# Setting up the appliance



- ▶ Appliance with enclosed wall spacers: Insert the wall spacers on the rear of the appliance at the bottom left and right.

## 9 Setting up the appliance



### CAUTION

Risk of injury due to heavy appliance!

- ▶ Have two people transport the appliance to its installation site.



### WARNING

Risk of fire due to short circuit!

- ▶ When you set the appliance up: do not kink, jam or damage the mains cable.
- ▶ The appliance must not be operated with a defective mains cable.



### WARNING

Danger of injury and damage due to the appliance being unstable!

The appliance can topple over.

- ▶ Secure the appliance as described in the instructions.



### WARNING

Fire hazard and danger of damage!

- ▶ Do not place appliances emitting heat e.g. microwaves, toasters etc. on the appliance!

Ensure that the following conditions are met:

- ☐ Only move the device when it is not loaded.
- ☐ Only install the appliance with help.
- ▶ Remove the mains cable from the package.
- ▶ Plug the mains cable's IEC socket completely into the appliance plug on the back of the appliance. Ensure that the IEC socket is tight.
- ▶ Use a cord to lay the mains plug to a freely accessible socket if required.

## 10 Setting up the appliance so that it is level




Fig. 4

- ▶ Unscrew the adjustable feet Fig. 4 (A) using the enclosed open-end spanner and a spirit level until the appliance is firmly aligned and level.



### CAUTION

Risk of injury or damage from the appliance tipping or the door falling open!

If the additional adjustable foot on the base support is not correctly positioned on the floor, there is a risk of the door falling open or the appliance tipping. This can lead to injury or property damage.

- ▶ Unscrew the additional adjustable foot on the swap bearing block as instructed.
- ▶ Unscrew the adjustable foot Fig. 4 (B) on the swap bearing block with the enclosed open-end spanner until it rests on the floor.
- ▶ Turn the adjustable foot Fig. 4 (B) 90° further.
- ▷ The appliance is aligned.

## 11 After setting up

- ▶ Take off the protective film from the exterior of the appliance.
- ▶ Take off the protective film from the trim panels.
- ▶ Take off the protective film from the trim panels and drawer fronts.
- ▶ Take off the protective film from the stainless steel rear panel.
- ▶ Remove all transport safety components.
- ▶ Clean the appliance. (see operating instructions)
- ▶ Note the type (model, number), appliance designation, appliance/serial number, purchase date and dealer's address.

## 12 Disposing of packaging



### WARNING

Danger of suffocation due to packing material and plastic film!

- ▶ Do not allow children to play with packing material.

The packaging is made of recyclable materials:

- corrugated board/cardboard
- expanded polystyrene parts
- polythene bags and sheets
- polypropylene straps
- nailed wooden frame with polyethylene panel\*

- Take the packaging material to an official collecting point.

## 13 What the symbols mean

|  |                                                                                                                                  |
|--|----------------------------------------------------------------------------------------------------------------------------------|
|  | Risk of injury here! Follow the safety notes!                                                                                    |
|  | These instructions apply to a range of models. Follow this step only if it applies to your appliance.                            |
|  | To install, please follow the detailed description in the Guide.                                                                 |
|  | This section applies either to a single-door appliance or a double-door appliance.                                               |
|  | Choose one of the options: Appliance with right-hinged door or appliance with left-hinged door.                                  |
|  | Installation step required if your model has IceMaker and/or InfinitySpring.                                                     |
|  | Just loosen the screws or tighten them slightly.                                                                                 |
|  | Tighten the screws.                                                                                                              |
|  | Check to see if the next step applies for your model.                                                                            |
|  | Check the correct assembly/seat of the components used.                                                                          |
|  | Measure the specified measurement and adjust if necessary.                                                                       |
|  | Tool for assembly: Metre rule                                                                                                    |
|  | Tool for assembly: Cordless screwdriver and attachments<br>A lengthwise bit insert is recommended for good access to the screws. |

|  |                                                           |
|--|-----------------------------------------------------------|
|  | Tool for assembly: Spirit level                           |
|  | Tool for assembly: Size 7 and size 10 spanners            |
|  | Two people are required for this step.                    |
|  | Carry out this step at the marked place on the appliance. |
|  | Aids for assembly: String                                 |
|  | Aids for assembly: Square                                 |
|  | Aids for assembly: Screwdriver                            |
|  | Aids for assembly: Scissors                               |
|  | Aids for assembly: Non-permanent marker pen               |
|  | Accessory kit: Remove components                          |
|  | Dispose of components that are no longer needed.          |

## 14 Door hinge change

### Tools

# Door hinge change




Fig. 5

## NOTICE

Risk of damage due to door collision!

Damage to the appliances with Side-by-Side positioning. If you set up two appliances next to each other in a specific Side-by-Side arrangement, the door hinge of both appliances is preset at the factory.

► Side-by-Side positioning: Do not change the door hinge.

These sections apply for appliances **without a soft stop mechanism**:

- ☐ For appliances **without** a soft stop mechanism
- ☐ For all appliances




Fig. 6

Remember the reading direction.

## 14.1 Removing the door

### Note

► Remove any food from the door racks before removing the door, so that no food falls out.

**For appliances without a soft stop:**




Fig. 7

► Open the door.

## NOTICE

Risk of damage!

If the door seal is damaged, the door may fail to close properly and the cooling will be inadequate.

► Do not damage the door seal with the screwdriver!

- Remove the outer cover Fig. 7 (1).
- Disengage and remove the swap bearing block cover Fig. 7 (2).
- Use a slotted screwdriver to unlatch the trim Fig. 7 (3) and swing it to the side.

**For all appliances:**




Fig. 8



## CAUTION

Risk of injury if the door tips!  
 ► Take good hold of the door.  
 ► Set down the door carefully.

► Lift the door and place it to one side.

## 14.2 Moving the upper bearing parts to the other side

For all appliances:



## WARNING

Danger of injury due to door falling out!  
 If the bearing parts are not screwed on tightly enough, the door may fall out. This can result in serious injuries. In addition, the door may not close with the result that the appliance does not cool properly.

► Screw on the bearing brackets/bearing pins tightly with 4 Nm.  
 ► Check all screws and retighten them if necessary.




Fig. 9

- Use screwdriver to unscrew both screws.
- Lift up and remove the bearing bracket.




Fig. 10

- Remove the cover Fig. 10 (1) from above towards the front.
- Turn the cover Fig. 10 (2) by 180° and attach to the other side from the right.
- Engage the cover Fig. 10 (3).
- Place the top swap bearing block Fig. 10 (4).
- Use screwdriver Fig. 10 (5) to place the screw and tighten it.
- Use screwdriver Fig. 10 (6) to place the screw and tighten it.

# Door hinge change

## 14.3 Moving the lower bearing parts to the other side

For all appliances:



### WARNING

Danger of injury due to door falling out!

If the bearing parts are not screwed on tightly enough, the door may fall out. This can result in serious injuries. In addition, the door may not close with the result that the appliance does not cool properly.

- ▶ Screw on the bearing brackets/bearing pins tightly with 4 Nm.
- ▶ Check all screws and retighten them if necessary.




Fig. 11

- ▶ Pull the bearing bolt Fig. 11 (1) out upwards completely.
- ▶ Use screwdriver to unscrew the screws Fig. 11 (2) and remove the swap bearing block.

For appliances without a soft stop:




Fig. 12

- ▶ Use screwdriver to loosen the screw Fig. 12 (1).
- ▶ Lift the door closing aid Fig. 12 (2) and turn 90° clockwise in the hole.
- ▶ Tighten screw Fig. 12 (3) with screwdriver.

For all appliances:




Fig. 13

- ▶ Remove cover Fig. 13 (1).




Fig. 14

- ▶ Unscrew the plate Fig. 14 (1), move it to the other side and screw it back on.




Fig. 15

- ▶ Place the swap bearing block on the other side and use a screwdriver to screw it on. Start with the screw Fig. 15 (2) at the bottom in the middle.
- ▶ Tighten screw Fig. 15 (3) and screw Fig. 15 (4).
- ▶ Insert the bearing bolt Fig. 15 (5) completely. Ensure that the latching cam is pointing towards the rear.




Fig. 16

- Re-attach the cover Fig. 16 (1) to the other side.

## 14.4 Moving the door bearing parts to the other side

For appliances without a soft stop:



### WARNING

Danger of injury due to door falling out!

If the bearing parts are not screwed on tightly enough, the door may fall out. This can result in serious injuries. In addition, the door may not close with the result that the appliance does not cool properly.

- Screw on the bearing brackets/bearing pins tightly with 4 Nm.
- Check all screws and retighten them if necessary.




Fig. 17

- The bottom side of door faces upwards: Turn the door.
- Use a slotted screwdriver to push the tab Fig. 17 (1) downwards.
- Pull the closing hook Fig. 17 (2) out of the guide.
- Insert the closing hook Fig. 17 (3) into the guide on the other side.
- The upper side of door faces upwards: Turn the door.

## 14.5 Moving the handles to the other side

For all appliances:




Fig. 18

- Remove the cover Fig. 18 (1).
- Unscrew screws Fig. 18 (2) with screwdriver.
- Remove the handle Fig. 18 (3).
- Use a slotted screwdriver to lift the side plug Fig. 18 (4) carefully and pull it out.
- Re-insert the plug Fig. 18 (5) on the other side.

## Door hinge change




Fig. 19

- ▶ Place the handle Fig. 19 (1) on the opposite side.
- ▷ The screw holes must be exactly above each other.
- ▶ Tighten screws Fig. 19 (2) with screwdriver.
- ▶ Place the covers Fig. 19 (3) on the side and push them on.
- ▷ Ensure that they latch into place.

## 14.6 Fitting the door

For all appliances:




Fig. 20

- ▶ Place the door on the lower bearing pins.
- ▶ Align the top of the door with opening in the bearing bracket. Fig. 20 (1)
- ▶ Insert the bolt Fig. 20 (2) and use screwdriver to tighten it.
- ▶ Fit the safety cover Fig. 20 (3) to secure the door: Insert the safety cover and check whether the door is resting on it. Otherwise, insert the bolt fully.
- ▶ Insert the plug Fig. 20 (4).

## 14.7 Aligning the door

For all appliances:



### WARNING

Danger of injury due to door falling out!

If the bearing parts are not screwed on tightly enough, the door may fall out. This can result in serious injuries. In addition, the door may not close with the result that the appliance does not cool properly.

- ▶ Screw the bearing brackets on firmly with 4 Nm.
- ▶ Check all screws and retighten them if necessary.
- ▶ Align the doors flush with the appliance housing using the two slots in the bearing bracket if needed. To do this undo the middle screw in the bottom bearing bracket with the T20 tool supplied. Undo the remaining screws a little with the T20 tool or with a T20 screwdriver and align using the slotted holes.
- ▶ Prop up the door: Take off the adjustable foot on the bearing bracket using the open-ended wrench SW10 until it comes into contact with the floor, then turn an additional 90°.

## 14.8 Fitting the covers

For appliances without a soft stop:




Fig. 21

The door is open 90°.

- ▶ Put the swap bearing block cover Fig. 21 (1) on and engage, push apart carefully if required.
- ▶ Place the trim Fig. 21 (2) on the side and engage.




Fig. 22

- ▶ Push the outer cover Fig. 22 (1) on.
- ▶ Close the upper door Fig. 22 (2).

## 15 Connecting the appliance to the power supply



### WARNING

Danger of electric shock and injury due to damaged appliance or damaged mains cable!

Danger of cuts and fatal injuries. If the appliance or the mains cable is damaged during transport, you may be electrocuted. You could also cut yourself on damaged parts of the appliance housing.

- ▶ Check the appliance and the mains cable for damage after transport.
- ▶ Never put the appliance into operation if the appliance or the mains cable are damaged.
- ▶ Contact Customer Service.

You can connect your appliance to the mains using the power cable supplied separately. The mains power cable has an appliance coupler at one end and a mains plug at the other end.

Connect your appliance to the mains using the power cable included. The power cable has a mains plug at the free end.

Make sure that the following requirements are fulfilled:

- The appliance and power cable are undamaged.
- The appliance is set up in accordance with the regulations. (see 8 Mounting wall spacers)
- Requirements for the electrical connection are met. (see 2 Installation conditions)
- Dimensions for connection in accordance with regulations are known and observed. (see 5 Connection dimensions for the power supply)
- Mains voltage and frequency correspond to the specifications on the type plate.
- The socket is earthed according to the regulations and fused.
- The fuse tripping current is between 10 A and 16 A.
- The socket is easily accessible and is not behind the appliance. (see 5 Connection dimensions for the power supply)

### NOTICE

Danger of damage to incorrect operation!

Damage to the electrical components of the appliance.

- ▶ Only use the supplied mains cable.




### WARNING

Danger of fire due to incorrect connection!

Burns.

Damage to the appliance.

- ▶ Do not use an extension cable.
- ▶ Do not use distributor blocks.



### NOTICE

Danger of damage to incorrect connection!

Damage to the appliance.

- ▶ Do not connect the appliance to a stand-alone inverter, e.g. solar power systems and petrol generators.

- ▶ Connect the mains cable plug to the power supply. Ensure that the plug is tightly in the socket.
- ▶ Connect the mains cable plug to the power supply. Ensure that the plug is tightly in the socket.
- ▷ The Liebherr logo appears in the display.
- ▷ The display switches to the standby symbol.
- ▷ If no action occurs within 60 seconds: The standby symbol fades or disappears.
- ▷ The appliance is connected. For information regarding first use, see the following section or the operating instructions.



[home.liebherr.com/fridge-manuals](https://home.liebherr.com/fridge-manuals)

**EN** freezer

Issue date: 20250325

**Part number index: 7088544-01**

Liebherr-Hausgeräte Ochsenhausen GmbH  
Memminger Straße 77-79  
88416 Ochsenhausen  
Deutschland



## Installation Guide

Quality, Design and Innovation



[home.liebherr.com/fridge-manuals](http://home.liebherr.com/fridge-manuals)




# LIEBHERR

# General safety instructions

## Contents

|      |                                                       |    |
|------|-------------------------------------------------------|----|
| 1    | General safety instructions.....                      | 2  |
| 2    | Installation conditions.....                          | 3  |
| 2.1  | Location.....                                         | 3  |
| 2.2  | Building the appliance into kitchen units.....        | 3  |
| 2.3  | Installing multiple appliances.....                   | 4  |
| 2.4  | Mains connection.....                                 | 4  |
| 3    | Installation dimensions.....                          | 4  |
| 4    | Ventilation requirements.....                         | 4  |
| 5    | Transporting appliance.....                           | 5  |
| 6    | Unpacking the appliance.....                          | 5  |
| 7    | Mounting wall spacers.....                            | 5  |
| 8    | Setting up the appliance.....                         | 5  |
| 9    | Setting up the appliance so that it is level.....     | 5  |
| 10   | After setting up.....                                 | 5  |
| 11   | Disposing of packaging.....                           | 5  |
| 12   | What the symbols mean.....                            | 6  |
| 13   | Door hinge change.....                                | 6  |
| 13.1 | Removing the door.....                                | 7  |
| 13.2 | Moving the upper bearing parts to the other side..... | 8  |
| 13.3 | Moving the lower bearing parts to the other side..... | 9  |
| 13.4 | Moving the door bearing parts to the other side.....  | 9  |
| 13.5 | Moving the handles to the other side.....             | 10 |
| 13.6 | Fitting the door.....                                 | 11 |
| 13.7 | Aligning the door.....                                | 11 |
| 13.8 | Fitting the covers.....                               | 11 |
| 14   | Connecting device.....                                | 12 |


The manufacturer is continually working on the further development of all types and models. Please be aware that we reserve the right to make changes to the shape, equipment and technology.

| Symbol | Explanation                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
|--------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|        | <b>Read instructions</b><br>Please read the information in these instructions carefully to understand all of the benefits of your new appliance.                                                                                                                                                                                                                                                                                                                       |
|        | <b>Additional information on the Internet</b><br>The digital manual with additional information can be found via the QR code on the front of the manual or by entering the service number at <a href="http://home.liebherr.com/fridge-manuals">home.liebherr.com/fridge-manuals</a> .<br>The service number can be found on the serial tag:<br><br><i>Fig. Example illustration</i> |
|        | <b>Check appliance</b><br>Check all parts for transport damage. If you have any complaints, please contact your agent or customer service.                                                                                                                                                                                                                                                                                                                             |

| Symbol | Explanation                                                                                                                                                                   |
|--------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|        | <b>Differences</b><br>These instructions apply to a range of models, so differences are possible. Sections that apply to certain models only are marked with an asterisk (*). |
|        | <b>Instructions and results</b><br>Instructions are marked with a ►.<br>Results are marked with a ▷.                                                                          |
|        | <b>Videos</b><br>Videos about the appliances are available on the YouTube channels of Liebherr-Hausgeräte.                                                                    |

## 1 General safety instructions

- Please keep this assembly manual in a safe place so you can refer back to it at any time.
- If you pass the appliance on, please hand this assembly manual to the next user.
- Read this assembly manual carefully before installation and use to ensure safe and correct use of the appliance. Follow the instructions, safety instructions and warning messages included at all times. They are important for ensuring you can operate and install the appliance safely and without any problems.
- First read the general safety instructions in the "General safety instructions" section of the **operating instructions**, which accompany these installation instructions, and follow them. If you cannot find the **operating instructions**, you can download the **operating instructions** from the internet by entering the service number at [home.liebherr.com/fridge-manuals](http://home.liebherr.com/fridge-manuals). The service number can be found on the serial



tag:

- **Observe the warning messages and other detailed information in the other sections when installing the appliance:**

|  |         |                                                                                                                     |
|--|---------|---------------------------------------------------------------------------------------------------------------------|
|  | DANGER  | identifies a situation involving direct danger which, if not obviated, may result in death or severe bodily injury. |
|  | WARNING | identifies a dangerous situation which, if not obviated, may result in death or severe bodily injury.               |

|                                                                                   |         |                                                                                                       |
|-----------------------------------------------------------------------------------|---------|-------------------------------------------------------------------------------------------------------|
|  | CAUTION | identifies a dangerous situation which, if not obviated, may result in minor or medium bodily injury. |
|                                                                                   | NOTICE  | identifies a dangerous situation which, if not obviated, may result in damage to property.            |
|                                                                                   | Note    | identifies useful instructions and tips.                                                              |

## 2 Installation conditions



### WARNING

Fire hazard due to dampness!

If live parts or the mains lead become damp this may cause short circuits.

- The appliance is designed for use in enclosed areas. Do not operate the appliance outdoors or in areas where it is exposed to splash water or damp conditions.

Intended use

- Install and use the appliance in indoor spaces only.

### 2.1 Location



### WARNING

Leaking coolant and oil!

Fire. The coolant contained in the appliance is eco-friendly, but also flammable. The oil contained in the appliance is flammable. Escaping coolant and oil can ignite if the concentration is high enough and in contact with an external heat source.

- Do not damage the pipelines of the coolant circuit and the compressor.

- If the appliance is installed in a very humid environment, condensation can build up on the outside of the unit. Always ensure good airflow and ventilation in the installation location.
- The more refrigerant there is in the appliance, the larger the space that it is installed in must be. If the space is too small, any leak may create a flammable mixture of gas and air. For every 8 g of refrigerant, the installation space must be at least 1 m<sup>3</sup>. Information regarding the coolant can be found on the serial tag inside the appliance.

#### 2.1.1 Supporting floor

- The floor of the installation site must be horizontal and even.
- The surface supporting the appliance must be at the same level as the surrounding floor.

#### 2.1.2 Positioning

- Do not place the appliance in direct sunlight or near radiators or similar sources of heat.
- You can place the appliance directly next to an oven.
- If the appliance is placed directly next to an oven, the energy consumption may increase slightly. This is dependent on the service life and usage intensity of the oven.
- Install the appliance with the rear panel up against the wall and always use the supplied wall spacers (see below).

## 2.2 Building the appliance into kitchen units

You can install kitchen cabinets around the appliance.




Fig. 1

- (1) Top cabinet
- (2) Appliance
- (3) Kitchen cabinet

- (4) Wall

- (A) Appliance depth

- (B) Door depth
- (C) Ventilation cross section
- (D) Distance to the back of the appliance
- (E) Distance to the side of the appliance

You can place the appliance directly beside the kitchen cabinet Fig. 1 (3).

There must be a ventilation shaft at the depth Fig. 1 (D) of the back of the top cupboard over the entire width of the top cupboard.

The ventilation cross-section Fig. 1 (C) must be maintained under the ceiling.

If the appliance is set up with the hinges next to a wall Fig. 1 (4), the distance between the appliance and the wall must be at least 57 mm. This is how far the handle protrudes when the door is open.

In order to be able to fully open the door, the appliance must protrude by the depth of the door Fig. 1 (B) from the front of the kitchen cabinet. The appliance may protrude further depending on the depth of the kitchen cabinets Fig. 1 (3) and whether wall spacers are used.

| Appliances with lever handle: |                          |
|-------------------------------|--------------------------|
| A                             | 675 mm *                 |
| B                             | 75 mm                    |
| C                             | Min. 300 cm <sup>2</sup> |
| D                             | Min. 50 mm               |
| E                             | Min. 57 mm               |

## Installation dimensions

\* The use of wall spacers increases the dimensions by 15 mm (see 7 Mounting wall spacers).

Ensure that the following conditions are met:

- Recess dimensions are adhered to.
- Ventilation requirements are complied with (see 4 Ventilation requirements).

### 2.3 Installing multiple appliances

#### NOTICE

Risk of damage due to condensate!

- Do not install the appliance directly alongside a further refrigerator/freezer.

These appliances are designed for a variety of installation options. Combine appliances only if the appliance is suitable. The following table shows the installation options by model:


| Installation option                                                                                                  | Model                                                                                                                      |
|----------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------|
| Single                                                                                                               | All models                                                                                                                 |
| Side-by-side (SBS)                                                                                                   | Model names starting with <b>S...</b>                                                                                      |
| Side-by-side with a space of 70 mm between the appliances<br>Otherwise condensation will build up between the units. | All models without side wall heating<br> |

Fig. 2

Assemble the appliances together, following their specific installation instructions.

### 2.4 Mains connection



#### WARNING

Danger of fire due to incorrect positioning!

If the mains cable or plug touches the back of the appliance, the vibration can damage the mains cable or the plug resulting in a short circuit.

- Make sure the mains cable is not trapped under the appliance when you position the appliance.
- Stand the appliance so that it is not touched by connectors or main cables.
- Do not connect any appliances to sockets in the area of the back of the appliance.
- Do **not** place and operate multi-sockets/power distributors and other electronic devices (such as halogen transformers) at the back of the appliances.

## 3 Installation dimensions




Fig. 3

|               | h    | a   | b    | b'   | c   | c'  | d     | d'   |
|---------------|------|-----|------|------|-----|-----|-------|------|
| R.. 42..      | 1255 | 597 | 675* | —    | 609 | —   | 1217* | —    |
| R... 46..     | 1455 | 597 | 675* | —    | 609 | —   | 1217* | —    |
| Kf 46Z00      | 1455 | 597 | 675* | —    | 609 | —   | 1217* | —    |
| R... 50..     | 1655 | 597 | 675* | —    | 609 | —   | 1217* | —    |
| R(B)... 52..  | 1855 | 597 | 675* | —    | 609 | —   | 1217* | —    |
| KB 52Vc20     | 1855 | 597 | 675* | —    | 609 | —   | 1217* | —    |
| Ksfe 52Z20    | 1855 | 597 | 675* | —    | 609 | —   | 1217* | —    |
| SR(B)... 5220 | 1855 | 597 | 675* | —    | 609 | —   | 1217* | —    |
| SR(B)sdh 5220 | 1855 | 597 | 675* | 719* | 609 | 654 | 1217* | 1222 |
| SR... 5230    | 1855 | 597 | 675* | 719* | 609 | 654 | 1215* | 1222 |
| RD... 52..    | 1855 | 597 | 675* | —    | 609 | —   | 1217* | —    |

\* For appliances with supplied wall spacers, the dimensions must be increased by 15 mm (see 7 Mounting wall spacers).

## 4 Ventilation requirements

#### NOTICE

Danger of overheating due to insufficient air ventilation!

The compressor may be damaged if there is insufficient air ventilation.

- Take care to ensure adequate air ventilation.
- Observe the ventilation requirements.

If the appliance is integrated into a fitted kitchen, the following ventilation requirements must be adhered to:

- There are spacer fins at the back of the appliance to provide sufficient ventilation. Make sure that these are not positioned in recesses or openings.
- As a rule, the larger the ventilation space the more efficiently the appliance can run.

## 5 Transporting appliance

### Note when transporting the appliance:

- ▶ Transport the appliance upright.
- ▶ Use two people to transport the appliance.

### During first use:

- ▶ Transport the appliance packaged.

### When transporting appliances after initial commissioning (e. g. moving or cleaning):

- ▶ Empty the appliance.
- ▶ Secure the door against unintentional opening.

## 6 Unpacking the appliance

Before you connect the appliance, report any damage immediately to the delivery company.


- ▶ Check the appliance and the packaging for damage during transport. Contact the supplier immediately if you suspect any level of damage.
- ▶ Remove all materials from the back or the side walls of the appliance that may prevent proper installation or ventilation.
- ▶ Remove all protective films from the appliance. Do not use sharp or pointed objects for this.
- ▶ Take the power cable from the rear of the appliance. Remove the cable brackets when you do this, otherwise there will be noise caused by vibrations!

## 7 Mounting wall spacers

With wall spacers, your device achieves the declared energy consumption and no condensation forms in high ambient humidity. The device is fully functional without the spacer brackets, but its energy consumption will be slightly higher.

If you insert the wall spacers, then the device depth increases by approx. 15 mm.

- ▶ Appliance with supplied wall spacers: Fit wall spacers on the rear of the appliance at the bottom left and right.



## 8 Setting up the appliance



### CAUTION

Risk of injury due to heavy appliance!

- ▶ Have two people transport the appliance to its installation site.



### WARNING

Danger of injury and damage due to the appliance being unstable!

The appliance can topple over.

- ▶ Secure the appliance as described in the instructions.



### WARNING

Fire hazard and danger of damage!

- ▶ Do not place appliances emitting heat e.g. microwaves, toasters etc. on the appliance!

Ensure that the following conditions are met:

- ☐ Only move the device when it is not loaded.
- ☐ Only set up the appliance when someone is available to help.

## 9 Setting up the appliance so that it is level




### CAUTION

Risk of injury or damage from the appliance tipping or the door falling open!

If the additional adjustable foot on the base support is not correctly positioned on the floor, there is a risk of the door falling open or the appliance tipping. This can lead to injury or property damage.

- ▶ Unscrew the additional adjustable foot on the support until it reaches the floor.
- ▶ Then turn it another 90°.

- ▶ Set up the appliance so that it is level using the supplied open-ended wrench to turn the adjustable feet (A) and a spirit level.
- ▶ Then prop up the door: Turn the adjustable foot (B) on the bearing bracket until it comes into contact with the floor, then turn an additional 90°.



- ▶ Then prop up the door: Turn the adjustable foot on the bearing bracket (B) using the open-ended wrench SW10 until it comes into contact with the floor, then turn an additional 90°.

## 10 After setting up

- ▶ Take off the protective film from the exterior of the appliance.
- ▶ Take off the protective film from the trim panels.
- ▶ Take off the protective film from the trim panels and drawer fronts.
- ▶ Take off the protective film from the stainless steel rear panel.
- ▶ Remove all transport safety components.
- ▶ Clean the appliance. (see operating instructions)
- ▶ Note the type (model, number), appliance designation, appliance/serial number, purchase date and dealer's address.

## 11 Disposing of packaging



### WARNING

Danger of suffocation due to packing material and plastic film!

- ▶ Do not allow children to play with packing material.

## What the symbols mean

The packaging is made of recyclable materials:

- corrugated board/cardboard
- expanded polystyrene parts
- polythene bags and sheets
- polypropylene straps
- nailed wooden frame with polyethylene panel\*

► Take the packaging material to an official collecting point.

## 12 What the symbols mean

|  |                                                                                                       |
|--|-------------------------------------------------------------------------------------------------------|
|  | Risk of injury here! Follow the safety notes!                                                         |
|  | These instructions apply to a range of models. Follow this step only if it applies to your appliance. |
|  | To install, please follow the detailed description in the Guide.                                      |
|  | This section applies either to a single-door appliance or a double-door appliance.                    |
|  | Choose one of the options: Appliance with right-hinged door or appliance with left-hinged door.       |
|  | Installation step required if your model has IceMaker and/or InfinitySpring.                          |
|  | Just loosen the screws or tighten them slightly.                                                      |
|  | Tighten the screws.                                                                                   |
|  | Check to see if the next step applies for your model.                                                 |
|  | Check the correct assembly/seat of the components used.                                               |
|  | Measure the specified measurement and adjust if necessary.                                            |
|  | Tool for assembly: Metre rule                                                                         |

|  |                                                                       |
|--|-----------------------------------------------------------------------|
|  | Tool for assembly: Cordless screwdriver and attachments               |
|  | A lengthwise bit insert is recommended for good access to the screws. |
|  | Tool for assembly: Spirit level                                       |
|  | Tool for assembly: Size 7 and size 10 spanners                        |
|  | Two people are required for this step.                                |
|  | Carry out this step at the marked place on the appliance.             |
|  | Aids for assembly: String                                             |
|  | Aids for assembly: Square                                             |
|  | Aids for assembly: Screwdriver                                        |
|  | Aids for assembly: Scissors                                           |
|  | Aids for assembly: Non-permanent marker pen                           |
|  | Accessory kit: Remove components                                      |
|  | Dispose of components that are no longer needed.                      |

## 13 Door hinge change

Tools



Fig. 4



## WARNING

Danger of injury due to door falling out!

If the bearing parts are not screwed on tightly enough, the door may fall out. This can result in serious injuries. In addition, the door may not close with the result that the appliance does not cool properly.

- Screw on the bearing brackets/bearing pins tightly with 4 Nm.
- Check all screws and retighten them if necessary.

These sections apply for appliances **without a soft stop mechanism**:

- ☐ For appliances **without** a soft stop mechanism
- ☐ For all appliances

## NOTICE

Risk of condensation damage for Side-by-Side appliances!\*  
Certain appliances can be set up as Side-by-Side combinations (two appliances next to each other).

If your appliance is a **Side-by-Side (SBS) appliance**:

- Set up the SBS combination in accordance with the enclosed document.

If the **positioning of the devices is stipulated**:

- Do not change the door hinges over.




Fig. 5

Remember the reading direction.

## 13.1 Removing the door

### Note

- Remove any food from the door racks before removing the door, so that no food falls out.

**For appliances without a soft stop:**




Fig. 6

- Open the door.

## NOTICE

Risk of damage!

If the door seal is damaged, the door may fail to close properly and the cooling will be inadequate.

- Do not damage the door seal with the screwdriver!

- Remove the outer cover. *Fig. 6 (1)*
- Disengage and release the bearing bracket cover. Remove the bearing bracket cover. *Fig. 6 (2)*
- Unlatch the panel with a slotted screwdriver and swivel it to one side. *Fig. 6 (3)*

**For all appliances:**

## Door hinge change




Fig. 7



### CAUTION

Risk of injury if the door tips!

- Take good hold of the door.
- Set down the door carefully.

- Carefully remove the protective cover. Fig. 7 (1)
- Undo the bolt a little with a T15 screwdriver. Fig. 7 (2)
- Hold the door and remove the bolts with your fingers. Fig. 7 (3)
- Pull the bearing bush out of the guide. Insert from the other side and latch into place. Fig. 7 (4)
- Lift the door and place it to one side.
- Carefully lift the plugs out of the door bearing bush with a slotted screwdriver and pull them out. Fig. 7 (5)

## 13.2 Moving the upper bearing parts to the other side

For all appliances:




Fig. 8

- Remove both screws with a T20 screwdriver.
- Lift up and remove the bearing bracket.




Fig. 9

- Take off the cover from above to the front. Fig. 9 (1)
- Rotate the cover 180° and clip onto the other side from the right. Fig. 9 (2)
- Latch the cover into place. Fig. 9 (3)
- Position the upper bearing bracket. Fig. 9 (4)
- Insert the screw with a T20 screwdriver and tighten it. Fig. 9 (5)
- Insert the screw with a T20 screwdriver and tighten it. Fig. 9 (6)

## 13.3 Moving the lower bearing parts to the other side

For all appliances:




Fig. 10

- Lift the bearing pin completely upward and pull it out. Fig. 10 (1)
- Take out the screws with a T20 screwdriver and take off the bearing bracket. Fig. 10 (2)

For appliances without a soft stop:




Fig. 11

- Loosen the screw using a T25 screwdriver. Fig. 11 (1)
- Lift the door closing aid and turn it 90° to the right in the hole. Fig. 11 (2)
- Tighten the screw using a T25 screwdriver. Fig. 11 (3)

For all appliances:




Fig. 12

- Remove the cover. Fig. 12 (1)




Fig. 13

- Place the bearing bracket on the other side and screw it on with a T20 screwdriver. Start with screw 2 at the bottom in the middle. Fig. 13 (2)
- Screw in screws 3 and 4 tightly. Fig. 13 (3,4)
- Insert the bearing pin completely. Make sure that the latching lug is pointing to the rear. Fig. 13 (5)




Fig. 14

- Put the cover back on the other side. Fig. 14 (1)

## 13.4 Moving the door bearing parts to the other side

For appliances without a soft stop:

## Door hinge change




Fig. 15

- The bottom side of door faces upwards: Turn the door.
- Push the lug downwards with a slotted screwdriver. Fig. 15 (1)
- Pull the door latch out of the guide. Fig. 15 (2)
- Push the door latch into the guide on the other side. Fig. 15 (3)
- The upper side of door faces upwards: Turn the door.

### 13.5 Moving the handles to the other side

For all appliances:




Fig. 16

- Pull off the cover. Fig. 16 (1)
- Remove the screws with a T15 screwdriver. Fig. 16 (2)
- Take off the handle. Fig. 16 (3)
- Carefully lift up the side plugs with a slotted screwdriver and pull them out. Fig. 16 (4)
- Insert the plugs again on the other side. Fig. 16 (5)




Fig. 17

- ▶ Position the handle on the other side. Fig. 17 (1)
- ▷ The screw holes must be exactly above each other.
- ▶ Tighten the screw with a T15 screwdriver. Fig. 17 (2)
- ▶ Position the covers on the side and push them on. Fig. 17 (3)
- ▷ Ensure that they latch into place.

## 13.6 Fitting the door

For all appliances:




Fig. 18

- ▶ Place the door on the lower bearing pins.
- ▶ Align the top of the door with opening in the bearing bracket. Fig. 18 (1)
- ▶ Insert the bolt and tighten with a T15 screwdriver. Fig. 18 (2)

- ▶ Fit the protective cover to protect the door: Insert the protective cover and check that it is flush to the door. If not, insert the bolt fully. Fig. 18 (3)
- ▶ Insert the plugs. Fig. 18 (4)

## 13.7 Aligning the door

For all appliances:



### WARNING

Danger of injury due to door falling out!

If the bearing parts are not screwed on tightly enough, the door may fall out. This can result in serious injuries. In addition, the door may not close with the result that the appliance does not cool properly.

- ▶ Screw the bearing brackets on firmly with 4 Nm.
- ▶ Check all screws and retighten them if necessary.
- ▶ Align the doors flush with the appliance housing using the two slots in the bearing bracket if needed. To do this undo the middle screw in the bottom bearing bracket with the T20 tool supplied. Undo the remaining screws a little with the T20 tool or with a T20 screwdriver and align using the slotted holes.
- ▶ Prop up the door: Take off the adjustable foot on the bearing bracket using the open-ended wrench SW10 until it comes into contact with the floor, then turn an additional 90°.

## 13.8 Fitting the covers

For appliances without a soft stop:




Fig. 19

The door is open 90°.

- ▶ Position the bearing bracket and latch it in place. If necessary push it apart carefully. Fig. 19 (1)
- ▶ Position the panel on the side and latch into place. Fig. 19 (2)




Fig. 20

- ▶ Slide on the outer cover. Fig. 20 (1)
- ▶ Close the upper door. Fig. 20 (2)

## 14 Connecting device

---



### **WARNING**

Danger of fire due to incorrect connection!

Burns.

Damage to the appliance.

- ▶ Do not use an extension cable.
- ▶ Do not use distributor blocks.

---

### **NOTICE**

Danger of damage to incorrect connection!

Damage to the appliance.

- ▶ Do not connect the appliance to a stand-alone inverter, e.g. solar power systems and petrol generators.

---

### **Note**

Only use the supplied mains cable.

- ▶ A longer mains cable can be ordered from Customer Service.

Ensure that the following conditions are met:

- The type of current and voltage at the installation site match the information on the serial tag .
- The socket is earthed according to the regulations and fused.
- The fuse tripping current is between 10 and 16 A.
- The socket is easily accessible.
- The socket is not located behind the appliance but in areas a or b (*a, b, c*).
- ▶ Check the electrical connection.
- ▶ Insert the appliance plug (*G*) into the back of the appliance. Ensure that they latch into place.
- ▶ Connect the mains plug to the power supply.
- ▷ The Liebherr logo appears on the screen.
- ▷ The display switches to the standby symbol.





[home.liebherr.com/fridge-manuals](https://home.liebherr.com/fridge-manuals)

**EN** Refrigerator

Issue date: 20240425

**Part number index: 7086341-01**

Liebherr-Hausgeräte Marica EOOD  
Bezirk Plovdiv  
4202 Radinovo  
Bulgarien