



User Guide

Quality, Design and Innovation





# LIEBHERR

Cor	ntents
1 1.1 1.2 1.3 1.4 1.5 1.6	The appliance at a glance.3Delivered contents.3Overview of appliances and equipment.3SmartDevice.4Range of appliance use.4Conformity.4Spare parts.4
2	General safety instructions 4
<b>3</b> 3.1 3.2 3.3	Functionality of the Touch & Swipe display.7Navigation and symbol explanation
<b>4</b> 4.1 4.2	Start-up9Switching on appliance (first use)9Starting the IceMaker for the first time9
<b>5</b> 5.1 5.2 5.3	Storage9Information regarding storage9Freezer compartment9Storage times10
6	Energy saving 11
7 7.1 7.1.1 7.1.2 7.2 7.2.1	Use11Controls and displays11Status display11Display symbols11Appliance functions11Notes on the appliance functions11Switching appliance off and on12
• 1))	WiFi12
-18℃	Temperature13
°C/F	Temperature unit14
***	SuperFrost14
*\( \)	Start defrost cycle14
ŃΪ	PartyMode15
<b>W</b>	SabbathMode15
$\Box$	EnergySaver16
	IceMaker / MaxIce17
5	IceMaker water inflow18
	TubeClean18

-\o	Display Brightness	.19
	Door alarm	.19
×lp	Input lock	20
	Language	20
Service No: Nodel Index:	Appliance information	20
of the accessing	Software	. 21
Software	Demo mode	. 21
$\bigcirc$	Resetting to factory settings	.22
7.3 7.3.1 7.3.2 7.3.3 7.3.4	Messages Overview of warnings Ending warnings Overview of reminders	22 23 23
8 8.1 8.2 8.3 8.4 8.5 8.6	Equipment	24 26 28 29 29 29
<b>9</b> 9.1 9.2 9.3	Maintenance	30 30 33 33
10 10.1 10.2 10.3 10.4 10.5	Customer support	<b>34</b> 34 34 35 36 37
11	Decommissioning	37
<b>12</b> 12.1 12.2	Disposal  Preparing the appliance for disposal  Disposing of the appliance in an environmentally friendly manner	<b>37</b> 37 37
	ratulations on the purchase of your new ar With this purchase, you have chosen all	

Congratulations on the purchase of your new appliance. With this purchase, you have chosen all the advantages of the latest refrigeration technology, guaranteeing you a high-quality appliance with a long life span and high operating safety.

The equipment of your appliance gives you the highest level of day-to-day ease of operation.

Together we are making an active contribution to the conservation of our environment by purchasing this

appliance which is manufactured in an environmentally friendly process with the use of recyclable materials.

We hope you enjoy your new appliance.

The manufacturer is constantly working to improve all types and models. Therefore, please be aware that we reserve the right to make changes to the shape, equipment and technology.

Symbol Explanation

#### **Read instructions**

Please read the information in these instructions carefully to understand all of the benefits of your new appliance.



#### Additional information online

The digital manual with supplemental information can be found online by scanning the QR code on the front page of this manual or by entering the service number at home.liebherr.com/fridge-manuals.



#### Check appliance

Check all parts for transport damage. If you have any complaints, please contact your agent or customer service.



#### **Differences**

These instructions apply to a range of models, so there may be differences. Sections that apply to certain models only are indicated by an asterisk (\*).



#### Instructions and results

Instructions are marked with a  $\triangleright$ . Results are marked with a  $\triangleright$ .



#### Videos

Videos about the appliances are available on the YouTube channel of Liebherr-Hausgeräte.

#### Open-source licenses:

The appliance includes software components that make use of open-source licenses. You can find information on the open-source licenses to be used here: home.liebherr.com/open-source-licenses

These operating instructions apply to:

SIF 5181

# 1 The appliance at a glance

#### 1.1 Delivered contents

Check all parts for transport damage. If you have any complaints, please contact the retailer or customer service. (see 10.4 Customer Service)

Delivery contains the following parts:

- Integrated appliance
- Equipment (depending on your model)
- Installation parts (depending on your model)
- User Guide
- Installation Guide
- Warranty documents

# 1.2 Overview of appliances and equipment




Fig. 1 Example illustration

- (1) Controls
- (2) Lighting
- (3) NoFrost
- (4) Tilting drawer
- (5) Drawer
- (6) IceMaker

- (8) Nameplate
- (9) Freezer tray
- (10) Ice cube scoop
- (11) VarioSpace
- (12) Adjustable feet
- (13) Soft-closing mechanism

(7) IceTower

#### Note

▶ The shelves, drawers, and baskets are arranged for optimal energy efficiency in the factory configuration. However, changes to the arrangement within the given insertion options – for example the arrangement of shelves in the fridge compartment – have no effect on energy consumption.

# **General safety instructions**

#### 1.3 SmartDevice

SmartDevice is the networking solution for your freezer.

If your appliance is SmartDevice-enabled or compatible, you can quickly and easily connect your appliance to your WiFi. With the SmartDevice app, you can operate your appliance from a mobile device. Additional functions and setting options are available in the SmartDevice app.

SmartDeviceenabled appli ance:

ee- Your appliance is capable of being appli- a SmartDevice. To be able to connect your device to WiFi, you need to download the SmartDevice app.



More information about SmartDevice:

Downloading the SmartDevice app:

More information smartdevice.liebherr.com



After installing and configuring the SmartDevice app, you can connect your appliance to the WiFi using the SmartDevice app and the WiFi appliance function (see WiFi).

# 1.4 Range of appliance use

#### Normal use

This appliance is intended to be used in household and similar applications such as,

- staff kitchen areas in shops, offices and other working environments;
- farm houses and by clients in hotels, motels and other residential type environments;
- bed and breakfast type environments;
- catering and similar non-retail applications.

All other types of uses are not permitted.

#### Foreseeable misuse

The following uses are specifically prohibited:

- Storage and cooling of medication, blood plasma, laboratory preparations or similar substances and products in accordance with the CMDCAS and FDA 510(k)
- Use outdoors

- Use in moist areas exposed to the rain
- Use in outdoor areas with very high humidity
- Use in areas at risk of explosion

Incorrect appliance use can cause damage to the stored products or cause them to spoil.

#### Climate ratings

The appliance is set to operate within specific ambient temperature limits according to its climate rating The climate rating for your appliance is printed on the rating plate

#### Note

➤ To guarantee trouble-free operation, comply with the indicated ambient temperatures.

Climate rating	for ambient temperatures from
SN	10 °C (50 °F) to 32 °C (90 °F)
N	16 °C (61 °F) to 32 °C (90 °F)
ST	16 °C (61 °F) to 38 °C (100 °F)
Т	16 °C (61 °F) to 43 °C (109 °F)
SN-ST	10 °C (50 °F) to 38 °C (100 °F)
SN-T	10 °C (50 °F) to 43 °C (109 °F)

### 1.5 Conformity

The refrigerant circuit has been tested for leaks. When installed, the appliance complies with the applicable safety regulations and with the corresponding directives.

# 1.6 Spare parts

Spare parts for functional and storable parts of the equipment are available for 15 years.

# 2 General safety instructions

Please keep these operating instructions in a safe place so you can refer back to them at any time.

If you pass the appliance on, please hand these operating instructions to the new owner. Read and follow these instructions. They contain safety information which is important for safe and problem-free installation and operation. Always read and follow the safety information.

#### Dangers for the user:

- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance. Cleaning and user maintenance must not be performed by children unless they are supervised. Children between the ages of 3 and 8 may load and unload the appliance. Children under the age of 3 must be kept away from the appliance unless they are constantly supervised.
- IMPORTANT: The power plug must be easily accessible so that the appliance can be disconnected from the mains quickly in an emergency. It must not be behind the back of the appliance.
- The socket must be easily accessible so that the appliance can be disconnected quickly from the electricity in an emergency. It must not be located in the area behind the appliance.
- Always hold the appliance at the plug when disconnecting it from the household power.
   Do not pull on the cable.
- Disconnect the power plug or fuse if there is a malfunction.
- Do not damage the power cable. Do not operate the appliance with a faulty power cable. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard. For Plug and Play connections, the change may be carried out by the customer.
- Repairs and work on the appliance may only be carried out by Customer Service or other specifically trained qualified personnel.
- Only install, connect and dispose of the appliance in accordance with the instructions.
- Only operate the appliance after it has been installed.
- The manufacturer is not liable for damage arising from a defective fixed water connection.

#### Risk of fire:

- The refrigerant contained within the appliance (specifications on the identification plate) is environmentally friendly, but flammable. Leaking refrigerant can ignite.
  - WARNING: Do not damage the refrigerant circuit.
  - Do not handle ignition sources inside the appliance.
  - WARNING: Do not use electrical appliances inside the food storage compartments of the appliance, unless they are of the type recommended by the manufacturer (e.g. steam cleaning appliances, heating appliances, ice cream makers).
  - If refrigerant leaks: Remove naked flames or ignition sources located near the area of the leak. Ventilate the room well. Contact Customer Service.
- Do not operate the appliance near explosive gases.
- Do not store or use gasoline or other flammable gases and liquids near the appliance.
- Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance. You can recognize such spray cans by the printed list of contents or by a flame symbol. Any leaking gases can be ignited by electrical components.
- Alcoholic beverages or other containers holding alcohol must always be tightly sealed for storage purposes. Any leaking alcohol can be ignited by electrical components.

# Risk of falling or toppling over:

- WARNING: To avoid a hazard due to instability of the appliance, it must be fixed in accordance with the instructions.
- Do not stand on the base, drawers, doors etc. or use them as improper supports. This applies in particular to children.

#### Danger of poisoning:

- Do not consume spoiled food.
- WARNING: Connect to potable water supply only.
- Do not use any old or already premounted water supply lines.

# General safety instructions

# Danger of frostbite, feeling of numbness and pain:

 Avoid prolonged skin contact with cold surfaces or chilled/frozen food or take protective measures, e.g. wear gloves.

#### Risk of injury and damage:

- Hot steam may cause injuries. Do not use any electrical heating or steam cleaning equipment, naked flames or defrosting sprays for defrosting measures.
- WARNING: Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.
- Do not remove ice using sharp objects.
- WARNING: Keep clear of obstruction all ventilation openings in the appliance enclosure or in the structure for building-in.
- WARNING: Risk of child entrapment. Before you throw away your old refrigerator or freezer:
  - · Take off the doors.
  - Leave the shelves in place so that children may not easily climb inside.

## Risk of crushing:

 Do not hold onto the hinge when opening and closing the door. Fingers may become trapped.

### California Proposition 65

 WARNING: This product can expose you to chemicals including Diisononyl Phthalate (DINP), which is known to the State of California to cause cancer, and Di-isodecyl Phthalate (DIDP), which is known to the State of California to cause birth defects or other reproductive harm. For more information, go to www.P65Warnings.ca.gov

### **FCC Warning**

 Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

#### **FCC** information

 This appliance has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference from an installation in residential areas. This appliance generates, uses and can radiate radio-frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this appliance does cause harmful interference to radio or television reception, which can be determined by switching the appliance on and off, the user should try to correct the interference by one or more of the following measures:

- · Reorient or relocate the receiving antenna.
- Increase the distance between the appliance and receiver.
- Connect the appliance to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

#### **FCC Radio Frequency Exposure Statement**

- This appliance is found to comply with FCC radio frequency (RF) exposure limits set for an uncontrolled environment. This transmitter must not be set up or operated in conjunction with another antenna or another transmitter.
- This appliance should be installed and operated with a minimum space of 200 mm (7 7/8 in) between the antenna and your body. The user must follow the specific operating instructions to ensure compliance with RF exposure.

#### IC information

- This appliance has license-exempt transmitters/receivers, which comply with the license-exempt Radio Standards Specification (RSS) of Innovation, Science and Economic Development Canada. Operation is subject to the following two conditions:
  - This appliance may not cause interference.
  - This device must accept any interference, including interference that may cause undesired operation of the device.

#### IC Radio Frequency Exposure Statement

 This appliance meets the IC RSS-102 limits for radiation exposure, which were defined for an uncontrolled environment. This appliance should be installed and operated so that there is a minimum space of 200 mm (7 7/8 in) between the antenna and your body.

#### Symbols on the device:



The symbol may be located on the compressor. It refers to the oil in the compressor and refers to the following danger: Can be fatal if swallowed or inhaled. This notice only applies for recycling. There is no danger during normal operation.



**WARNING**: Risk of fire / flammable materials. The symbol is located on the compressor and indicates the danger from flammable materials. Do not remove the label.



This label or a similar one may be located on the rear of the appliance. This label indicates that there are vacuum insulation panels (VIP) or perlite panels in the door and/or housing. This notice only applies for recycling. Do not remove the label.

# Observe the warning messages and other detailed information in the other sections:

$\triangle$	DANGER	Indicates an immediately hazardous situation, which if not avoided, will result in death or serious injury.
À	WARNING	Indicates a hazardous situation, which if not avoided, could result in death or serious injury.
<u> </u>	CAUTION	Indicates a hazardous situation, which if not avoided, could result in minor or moderate injury.
	NOTICE	Indicates a hazardous situation, which if not avoided, could result in damage to property.
	Note	Indicates useful advice and tips.

# 3 Functionality of the Touch & Swipe display

You operate your appliance using the Touch & Swipe display. You select appliance functions in the Touch & Swipe display (hereafter referred to as display) by tapping them. If you do not perform any action on the display for 10 seconds, the display either jumps back to the higher-level menu or directly to the status display.

# 3.1 Navigation and symbol explanation

In the illustrations, different symbols are used to navigate the display. The following table describes these symbols.

Symbol	Description
	Briefly touch the display: Activates/deactivates function. Confirms selection. Opens submenu.
(38)	Touch the display for a specified time (e.g. 3 seconds): Activates/deactivates function or value.
	Swipe left or right: Navigate in the menu.
Back	Briefly touch the Back symbol: Jumps back one menu level.
Back (3s)	Press and hold the Back symbol for 3 seconds: Jumps back to the status display.
<b>→</b> ⊗	Arrow with clock: It takes more than 10 seconds for the following message to appear in the display.
<b>→ →</b> 2s 5s 10s	Arrow with a time indication:  It takes the specified amount of time until the following message appears in the display.

# Functionality of the Touch & Swipe display

Symbol	Description
={()}	"Open Settings menu" symbol: Navigates to the Settings menu and opens the settings menu. If necessary: Navigate to the desired function in the Settings menu. (see 3.2.1 Opening the Settings menu)
	"Open Advanced menu" symbol: Navigates to the Advanced menu and opens the advanced menu. If necessary: Navigate to the desired function in the Advanced menu. (see 3.2.2 Opening expanded menu)
No action for 10 seconds	If you do not perform any action on the display for 10 seconds, the display either jumps back to the higher-level menu or directly to the status display.
close it again.	If you open the door and immediately close it again, the display jumps directly back to the status display.

Note: Illustrations of the display are shown in the English version.

#### 3.2 Menus

The appliance functions are distributed over various menus:

Menu	Description
Main menu	When you switch the appliance on, you are automatically in the main menu.
	From here you can navigate to the most important appliance functions, to the Settings menu and to the Advanced menu.
€C} Settings	The Settings menu contains additional appliance functions for setting up your appliance.
Settings menu	
Advanced menu	The advanced menu contains special appliance functions for setting up your appliance. Access to the Advanced menu is protected by the numerical code <b>151</b> .

#### 3.2.1 Opening the Settings menu




Fig. 2 Example illustration

- ► Carry out action steps according to the illustration.
- Settings menu is open.
- ▶ If necessary: Navigate to the desired function.

### 3.2.2 Opening expanded menu



Fig. 3




Fig. 4 Example illustration, access with numerical code 151

- ► Carry out action steps according to the illustration.
- $\triangleright$  Expanded menu is open.
- ▶ If necessary: Navigate to the desired function.

# 3.3 Sleep mode

If you do not touch the display for 1 minute, the display switches to sleep mode. In sleep mode, the display brightness is dimmed.

# 3.3.1 Ending sleep mode

- ► Touch the display briefly with your finger.
- Sleep mode is ended.

# 4 Start-up

# 4.1 Switching on appliance (first use)

Make sure that the following requirements are fulfilled:

- ☐ The appliance is properly installed and connected according to the installation instructions.
- ☐ All adhesive strips, adhesive and protective films and transport locks are removed from inside and on the appliance.
- □ All marketing leaflets are removed from the drawers.□ You are familiar with the functionality of the
- ☐ You are familiar with the functionality of the Touch & Swipe display. (see 3 Functionality of the Touch & Swipe display)

# Switch on the appliance using the Touch & Swipe display.

- ► If the display is in sleep mode: Briefly touch the display.
- ► Carry out action steps according to the illustration.




Fig. 5 Example illustration

- > Status display appears.
- > The appliance cools to the temperature set at the factory.
- ➤ The appliance starts in demo mode (status display with DEMO appears): If the appliance starts in demo mode, you can deactivate demo mode within the next 5 minutes. (see Demo mode)

#### More information:

- Start the IceMaker for the first time. (see 4.2 Starting the IceMaker for the first time)
- Start the SmartDevice for the first time. (see 1.3 SmartDevice) and (see WiFi)

#### Note

The manufacturer recommends:

- ▶ Store frozen foods at -18 °C (-0 °F) or colder.
- ▶ Observe the notes on storing food. (see 5.1 Information regarding storage)

#### Note

Accessories can be purchased from the Liebherr Service Center. The address for your respective country can be found on the back of the instructions.

# 4.2 Starting the IceMaker for the first time

If your appliance is equipped with IceMaker, you must clean the IceMaker **before using it for the first time**.

Make sure that the following requirements are fulfilled:

- ☐ The water supply has been connected. See Installation Guide or mounting instructions.
- ☐ The appliance is properly installed and connected.
- ► Clean the IceMaker. (see 9.3.4 Cleaning the IceMaker)

# 5 Storage

# 5.1 Information regarding storage



#### WARNING

Danger of fire

▶ Do not use electrical appliances inside the food storage compartments of the appliance, unless they are of the type recommended by the manufacturer.

#### Note

Insufficient ventilation results in an increase in energy consumption and reduction of the refrigerating performance

Always keep the air slots unobstructed.

Observe the following specifications for storage:

- Package food properly.
- Package raw meat or fish in clean, closed containers. This will prevent meat or fish from touching or dripping onto other food.
- Leave space between goods to ensure good air circulation.
- Store food according to the instructions on the packaging.
- Always observe the best-before date indicated on the packaging.

#### Note

Failure to follow these guidelines can lead to foodstuffs spoiling.

# 5.2 Freezer compartment

Here, a dry, frosty storage climate is created at -18 °C (-0 °F). The frosty storage climate is suitable for storing frozen food for several months, for making ice cubes or freezing fresh food.

#### 5.2.1 Freezing food

#### Freezing quantity

The maximum amount of fresh food that you can freeze within 24 hours is specified on the type plate (see 10.5 Rating plate) under "Freezing capacity ... kg/24h."

To ensure that food quickly freezes through, adhere to the following quantities per package:

- Fruit and vegetables up to 1 kg (2.20 lb)
- Meat up to 2.5 kg (5.51 lb)

#### Freezing food using SuperFrost

Depending on the amount of food to be frozen, you can activate SuperFrost before freezing to reach lower freezing temperatures. (see SuperFrost)

► Activate SuperFrost if the amount of food you have to freeze is more than approx. 2 kg (4.41 lb).

The time at which you activate SuperFrost depends on the amount of food you have to freeze:

Freezing quantity	Time at which you should activate SuperFrost		
	Activate SuperFrost about 6 hours before freezing.		
freeze	You can place the food in the freezer as soon as the appliance automatically deactivates SuperFrost.		
Maximum amount of food	Activate SuperFrost about 24 hours before freezing.		
to freeze	You can place the food in the freezer as soon as the appliance automatically deactivates SuperFrost.		

#### Arranging your food properly



# CAUTION

Risk of injury from broken glass!

Bottles and cans with beverages can burst during freezing. This applies in particular to carbonated beverages.

► Only freeze bottles and cans with beverages if you have activated the BottleTimer function in the SmartDevice app.

Appliance height < 1220 mm (48 in)			
Freezing quantity	Arranging your food properly		
Small amount of food to freeze	Distribute packaged groceries throughout all drawers.  If possible, place groceries at the back of the drawer near the rear wall.		

Appliance height < 1220 mm (48 in)			
Freezing quantity	Arranging your food properly		
Maximum amount of food to freeze	Distribute packaged groceries throughout all drawers.  If possible, place groceries at the back of the drawer near the rear		
	wall.		

Appliance height ≥ 1220 mm (48 in)			
Freezing quantity	Arranging your food properly		
Small amount of food to freeze	Distribute packaged groceries throughout all drawers, but do not place any groceries in the top drawer.		
Maximum amount of food to freeze	Distribute packaged groceries throughout all drawers. If possible, place groceries at the back of the drawer near the rear wall.		

#### 5.2.2 Defrosting food



# WARNING

Danger of food poisoning!

- ▶ Do not re-freeze defrosted food.
- ▶ Use defrosted foodstuff as quickly as possible.

You can defrost food in several ways:

- In a refrigeration unit
- In the microwave
- In the oven/fan-assisted oven
- At room temperature
- ► Take out only as much food as necessary.

#### 5.2.3 Freezer tray

You can freeze berries, herbs, vegetables and other small frozen food in the freezer tray without it all freezing together. The frozen food is less likely to get squashed and subsequent portioning is easier.

▶ Distribute food on the freezer tray without packaging and well spaced out.

# 5.3 Storage times

The storage times given are guidelines

Food with a "use by" date must still be consumed by the date indicated on the package

Guidelines for storage periods for various foods			
Ice cream	at -18 (-0 °F)	°C	2 to 6 months

Guidelines for storage periods for various foods					
Sausage, ham	at -18 (-0 °F)	°C	2 to 3 months		
Bread, bakery products	at -18 (-0 °F)	°C	2 to 6 months		
Game, pork	at -18 (-0 °F)	°C	6 to 9 months		
Fish, fatty	at -18 (-0 °F)	°C	2 to 6 months		
Fish, lean	at -18 (-0 °F)	°C	6 to 8 months		
Cheese	at -18 (-0 °F)	°C	2 to 6 months		
Poultry, beef	at -18 (-0 °F)	°C	6 to 12 months		
Vegetables, fruit	at -18 (-0 °F)	°C	6 to 12 months		

# 6 Energy saving

- Always ensure good ventilation. Keep clear of obstruction all ventilation openings in the appliance enclosure or in the structure for building-in.
- Never block air slits in the fan.
- Do no install the appliance in an area with direct sunlight, next to a heating unit or similar.
- If you install the appliance directly next to an oven, its energy consumption may increase slightly. This depends on the service life and how often the oven is used.
- Energy consumption depends on installation conditions such as the ambient temperature (see 1.4 Range of appliance use). A warmer ambient temperature can increase the energy consumption.
- Avoid opening the appliance door for any longer then necessary
- The lower the temperature is set the higher the energy consumption.
- All food stored in the appliance should be well wrapped and covered. This prevents frost buildup.
- Insertion of warm foods: first let the food cool down to room temperature.

### 7 Use

### 7.1 Controls and displays

#### 7.1.1 Status display



Fig. 6 Status display shows the actual temperature.

#### (1) Temperature display

The status display shows the actual temperature and is the initial display. You can navigate from there to the functions and settings.

#### 7.1.2 Display symbols

The display symbols provide information about the current appliance status.

Symbol	Appliance status
()	<b>Standby</b> The appliance or temperature zone is turned off.
-18°	Flashing number Appliance is working. Temperature flashes until the set temperature is reached.
	Flashing symbol Appliance is working. Setting is made.

# 7.2 Appliance functions

# 7.2.1 Notes on the appliance functions

The appliance functions are set at the factory so that your appliance is fully functional.

Before you alter, activate or deactivate the appliance functions, make sure that the following requirements are met:

- ☐ You have read and understood the descriptions of how the display works. (see 3 Functionality of the Touch & Swipe display)
- ☐ You have familiarized yourself with the operating and display elements of your appliance.



# Switching appliance off and on

This function switches the entire appliance on and off.

#### Switching off the appliance

If you switch off the appliance, the settings that were made before remain stored.

Make sure that the following requirements are fulfilled:

☐ Handling instructions (see 11 Decommissioning) have been completed.



Fig. 7




Fig. 8

- ► Carry out action steps according to the illustration.
- ▶ Appliance is switched off.
- > Standby symbol appears in the display.
- Display turns black.

#### Switching on the appliance

If the display is in sleep mode:

► Briefly touch the display.




Fig. 9 Example illustration

- ► Carry out action steps according to the illustration. If the appliance starts in demo mode:
- ▶ Deactivate demo mode. (see Deactivating demo mode)
- ▶ Appliance is switched on.
- Previously made settings are re-established.
- ➤ The appliance cools to the set target temperature.



#### WiFi

Use this function to connect your appliance to WiFi. You can then operate it via the SmartDevice app on a mobile device. You can also use this function to disconnect or reset the WiFi connection.

More information on the SmartDevice: (see 1.3 SmartDevice)

#### Note

The SmartDevice function is not available in the following countries: Russia, Belarus, Kazakhstan.


#### Establishing the WiFi connection for the first time

Make sure that the following requirements are fulfilled:

- ☐ You have installed the SmartDevice app (see apps.home.liebherr.com).
- ☐ Registration in the SmartDevice app is completed.



Fig. 10



Fia. 11

- ► Carry out action steps according to the illustration.
- Connection is established.

#### Disconnecting from the WiFi



Fig. 12




Fig. 13

► Carry out action steps according to the illustration. 
▷ There is no connection.

#### Resetting the WiFi connection



Fig. 14




Fig. 15

- ► Carry out action steps according to the illustration.

#### Showing information about the WiFi connection



Fig. 16




Fig. 17

► Carry out action steps according to the illustration.

# -18<sub>°</sub> Temperature

Use this function to set the temperature.

The temperature depends on the following factors:

- How often the door is opened
- How long the door is open
- The room temperature of the installation site
- Type, temperature and amount of food

Freezer compartment	,	Recommended setting
-18⁻∘	-18 °C (-0 °F)	-18 °C (-0 °F)

#### Setting the temperature




Fig. 18 Example illustration

- ► Carry out action steps according to the illustration.



# Temperature unit

Use this function to set the temperature unit. You can set the temperature unit in either degrees Celsius or degrees Fahrenheit.

#### Setting the temperature unit



Fig. 19




Fig. 20 Example illustration: Switching between degrees Celsius or degrees Fahrenheit.

- Carry out action steps according to the illustration.
- > Temperature unit is set.



# \*\* SuperFrost

This function activates or deactivates SuperFrost. Activating SuperFrost the appliance increases the freezing capacity. This allows you to achieve lower freezer temperatures.

#### Application:

- Quickly freezing fresh food through to the core. This ensures that the nutrition value, look, and taste of the food is preserved.
- Increasing cold reserves in stored frozen food before defrosting the appliance.

If the function is active, the appliance operates at a higher output. As a result, the operating noise of the appliance may be temporarily louder, while energy consumption increases.

#### **Activating SuperFrost**

Make sure that the following requirements are fulfilled:

☐ The freezing volume and time for SuperFrost activation are taken into account. (see Freezing food using SuperFrost)



Fig. 21




Fig. 22

- ▶ Carry out action steps according to the illustration.
- ▶ Activating with the SmartDevice app.
- SuperFrost is activated.
- > Temperature display turns blue.

#### **Deactivating SuperFrost**

SuperFrost is automatically deactivated 56 to 72 hours depending on the volume of the stored food. However, you can also manually deactivate SuperFrost at any time:



Fig. 23



Fig. 24

- ► Carry out action steps according to the illustration.
- ▶ Deactivating with the SmartDevice app.
- SuperFrost is deactivated.
- > Appliance continues to run in normal operation.
- ➤ The appliance first cools to the set temperature.



### Start defrost cycle

Use this function to start the automatic defrost cycle manually if the defrost cycle does not start automatically in case of an error.

#### Starting the defrost cycle



Fig. 25




Fig. 26

- ► Carry out action steps according to the illustration.
- Defrost cycle has started: Symbol flashes until the defrost cycle is automatically completed.
- ▶ When the defrost cycle is completed: Appliance continues to run in normal operation.

#### Canceling the defrost cycle

The defrost cycle is automatically completed. However, you can also cancel the defrost cycle at any time during the defrosting:




Fig. 27

- ► Carry out action steps according to the illustration.
- Defrost cycle is canceled.
- ▶ Appliance continues to run in normal operation.



#### **PartyMode**

This function activates and deactivates PartyMode. PartyMode activates different functions that are useful for a party.

PartyMode activates the following functions:

- SuperFrost (see SuperFrost)
- IceMaker with MaxIce (see IceMaker / MaxIce )

You can set all listed functions individually and flexibly. By deactivating PartyMode all changes are discarded.

If the function is active, the appliance operates at a higher output. As a result, the operating noise of the appliance may be temporarily louder, while energy consumption increases.

#### **Activating PartyMode**

Make sure that the following requirements are fulfilled:
☐ IceMaker has been started for the first time.
(see 4.2 Starting the IceMaker for the first time)



Fig. 28



Fig. 29

- ► Carry out action steps according to the illustration.
- ▶ PartyMode and the corresponding functions are activated.
- > Temperature display turns blue.
- The current temperature flashes until the target temperature is reached.

#### **Deactivating PartyMode**

PartyMode is automatically deactivated after 24 hours. However, you can also manually deactivate PartyMode at any time:



Fig. 30




Fig. 31

- ► Carry out action steps according to the illustration.
- ▶ PartyMode is deactivated.
- The appliance first cools to the set temperature: The current temperature flashes until the target temperature is reached.

# $\overline{\Psi}$

#### SabbathMode

This function activates and deactivates SabbathMode. If you activate this function, some electronic functions are switched off. Your appliance thereby meets the religious requirements of Jewish holidays such as the Sabbath and complies with STAR-K Kosher certification.

#### Appliance status with active SabbathMode

The status display continuously shows SabbathMode.

All functions in the display except the **Deactivating SabbathMode function** are disabled.

Active functions remain active.

The display remains bright when you close the door.

The interior lighting is deactivated.

Memories are not listed. The set time interval is stopped.

Appliance status with active SabbathMode

Memories and warnings are not displayed.

There is no door alarm.

There is no temperature alarm.

The IceMaker is out of order.

The defrost cycle operates only for the specified time without taking into account the appliance usage.

After a power failure, the device returns to SabbathMode.

Appliance status

#### Note

This appliance has certification from the "Institute for Science and Halacha". (www.machonhalacha.co.il)

You can find a list of STAR-K-certified appliances at www.star-k.org/appliances.

#### **Activating SabbathMode**



#### **WARNING**

Danger of poisoning from spoiled food!

If you have SabbathMode activated and a power failure occurs, no message appears in the status display about the power failure. Once the power is restored, the appliance continues to operate in SabbathMode. The power failure may mean that food spoils and the consumption of this food could lead to food poisoning. After a power failure:

▶ Do not consume food that has been frozen and thawed.



Fig. 32



Fig. 33

- ► Carry out action steps according to the illustration.
- $\triangleright$  SabbathMode is activated.
- Status display continuously shows SabbathMode.

#### **Deactivating SabbathMode**

SabbathMode is automatically deactivated after 80 hours. However, you can also manually deactivate SabbathMode at any time:




Fig. 34

- ► Carry out action steps according to the illustration.
- SabbathMode is deactivated.



#### **EnergySaver**

Use this function to activate or deactivate energy saving mode. If you activate energy saving mode, energy consumption drops and the temperature in the appliance increases. Food remains fresh, but shelf life is reduced.

Tempera- ture zone	Recommended setting (see Setting the temperature)	Temperature while EnergySaver is active
-18∞	-18 °C (-0 °F)	-16 °C (3 °F)

Temperatures

#### **Activating EnergySaver**



Fig. 35




Fig. 36

- ► Carry out action steps according to the illustration.
- Energy saving mode is activated.

#### Deactivating EnergySaver



Fig. 37




Fig. 38

- Carry out action steps according to the illustration.
- Energy saving mode is deactivated.



#### IceMaker / MaxIce

You can activate or deactivate ice cube production with the IceMaker function. Use the MaxIce function to increase the number of ice cubes in the IceMaker.

More numbe	information er of ice cubes	on :	the	(see speci	10.1 fication	Technical s)
More IceMal	information ker water inflo	on w:	the	(see inflov	lceMa v)	aker water
More information on cleaning the lines of the IceMaker:		(see	TubeCl	ean )		

If the function is active, the appliance operates at a higher output. As a result, the operating noise of the appliance may be temporarily louder, while energy consumption increases.

#### **Activating IceMaker**

Make sure that the following requirements are fulfilled:

- ☐ The water supply is established at the fixed water connection. See Assembly Manual.
- ☐ IceMaker is put into operation. (see 8.4 IceMaker)



Fig. 39




Fig. 40

- ► Carry out action steps according to the illustration. -or-
- ► Activate with the SmartDevice app.

▷ IceMaker is activated. It can take up to 24 hours for the IceMaker to produce the first ice cubes.

#### Activating the IceMaker with MaxIce

If you have not activated the IceMaker function before, make sure that the following requirements are met:

- ☐ The water supply is established at the fixed water connection. See Assembly Manual.
- ☐ IceMaker is put into operation. (see 8.4 IceMaker)



Fig. 41




Fig. 42

- ► Carry out action steps according to the illustration.
- ► Activate with the SmartDevice app.
- The IceMaker is activated with MaxIce.

#### Changing between the IceMaker and MaxIce

If you have activated IceMaker and would like to change to MaxIce:



Fig. 43




Fig. 44

- ► Carry out action steps according to the illustration.
- The IceMaker is activated with MaxIce.

If you have activated MaxIce and would like to change to IceMaker:



Fig. 45




Fig. 46

- ► Carry out action steps according to the illustration.
- □ IceMaker is activated.

#### Deactivating the IceMaker / MaxIce



Fig. 47




Fig. 48 Example illustration of the active IceMaker function

▶ Carry out action steps according to the illustration.

#### -or-

- ▶ Deactivate with the SmartDevice app.
- □ IceMaker and MaxIce are deactivated.
- ▷ If ice cubes are currently being made, the system completes the process.
- ▶ The IceMaker goes off automatically.



#### IceMaker water inflow

Use this function to set the IceMaker water inflow. The IceMaker water inflow regulates the water inflow volume. You can adjust the IceMaker water inflow if the water inflow does not match the water pressure and the dispensed ice cube size.

Upon delivery, the IceMaker water inflow is set to the value 5. You can select a value of between 1 (smallest inflow volume) and 8 (largest inflow volume).

#### Setting the IceMaker-water inflow

Make sure that the following requirements are fulfilled:

- □ IceMaker has been started for the first time. (see 4.2 Starting the IceMaker for the first time)
- ☐ IceMaker is activated. (see IceMaker / MaxIce )



Fig. 49




Fig. 50 Example illustration: Switching from value 5 to value 6

- ► Carry out action steps according to the illustration.
- □ IceMaker water inflow is set.



#### TubeClean

This function activates or deactivates TubeClean. Activating TubeClean cleans the IceMaker lines.

#### **Activating TubeClean**

Make sure that the following requirements are fulfilled:

- ☐ IceMaker cleaning is prepared. (see 9.3.4 Cleaning the IceMaker)
- Empty container with a capacity of 1.5 l (1.59 qt) and with a maximum height of 10 cm (3 15/16 in) is ready.
- ► Place the container into the drawer below the IceMaker.



Fig. 51




Fig. 52

- ► Carry out action steps according to the illustration.
- □ TubeClean is activated.
- ▷ Cleaning process has started: Symbol flashes until the cleaning process is automatically completed after 60 minutes.
- ▶ When the cleaning process is completed: Appliance continues to run in normal operation.

#### **Deactivating TubeClean**

TubeClean is automatically completed after 60 minutes. However, you can also deactivate Tube-Clean at any time during the cleaning process:



Fig. 53

- ► Carry out action steps according to the illustration.
- □ TubeClean is deactivated: Cleaning process is canceled.
- ▶ Appliance continues to run in normal operation.



#### **Display Brightness**

Use this function to set the brightness of the display gradually.

You can set the following brightness levels:

- 40 %
- 60 %
- 80 %
- 100% (default setting)

#### Setting the brightness



Fig. 54




Fig. 55 Example illustration: Switching from 80 % to 60 %.

- Carry out action steps according to the illustration.
- ▶ Brightness is set.



#### Door alarm

Use this function to activate or deactivate the door alarm. The door alarm sounds if the door is open for too long. The door alarm is activated upon delivery. You can set how long to door can remain open until the door alarm sounds.

You can set the following values:

- 1 minute
- 2 minutes
- 3 minutes
- Off

#### Setting the door alarm



Fig. 56




Fig. 57 Example illustration: Changing the door alarm from 1 minute to 3 minutes.

- ► Carry out action steps according to the illustration.
- Door alarm is set.

#### Deactivating door alarm



Fig. 59




Fig. 60

- ► Carry out action steps according to the illustration.
- Door alarm is deactivated.



# Input lock

This function activates and deactivates the input lock. The input lock prevents the appliance from being operated accidentally, e. g. by children.

#### Application:


- Prevent unintentional changes of functions.
- Prevent switching off of the appliance.
- Prevent unintentional temperature setting.

#### Activating the input lock

If you activate the input lock, you can continue to navigate in the menus, however you cannot select or modify other functions.



Fig. 61




► Carry out action steps according to the illustration. ▶ Input lock is activated.

#### Deactivating the input lock



Fig. 63



► Carry out action steps according to the illustration. ▶ Input lock is deactivated.

# Language

Use this function to set the display language.

You can set the following languages:

- German
- English
- French
- Spanish
- Italian
- Dutch

- Czech
- Polish
- Portuguese
- Bulgarian
- Russian
- Chinese

#### Setting the language



Fig. 65




Fig. 66 Example illustration depending on the language and temperature

- ► Carry out action steps according to the illustration.
- ▶ Language is set.
- Display jumps back to the status display.

# **Appliance information**

Use this function to display the model name, index, serial number and service number of your appliance. You will need the appliance information when you contact customer service. (see 10.4 Customer Service)

You also use this function to open the expanded menu. (see 3 Functionality of the Touch & Swipe display)

#### Display appliance information



Fig. 67



- Carry out action steps according to the illustration.
- Display shows the appliance information.



#### **Software**

Use this function to display the software version of your appliance.

#### Display software version



Fig. 69



Fig. 70

- ► Carry out action steps according to the illustration.
- $\triangleright$  Display indicates the software version.



#### Demo mode

Demo mode is a special feature for dealers who want to demonstrate appliance features. If you activate demo mode, all refrigeration functions are deactivated.

If you switch on your appliance and "Demo" appears in the status display, then demo mode is already activated.

If you activate and then deactivate demo mode, the appliance will be reset to factory defaults. (see Resetting to factory settings)

#### Activating demo mode



Fig. 71




Fig. 72

- ► Carry out action steps according to the illustration.
- Demo mode is activated.
- ▶ Appliance is switched off.
- ➤ Switch on the appliance. (see 4.1 Switching on appliance (first use))
- > "DEMO" appears in the status display.

#### Deactivating demo mode



Fig. 73




Fig. 74

- ► Carry out action steps according to the illustration.
- Demo mode is deactivated.
- ▷ Appliance is switched off.
- Switch on the appliance. (see 4.1 Switching on appliance (first use))
- ▶ Appliance is reset to factory settings.



# Resetting to factory settings

Use this function to reset all settings to factory settings. All settings you have made so far are reset to their original settings.

#### Performing a reset



Fig. 75




Fig. 76

► Carry out action steps according to the illustration.

- ▶ Appliance is reset.
- > Appliance is switched off.
- ► Restart the appliance. (see 4.1 Switching on appliance (first use))

### 7.3 Messages

There are two categories of messages:

Category	Meaning		
Warning	Warnings are displayed if there is a door alarm or a malfunction. You can easily end warnings yourself. For any major malfunction, you must contact Customer Service. (see 10.4 Customer Service)		
Reminder	Reminders remind you of general processes. You can perform these processes and end the message doing so.		

### 7.3.1 Overview of warnings

The appliance's behavior in the event of a warning:

- Warning appears in the display in red.
- Alarm sounds in increasing volume.
- For some warnings the interior lighting pulses.

Message	Cause	Ending the message
Close the door.  Door alarm	The message appears if the door is open for too long.	
Power failure Power failure alarm	The message appears if the freezing temperature increases due to a power outage.	action steps (see Power
Temperature alarm Temperature alarm	The message appears if the freezing temperature does not correspond to the set temperature.	action steps (see Temper-
Error	This message appears if there is an appliance error. An appliance module indicates an error.	action steps

Message	Cause	Ending the message
WIFI Error WLAN error	This message appears if the appliance could not be connected to the WLAN. (see Establishing the WiFi connection for the first time)	action steps (see WLAN

#### 7.3.2 Ending warnings

#### Door alarm




Fig. 77 Example illustration

- ► Carry out action steps according to the illustration.
- ► Close the door.

Display skips to status display.

You can set how long to door may remain open until the door alarm sounds. (see Setting the door alarm)

#### Power failure alarm

Once the power failure has ended, the appliance cools to the target temperature set earlier.




Fig. 78 Example illustration

- ► Briefly touch the display.
- Display shows information about the warning.
- ▶ Briefly touch the display.
- ➤ The warmest freezing temperature is displayed.
- If the freezing temperature was below -9 °C (16 °F): Food can still be eaten.

If the freezing temperature exceeded -9 °C (16 °F):

- ▶ Check the food.
- ▶ Briefly touch the display.
- Display skips to status display: The current temperature and target temperature are displayed.

#### Temperature alarm

Causes for the temperature differences may be:

- You have put in warm, fresh food.

- Too much warm room air has flowed in during the rearrangement and removal of food.
- The power has been out for a longer period of time.
- The appliance is defective.
- ► Remedy the cause.
- > The appliance cools to the target temperature set earlier:




Fig. 79 Example illustration

- ► Briefly touch the display.
- Display shows information about the warning.
- Briefly touch the display.
- > The warmest freezing temperature is displayed.
- If the freezing temperature was below -9 °C (16 °F): Food can still be eaten.

If the freezing temperature exceeded -9 °C (16 °F):

- ► Check the food.
- ► Briefly touch the display.
- Display skips to status display: The current temperature and target temperature are displayed.

#### **Error**




Fig. 80 Example illustration

- ► Briefly touch the display.
- ► Make a note of the error code.
- ► Briefly touch the display.
- Display skips to status display.
- ► Contact Customer Service. (see 10.4 Customer Service)

#### **WLAN** error

- ► Check the WLAN connection.
- ► Connect the appliance to the WLAN again. (see WiFi)

#### 7.3.3 Overview of reminders

The appliance's behavior in the event of a reminders:

Reminder appears in the display in yellow.

# **Equipment**

- Alarm tone sounds.
- For some reminders the interior lighting pulses.

Message	Cause	Ending the message	
No water  Check water	This message appears if the IceMaker is active, but the IceMaker is no longer being	action steps (see Check water connec-	
connection	supplied with water by a permanent water connection.		
No Drawer	This message appears if the IceMaker is active, but the IceMaker	action steps (see Push in	
Push in the IceMaker drawer	drawer is open.	drawer) .	

#### 7.3.4 Ending reminders

#### Check water connection




Fig. 81 Example illustration

- ► Briefly touch the display
- Display shows information about the reminder.
- ► Briefly touch the display
- ► Check the water connection.

#### -or-

▶ Deactivate IceMaker. (see Deactivating the IceMaker / MaxIce)

If the water connection has been checked and IceMaker is activated:

► Clean the IceMaker. (see 9.3.4 Cleaning the IceMaker)

▶ IceMaker is producing ice cubes.

#### Push in the IceMaker drawer




Fig. 82 Example illustration

- ► Briefly touch the display.
- Display shows information about the reminder.
- ► Briefly touch the display.
- ► Push in the IceMaker drawer.

#### -or-

- ▶ Deactivate IceMaker. (see IceMaker / MaxIce )
- ▷ If the IceMaker drawer is pushed in and IceMaker is active: IceMaker is producing ice cubes.

# 8 Equipment

#### 8.1 Drawers

You can remove the drawers for cleaning.

You can remove the drawers to use VarioSpace.

The way to remove/insert the drawers varies depending on the pull-out system. Your appliance can contain a variety of pull-out systems.

#### Note

Insufficient ventilation results in an increase in energy consumption and reduction of the refrigerating performance.

- ► Leave the bottom drawer in appliance!
- ▶ Never obstruct the vents on the interior rear wall!

# 8.1.1 Drawer on appliance base or glass shelf

The drawer runs directly on the appliance base or on a glass shelf. There are no rails.

When you remove the drawers, you can use the glass shelves below them as storage shelves.

#### Removing drawer




Fig. 83

▶ Remove drawer as shown in the diagram.

#### Inserting drawer




Fig. 84

► Insert drawer as shown in the diagram.

#### 8.1.2 Drawer on telescopic rails

The drawer runs on full-extension rails (telescopic rails). There are full-extension telescopic rails and telescopic rails with partial pull-out. Drawers which are full extension can be pulled out fully from the appliance. Drawers with partial pull-out cannot be pulled out fully from the appliance. The system in your appliance depends on the type of appliance.

#### Drawer on glass shelf

The drawer guided on a glass shelf is a partial pull-out.

#### Removing drawer




Fig. 85

- ▶ Pull out drawer as far as it will go. Fig. 85 (1)
- Lift drawer on the left. Fig. 85 (2)
- ► Slide in left rail. Fig. 85 (3)




Fig. 86

- ► Lift drawer on the right. Fig. 86 (4)
- ► Slide in right rail. Fig. 86 (5)
- ► Remove drawer to the front. Fig. 86 (6)




Fig. 87

If the rails are not yet fully pushed in after removing the drawer:

▶ Push the rails in completely.

#### Inserting drawer




Fig. 88

- ► Slide rails in.
- ▶ Place drawer on rails at an angle.




Fig. 89

- Lower drawer.
- ► Slide in drawer to the back.

### 8.1.3 Top tilting drawer

When you pull out the top drawer, it tilts forward. This gives you a better view into the drawer. The function depends on the height of the appliance.

When you remove the upper tilting drawer, you can use the glass shelf below it as a storage shelf.

#### Removing drawer




Fig. 90

- ▶ Pull out drawer as far as it will go.
- ► Lift drawer at the front and simultaneously push up at the back from below.
- ► Remove drawer to the front.

# **Equipment**

#### Inserting drawer




Fig. 91

- ▶ Place on the drawer as shown in the diagram.
- $\triangleright$  The drawer rests on the glass panel.
- ► Lift drawer slightly from below at the back and slide over the lip.
- ► Slide in drawer to the back.

#### 8.1.4 Drawer on molded rib

The drawer runs directly on the molded rib. There are no rails.

#### Removing drawer




Fig. 92

- ▶ Pull out drawer as far as it will go.
- Lift drawer at the front. Fig. 92 (1)
- ► Remove drawer to the front. Fig. 92 (2)

#### Inserting drawer




Fig. 93

- ► Place drawer at an angle behind the stoppers on the molded rib. (see Fig. 93)
- ► Lower drawer.
- ► Slide in drawer to the back.

#### 8.2 Pull-out board with IceTower




Fig. 94 Pull-out board with IceTower

- (1) IceMaker
- (3) Container for pizza or alcoholic beverages, for example
- (2) Hang-on tray for ice cubes
- (4) Pull-out board

On the pull-out board are two tall containers (IceTower). Ice cubes from the IceMaker are collected and stored in the container *Fig. 94 (2)*. The container *Fig. 94 (3)* is suitable for storing tall foodstuffs or beverages such as pizzas or alcoholic drinks.

The pull-out board with IceTower is mounted on a glass shelf with pull-out rails. You can dismantle the pull-out board for cleaning.

# 8.2.1 Dismantling the pull-out board with IceTower

#### Removing the container




Fig. 95

- ► Remove the pull-out board.
- ▶ Lift the container Fig. 95 (5) at the front.
- ► Remove the container.




Fig. 96

- ▶ Remove the hang-on tray Fig. 96 (6).
- ► If there are ice cubes in the hang-on tray: Empty the hang-on tray.
- The container and hang-on tray have been removed and you can clean them. (see 9.3.3 Cleaning the equipment)

#### Removing the pull-out board

Make sure that the following requirements are fulfilled:

☐ Containers have been removed. (see Removing the container)




Fig. 97

- ► Slide in the pull-out board. Fig. 97 (7)
- ▶ Lift the pull-out board at the front left. Fig. 97 (8)
- ▶ Lift the pull-out board at the front right. Fig. 97 (9)
- > The pull-out board is detached from the attachment at the front.
- ► Take out the pull-out board to the front. Fig. 97 (10)
- The pull-out board has been removed and you can clean it. (see 9.3.3 Cleaning the equipment)

# Removing the glass shelf from under the pull-out board

(see 8.3 Glass shelves)

# 8.2.2 Inserting the pull-out board with IceTower

#### Inserting the glass shelf under the pull-out board

(see 8.3 Glass shelves)

#### Inserting the pull-out board




Fig. 98

► Slide the rails in.




Fig. 99

- ▶ Place the pull-out board in at an angle behind the front lug.
- ▶ Slide it in at an angle. Make sure that the stop is behind the lug on both sides. Fig. 99 (11)
- Lower the pull-out board at the front. Fig. 99 (12)




Fig. 100

- ▶ Push the pull-out board down at the front.
- > The pull-out board clicks into place.

#### Inserting the container

Make sure that the following requirements are fulfilled:

☐ The pull-out board is inserted. (see Inserting the pull-out board)

# **Equipment**




Fig. 101

- ► Remove the pull-out board.
- ► Hold the pull-out board with one hand.

#### Note

The containers are shaped in a way that they cannot be interchanged.

- ▶ Place the container at an angle on the pull-out board. Fig. 101 (13)
- ► Slide in the container at an angle to the back. Fig. 101 (14)
- ▶ Place container at the front. Fig. 101 (15)




Fig. 102

- ▶ Insert hang-on tray Fig. 102 (6) for ice cubes.
- ► Slide in the pull-out board with container (IceTower). Fig. 102 (16)
- ▶ Pull-out board with IceTower is fully inserted.

#### 8.3 Glass shelves

#### NOTICE

Impermissible removal of the glass panel above the IceTower!

Damage to the IceMaker. The IceMaker is attached to the glass panel above the IceTower.

▶ Do not remove the glass panel above the IceTower.

You can remove the glass shelf under the drawers for cleaning.

You can remove the glass shelf under the drawers to use VarioSpace.

# 8.3.1 Removing / inserting the glass shelf under the tilting drawer

The glass shelf is located under the top tilting drawer.

Make sure that the following requirements are fulfilled:

☐ Drawer has been removed. (see 8.1.3 Top tilting drawer)

#### Removing glass shelf




Fig. 103 Tilting drawer glass shelf

- ► Press the glass shelf upwards from below on both sides. (see Fig. 103)
- ▶ Remove the glass shelf to the front.

#### Inserting glass shelf




Fig. 104 Tilting drawer glass shelf

- ► Position glass shelf at an angle behind the stoppers. (see Fig. 104)
- Lower glass shelf.
- ► Slide in glass shelf to the back.
- Glass shelf clicks into place.

#### 8.3.2 Removing / inserting the glass shelf

Depending on the equipment, the glass shelf may be located under the drawer.

Depending on the equipment, the glass shelf may be located under the IceTower.

Make sure that the following requirements are fulfilled:

- ☐ Glass shelf under the drawer: Drawer has been removed. (see 8.1 Drawers)
- ☐ Pull-out board under IceTower: IceTower has been removed. (see 8.2 Pull-out board with IceTower)

#### Removing glass shelf




Fig. 105 Example illustration of glass shelf

- ► Lift glass shelf at the front. Fig. 105 (1)
- ► Remove glass shelf to the front. Fig. 105 (2)

#### Inserting the glass shelf




Fig. 106 Example illustration of glass shelf

- ► Position glass shelf at an angle behind the stoppers. (see Fig. 106)
- ► Lower glass shelf.
- ▶ Slide in glass shelf to the back.

#### 8.4 IceMaker

The IceMaker is used exclusively for the production of ice cubes in household quantities.

Make sure that the following conditions are fulfilled

- IceMaker is cleaned. (see 9 Maintenance)
- IceMaker drawer is cleaned.
- IceMaker drawer is fully inserted.

#### 8.4.1 Producing ice cubes

The production capacity depends on the freezer temperature The lower the temperature, the more ice cubes can be produced in a certain period

Once IceMaker is switched on for the first time, it can take up to 24 hours to produce the first ice cubes.

- ► Activate the IceMaker function.
- ► Making many ice cubes: Activate the MaxIce function.
- ► To make a large quantity of ice cubes: Move or remove the separators in the IceMaker drawer.
- Distribute ice cubes evenly in the drawer to increase its capacity.
- Close the drawer: The IceMaker starts making ice again.

#### Note

When a certain level is reached in the IceMaker drawer, it stops making ice cubes. The IceMaker does not fill the drawer to the very top.

### 8.5 VarioSpace




Fig. 107

You can remove drawers and glass panels from your appliance. This provides more room for large food items such as poultry, joints of meat, large game and bulky baked goods. You can then freeze these items whole for later preparation.

Note the load limits on the drawers and glass panels (see 10.1 Technical specifications).

# 8.6 Flexible ice compartment divider

The IceMaker's ice cube drawer has a flexible ice compartment divider. This allows you to store larger quantities of ice cubes or additional food items as needed. You can move or remove the ice compartment divider.

# 8.6.1 Moving the flexible ice compartment divider




Fig. 108 Example illustration of the ice compartment divider
 ▶ Move the ice compartment divider to the desired position.

# 8.6.2 Removing the flexible ice compartment divider

Make sure that the following requirements are fulfilled:
☐ Ice cube drawer is removed. (see 8.1 Drawers)




Fig. 109

- ► Lift the rear part of the ice compartment divider. Fig. 109 (1)
- ► Remove the ice compartment divider upwards. Fig. 109 (2)

# 8.6.3 Putting in the flexible ice compartment divider

Make sure that the following requirements are fulfilled:
☐ Ice cube drawer is removed. (see 8.1 Drawers)




Fig. 110

- ► Insert the front part of the ice compartment divider. Fig. 110 (1)
- ► Lower the rear part of the ice compartment divider to the drawer bottom. Fig. 110 (2)

### 9 Maintenance

# 9.1 Disassembling / assembling pullout systems

#### 9.1.1 Notes on disassembly

You can disassemble some of the pull-out systems for cleaning. Your appliance can contain a variety of pull-out systems.

The following pull-out systems can be disassembled or cannot be disassembled:

Pull-out system	can be disassembled / cannot be disassembled		
Drawer on appli- ance base or glass shelf	cannot be disassembled		
Drawer guided on glass shelf	can be disassembled (see Drawer on glass shelf)		
Top tiltable drawer	can be disassembled (see 9.1.3 Top tilting drawer)		
Drawer guided on support rib	can be disassembled (see 9.1.4 Drawer on molded rib)		
IceTower	can be disassembled (see 9.1.5 IceTower)		

#### 9.1.2 Drawer on telescopic rails

#### Drawer on glass shelf

#### Disassembling pull-out system

Make sure that the following requirements are fulfilled:

- Drawer has been removed.
- ☐ Glass shelf has been removed. (see 8.3 Glass shelves)




Fig. 111 Glass shelf with rails

- ▶ Push up front click-in hooks. (1)
- ▶ Slide pull-out rails to the side (2) and backwards (3).




Fig. 112 Attachment on the right molded rib

▶ Remove molded rib attachment sideways.

#### Installing pull-out system




Fig. 113 Glass shelf with rails

- ► Hook in rail at the back. (1)
- ► Hook in rail at the front. (2)




Fig. 114 Attachment on the right molded rib

▶ Press attachment onto molded rib.

#### 9.1.3 Top tilting drawer

#### Disassembling pull-out system

Make sure that the following requirements are fulfilled:

- ☐ Drawer has been removed. (see 8.1.3 Top tilting drawer)
- ☐ Glass shelf has been removed. (see 8.3 Glass shelves)




Fig. 115 Glass shelf with side parts

► Remove side part from glass shelf sideways.

#### Installing pull-out system




Fig. 116 Glass shelf with side parts

- ▶ Place on side part at the back.
- ▶ Press side part onto glass shelf at the front.

#### 9.1.4 Drawer on molded rib

#### Disassembling pull-out system

Make sure that the following requirements are fulfilled:

☐ Drawer has been removed. (see 8.1.4 Drawer on molded rib)




Fig. 117 Attachment on the right molded rib

- ► Grab attachment at the back from below.
- ▶ Pull off attachment at the back sideways. Fig. 117 (1)
- ▶ Pull off attachment at the front sideways. Fig. 117 (2)

#### Installing pull-out system




Fig. 118 Comparing attachments

#### Maintenance

There are two different attachments in the appliance. The attachment above the lowest drawer *Fig. 118 (2)* has a three-cornered edge. All other attachments *Fig. 118 (1)* have a straight edge.

- ► Fit attachment *Fig. 118 (2)* with the three-cornered edge above the lowest drawer.
- ► Fit attachment *Fig. 118 (1)* with straight edge in all other positions.




Fig. 119 Attachment on the right molded rib

- ► Position attachment on molded rib at the front. Fig. 119 (1)
- ▶ Press on attachment at the back. Fig. 119 (2)

#### 9.1.5 IceTower

#### Disassembling pull-out system

Make sure that the following requirements are fulfilled:

- ☐ IceTower has been removed. (see 8.2 Pull-out board with IceTower)
- ☐ Glass shelf has been removed. (see 8.3 Glass shelves)
- ▶ Place pull-out board on a table.
- > You are able to remove the rails more easily from the glass shelf.




Fig. 120 Glass shelf with rails and retaining parts

▶ Press down retaining part at the rear (see Fig. 120) and simultaneously push rail back.




Fig. 121 Glass shelf with rails and retaining parts

▷ The rail hooks are released from the retaining part.

► Remove rail from retaining part.




Fig. 122 Glass shelf with retaining part

► Remove retaining part from glass shelf sideways.

#### Installing pull-out system




Fig. 123 Glass shelf with retaining part

- ► Fit retaining part on glass shelf.
- ▶ Push retaining part onto glass shelf as far as it will go.




Fig. 124 Damping mechanism

The damping mechanism is attached to the left rail. (see Fig. 124) There is no damping mechanism attached to the right rail.




Fig. 125 Glass shelf with rails and retaining parts Install rail with damping mechanism:

- ▶ Place rail hooks onto the openings of the **left** retaining part. *Fig.* 125 (1)
- ▶ Push rail forwards. Fig. 125 (2)
- $\triangleright$  Rail latches in audibly.
  - Install rail without damping mechanism:
- ▶ Place rail hooks onto the openings of the **right** retaining part. Fig. 125 (1)
- ▶ Push rail forwards. Fig. 125 (2)
- > Rail latches in audibly.

# 9.2 Defrosting the appliance

#### 9.2.1 Defrosting with NoFrost

Defrosting is performed automatically by the NoFrost system. The moisture condenses on the evaporator and is periodically defrosted and evaporated.

The appliance does not need to be defrosted.

# 9.3 Cleaning the appliance

### 9.3.1 Preparation



#### WARNING

Danger of electric shock.

► Unplug refrigerator or disconnect power.



#### WARNING

Danger of fire

- ▶ Do not damage the refrigerant circuit.
- Empty appliance.
- ▶ Pull out the power plug.

#### 9.3.2 Cleaning the interior

#### NOTICE

Improper cleaning!

Damage to the appliance.

- ➤ Only use soft cleaning cloths and ph-neutral allpurpose cleaners.
- ▶ Do not use steel wool or sponges that scour or scratch.
- ▶ Do not use caustic or abrasive cleaning materials or those containing sand, chloride, or acids.
- ▶ Plastic surfaces: clean by hand with a soft clean cloth, lukewarm water and a little detergent.
- ▶ Metal surfaces: clean by hand with a soft clean cloth, lukewarm water and a little detergent.

#### 9.3.3 Cleaning the equipment

#### NOTICE

Improper cleaning!

Damage to the appliance.

- Only use soft cleaning cloths and ph-neutral allpurpose cleaners.
- ▶ Do not use steel wool or sponges that scour or scratch.
- ▶ Do not use caustic or abrasive cleaning materials or those containing sand, chloride, or acids.

# Clean with a soft, clean cloth, lukewarm water and a little washing up liquid:

- IceTower pull-out board
- Drawer
  - Please note: Do not remove the magnet on the drawer. The magnet ensures that the IceMaker functions.
- Flexible ice compartment divider in the ice cube tray of the IceMakers
- Freezer tray

#### Clean with a damp cloth:

- Retracting rails

Please note: the grease in the tracks is there for lubrication purposes and must not be removed!

#### Clean in the dishwasher up to 60 °C (140 °F):

- Ice cube scoop
- ▶ Disassemble the equipment: see the relevant section.
- ► Clean the equipment.

### 9.3.4 Cleaning the IceMaker

There are various options for cleaning the IceMaker.

We recommend cleaning in the following situations:

- ☐ Initial commissioning
- ☐ With water connection:

If out of use for longer than 5 days.

Make sure that the following requirements are met:

☐ IceMaker drawer is emptied.

# **Customer support**

☐ IceMaker drawer is fully inserted.

☐ The IceMaker has been activated.

#### On first use or if not used for prolonged periods

Clean the IceMaker with TubeClean.

- ▶ Put an empty 1.5 l (1.59 qt) vessel (max. height 10 cm (3 15/16 in)) in the drawer under the IceMaker.
- ► Activate the TubeClean function.
- The rinse process is prepared (max. 60 min.): The symbol flashes.
- ▶ Rinsing process is complete: Function turns off automatically.
- ► Take out the IceMaker drawer and remove the container.
- ► Clean the IceMaker drawer with warm water and a little detergent.
- ► Push in the IceMaker drawer.
- ▶ Ice cube production starts automatically.
- ▶ Dispose of any ice cubes that are produced within 24 hours of the first ice cube production.

#### When cleaning is required

Clean the IceMaker manually.

- ► Remove the IceMaker drawer and clean with warm water and a little detergent.
- ▶ Push in the IceMaker drawer.
- ▶ Ice cube production starts automatically.

#### 9.3.5 After cleaning

- ▶ Wipe dry the appliance and items of equipment
- ► Connect and switch on the appliance.
- ► Activate SuperFrost (see 7.2 Appliance functions) . When the temperature is sufficiently cold
- ▶ Place the food inside.

Temperature zone

► Repeat cleaning regularly.

# 10 Customer support

# 10.1 Technical specifications

•			
Freezing	-28 °C (-18 °F) to -15 °C (5 °F)		
Maximum freezing quantity/24 h			
Freezer	See "Freezing capacity/24 h" on the type plate		

Max. equipment capacity					
Equipment	Appliance width 550 mm (21 5/8 in) (see installation instructions, appliance dimensions)		Appliance width 700 mm (27 9/16 in) (see installation instructions, appliance dimensions)		
Drawer on glass shelf (see 8.1.1 Drawer on appliance base or glass shelf)	12 kg (26.46 lb)	15 kg (33.07 lb)			
Drawer on molded rib (see 8.1.4 Drawer on molded rib)	14 kg (30.86 lb)	19 kg (41.89 lb)	19 kg (41.89 lb)		
Drawer on glass shelf (see 8.1.2 Drawer on telescopic rails)	12 kg (26.46 lb)	15 kg (33.07 lb)	22 kg (48.50 lb)		

lce cube production with IceMaker+			
Ice cube production/24 h	At a temperature of -18 °C (-0 °F): 1.2 kg (2.65 lb) of ice cubes		
Maximum ice cube production/ 24 h	When the MaxIce function is active: 1.6 kg (3.53 lb) of ice cubes		

For appliances with a WiFi connection:

Frequency specification		
Frequency band	2.4 GHz	
Maximum radi- ated power	< 100 mW	
	Integration in the local WiFi network for data communication	

# 10.2 Operating noises

The appliance makes noises while in operation.

- At **less cooling output** the appliance saves energy but takes longer to cool items. The volume is **lower**.
- At a higher cooling output the food cools more quickly. The volume is higher.

#### Examples:

- Activated functions (see 7.2 Appliance functions)
- Running fan
- Freshly sorted food
- · High ambient temperature
- Door opened for long periods

Noise	Possible cause	Type of noise	
Bubbling and splashing	Coolant is flowing into the cooling circuit.	Normal noise	
Spitting and hissing	Coolant is spraying into the cooling circuit.	Normal noise	
Humming	The appliance cools. The volume depends on the cooling output.	Normal noise	
Sipping noises	The self-closing door is being opened and closed.	Normal noise	
Whirring and murmuring	The fan is running.	Normal oper- ating noise	
Clicking	Components are being switched on and off.		

Noise	Possible cause	Type of noise
Rattling or humming		Normal switching noise

Noise	Possible cause	Type of noise	How to resolve
Vibration	Unsuitable installation	Error noise	Check installation. Set up the appliance.
Clattering	Equipment, Objects inside the appliance	Error noise	Secure equipment parts. Leave a gap between items.

### 10.3 Technical faults

Your appliance is designed and manufactured for reliable operation and a long service life. If a malfunction nonetheless occurs during operation, please check whether the malfunction is due to an operating error. In this case, you will have to be charged for the costs incurred, even during the warranty period.

You may be able to rectify the following faults yourself.

### 10.3.1 Appliance function

Defect	Cause	Remedy
The appliance	The appliance is not switched on.	► Switch on the appliance.
does not work.	The power plug is not properly inserted in the wall socket.	► Check the power plug.
	The powerfuse in the wall socket is not OK.	► Check the fuse.
	Power failure.	<ul> <li>▶ Keep the appliance closed.</li> <li>▶ Protect food: Place cold storage batteries on the food or use another freezer appliance if the power failure lasts longer.</li> <li>▶ Do not re-freeze defrosted food.</li> </ul>
	The IEC socket is not correctly plugged into the appliance.	► Check the IEC socket.
The temperature is not cold	This means that the door of the appliance is not closed properly	► Close the appliance door
enough	Insufficient ventilation	Clear and clean the ventilation grille.
	The ambient temperature is too high	► Problem solution: (see 1.4 Range of appliance use)

# **Customer support**

Defect	Cause	Remedy
	The appliance was opened too frequently or for too long	► Wait to see if the required temperature corrects itself. If not, contact Customer Service. (see 10.4 Customer Service)
	Too much fresh food was placed inside without SuperFrost.	► Solution: (see SuperFrost)
	The temperature is incorrectly set	► Set to a colder temperature and check after 24 hours.
	The appliance is too near to a heat source (stove, heater etc).	► Change location of appliance or the heat source.
	The appliance was not properly installed in the recess.	► Make sure the appliance was installed correctly and the door closes properly.
The door seal is defective or should be replaced for other reasons.	The door seal is interchangeable. You can replace it without the use of any special tools.	
The appliance is iced up or condensation is building.	The door seal may have slipped out of its groove.	► Check the door seal is well placed in the groove.

# 10.3.2 Equipment

Defect	Cause	Remedy
The IceMaker cannot be switched on.	The appliance and therefore the IceMaker are not connected.	► Connect the appliance (see Installation Guide).
The IceMaker is	The IceMaker is not switched on.	► Activate the IceMaker.
not making any ice cubes.	The drawer of the IceMaker is not properly closed	► Close the drawer properly
	The water connection is not open	▶ Open the water connection
The interior light	The appliance is not switched on.	► Switch on the appliance.
does not turn on.	The door was open for more than 15 minutes.	► If the door is open, the interior lighting switches off automatically after about 15 minutes.
	The LED interior light is faulty or the lid is damaged.	► Contact Customer Service. (see 10.4 Customer Service)

### 10.4 Customer Service

First check whether you can rectify the fault yourself (see 10 Customer support) . If you cannot rectify the problem, contact Customer Service.

You can find the address in the enclosed brochure "Liebherr-Service" or at home.liebherr.com/service.



## WARNING

Unprofessional repair! Injuries.

- ► A damaged power cable may only be replaced by the manufacturer, the manufacturer's Customer Service or a similarly qualified person.
- ► For appliances with plug and play connection cables, the change can be made by the customer.

## 10.4.1 Contacting Customer Service

Make sure that the following appliance information is available:

- Appliance name (model and index)
- ☐ Service no. (service)
- ☐ Serial no. (S no.)
- ► Call up the appliance information via the display. (see Appliance information)

-or-

- ▶ Refer to the type plate for appliance information. (see 10.5 Rating plate)
- ▶ Take note of the appliance information.
- ▶ Notify customer service: Report errors and the appliance information.
- This will help us give you fast and accurate support.
- ► Follow further instructions from Customer Service.

## 10.5 Rating plate

The nameplate is located behind the drawers on the inside of the appliance.




Fig. 126

- (1) Appliance name
- (3) Serial no.
- (2) Service no.
- ► Information from the nameplate.

## 11 Decommissioning

- ► Empty appliance.
- ▶ Deactivate IceMaker. (see Deactivating the IceMaker / MaxIce )
- Switch off appliance. (see Switching appliance off and on)
- ▶ Pull the power plug from the outlet.
- ▶ If necessary, remove the IEC socket: Pull the IEC socket out of the appliance plug while turning it to the left and right at the same time.

- ► Clean appliance. (see 9.3 Cleaning the appliance)
- ► Leave the door open to prevent unpleasant odors.

## 12 Disposal

## 12.1 Preparing the appliance for disposal



#### WARNING

Risk of child entrapment!

Before you throw away your old refrigerator or freezer:

- ▶ Take off the doors.
- Leave the shelves in place so that children may not easily climb inside.



Liebherr uses batteries in some of its appliances. You should remove these before disposal of the old appliance for environmental reasons. If your appliance contains batteries, a corresponding notice attached to the appliance.

Lamps

If you can remove the lamps yourself without destroying them, also remove these before disposal.

- ▶ Take the appliance out of operation.
- ▶ If possible: Remove lamps without destroying them.

## 12.2 Disposing of the appliance in an environmentally friendly manner





LI-lon

The appliance still contains valuable materials and must be collected separately from unsorted municipal waste so it can be recycled.

Dispose of batteries separately from the old appliance. Certain batteries should NOT go in household garbage or recycling bins. Waste batteries can always be recycled or taken to household hazardous waste collection points. To prevent fires from lithium-ion batteries. tape battery terminals and/or place batteries in separate plastic bags and never put these batteries in household garbage or recycling bins.

Dispose of removed lamps via the respective collection systems.

Lamps

## **Disposal**

For USA: Check the Responsible Appli-

ance Disposal (RAD) program to find a RAD partner near

you.

For Canada: Follow your local guidance

about recycling and disposal

capabilities near you.



#### WARNING

Leaking refrigerant and oil!

Fire. The refrigerant contained within the appliance is environmentally friendly, but flammable. The oil contained within the appliance is flammable. Escaping refrigerant and oil can ignite if they are of high enough concentration and are exposed to an external heat source.

- ▶ Do not damage the pipelines of the coolant circuit and the compressor.
- ▶ Observe the notes on appliance transport.
- ► Transport the appliance away without damaging it.
- ▶ Dispose of batteries, lamps, and the appliance according to the above specifications.



home.liebherr.com/fridge-manuals

**EN** Built-in combined fridge-freezer

Part number index: 7088429-00

For Service in the U.S.: Liebherr Service Center Toll Free: 1-866-LIEBHER or 1-866-543-2437 Service-appliances.us@liebherr.com PlusOne Solutions, Inc. 3501 Quadrangle Blvd, Suite 120 Orlando, FL 32817

Issue date: 20241105

For Service in Canada: Liebherr Service Center
Toll Free: 1-888-LIEBHER or 1-888-543-2437
www.euro-parts.ca
EURO-PARTS CANADA
39822 Belgrave Road, Belgrave, Ontario, NOG 1E0
Phone: (519) 357-3320 | Fax: (519) 357-1326





User Guide

Quality, Design and Innovation





# LIEBHERR

Cor	ntents		->-	Display Brightness	19
<b>1</b> 1.1	The appliance at a glance  Delivered contents	3		Door alarm	19
1.2 1.3 1.4	Overview of appliances and equipment SmartDevice	4	×(m)	Input lock	19
1.5 1.6	ConformitySpare parts	5		Language	
2	General safety instructions	5	Service Nox Model Index:	Appliance information	20
<b>3</b> 3.1 3.2	Functionality of the Touch & Swipe display.  Navigation and symbol explanation  Menus	<b>7</b> 7 8	d on accordance pro saw appropries	Software	
3.3	Sleep mode		\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\	Reminder	21
<b>4</b> 4.1 4.2	Start-up Switching on appliance (first use) Putting InfinitySpring into operation	9	$\bigcirc$	Demo mode	
5	Storage		$\bigcirc$	Resetting to factory settings	22
5.1	Information regarding storage	10	7.3	Messages	22
5.2 5.3	Fridge compartment BioFresh		7.3.1	Overview of warnings	
5.4	Storage times		7.3.2	Ending warnings	22
6	Energy saving		7.3.3 7.3.4	Overview of reminders Ending reminders	
7	Use		8	Equipment	
7.1	Controls and displays		8.1	Door racks	
7.1.1	Status display		8.2	Shelves	
7.1.2	Display symbols		8.3	Split shelf	
7.2	Appliance functions	13	8.4	VarioSafe	
7.2.1	Notes on the appliance functions	13	8.5	InfinitySpring	28
71	Switching appliance off and on	13	8.6	Space for baking tray	
(			8.7	Variable bottle shelf	29
	WiFi	13	8.8	Drawers	
(î.			8.9	Fruit & Vegetable-Safe cover	
	Temperature	14	8.10	Humidity control	
5 ⋅c	Temperature	14	8.11	Butter dish	
	Ta mana a mada a mana a maid	15	8.12	Egg rack	
°C/_	Temperature unit	15	8.13	Bottle rack	
/ "⊦	5. 5. 1. 5. 7. 1.		8.14	FlexSystem	32
<b>B5</b>	BioFresh B-Value	15	9	Maintenance	
	D-Value	15	9.1 9.2	FreshAir carbon filter Water tank	
D1	D-value	13	9.2 9.3	Water filter	
$\frac{1}{2}$	SuperCool	15	9.4	Disassembling / assembling pull-out systems	t . 34
ΝĪ	PartyMode	16	9.5 9.6	Defrosting the appliance	
<u>~</u>	HolidayMode	17	<b>10</b> 10.1 10.2	Customer support  Technical specifications  Operating noises	36
$\Psi$	SabbathMode	17	10.2 10.3 10.4	Technical faults	37
$\Box$	EnergySaver	18	10.5	Rating plate	
	ClassingMode	10	11	Decommissioning	38
	CleaningMode	18	<b>12</b> 12.1	<b>Disposal</b> Preparing the appliance for disposal	

12.2 Disposing of the appliance in an environmentally friendly manner...... 39

Congratulations on the purchase of your new appliance. With this purchase, you have chosen all the advantages of the latest refrigeration technology, guaranteeing you a high-quality appliance with a long life span and high operating safety.

The equipment of your appliance gives you the highest level of day-to-day ease of operation.

Together we are making an active contribution to the conservation of our environment by purchasing this appliance which is manufactured in an environmentally friendly process with the use of recyclable materials.

We hope you enjoy your new appliance.

The manufacturer is constantly working to improve all types and models. Therefore, please be aware that we reserve the right to make changes to the shape, equipment and technology.

## Symbol Explanation Read instructions Please read the information in these instructions carefully to understand all of the benefits of your new appliance. Additional information online The digital manual with supplemental information can be found online by scanning the QR code on the front page of this manual or by entering the service number at home.liebherr.com/fridge-manuals. Check appliance Check all parts for transport damage. If you have any complaints, please contact your agent or customer service. Differences These instructions apply to a range of models, so there may be differences. Sections that apply to certain models only are indicated by an asterisk (\*). Instructions and results Instructions are marked with a ▶. Results are marked with a $\triangleright$ . Videos Videos about the appliances are available on the YouTube channel of Liebherr-Hausgeräte.

## Open-source licenses:

The appliance includes software components that make use of open-source licenses. You can find information on the open-source licenses to be used here: home.liebherr.com/open-source-licenses

These operating instructions apply to:

IRB5160

## 1 The appliance at a glance

#### 1.1 Delivered contents

Check all parts for transport damage. If you have any complaints, please contact the retailer or customer service. (see 10.4 Customer Service)

Delivery contains the following parts:

- Integrated appliance
- Equipment (depending on your model)
- Installation parts (depending on your model)
- User Guide
- Installation Guide
- Warranty documents

## 1.2 Overview of appliances and equipment




Fig. 1 Example illustration

#### Temperature range

- (A) Fridge compartment (C) Coldest zone
- (B) BioFresh

## The appliance at a glance

#### **Equipment**

(1) Controls

(2) Fan with FreshAir activated charcoal filter

(3) Separable shelf

(4) Storage shelf

(5) InfinitySpring (6) VarioSafe

(7) Space for baking tray

(8) Variable bottle rack

(9) Cover for Fruit & Vegetable(10) Fruit & Vegetable-Safe

(11) Drain hole

(12) Nameplate

(13) Meat & Dairy-Safe

(14) Door racks

(15) Bottle holder

(16) Vario Boxes

(17) Soft-closing mechanism

Safe

▶ The shelves, drawers, and baskets are arranged for optimal energy efficiency in the factory configuration. However, changes to the arrangement within the given insertion options - for example the arrangement of shelves in the fridge compartment have no effect on energy consumption.

### 1.3 SmartDevice

SmartDevice is the networking solution for your refrigerator.

If your appliance is SmartDevice-enabled or compatible, you can guickly and easily connect your appliance to your WiFi. With the SmartDevice app, you can operate your appliance from a mobile device. Additional functions and setting options are available in the SmartDevice app.

SmartDeviceenabled ance:

Your appliance is capable of being appli- a SmartDevice. To be able to connect your device to WiFi, you need to download the SmartDevice



More information smartdevice.liebherr.com about SmartDevice:

Downloading the SmartDevice app:



After installing and configuring the SmartDevice app, you can connect your appliance to the WiFi using the SmartDevice app and the WiFi appliance function (see WiFi).

## 1.4 Range of appliance use

#### Normal use

This appliance is intended to be used in household and similar applications such as,

- staff kitchen areas in shops, offices and other working environments;
- farm houses and by clients in hotels, motels and other residential type environments;
- bed and breakfast type environments:
- catering and similar non-retail applications.

The appliance is not suitable for freezing food; All other types of uses are not permitted.

#### Foreseeable misuse

The following uses are specifically prohibited:

- Storage and cooling of medication, blood plasma, laboratory preparations or similar substances and products in accordance with the CMDCAS and FDA 510(k)
- Use outdoors
- Use in moist areas exposed to the rain
- Use in outdoor areas with very high humidity
- Use in areas at risk of explosion

Incorrect appliance use can cause damage to the stored products or cause them to spoil.

#### Climate ratings

The appliance is set to operate within specific ambient temperature limits according to its climate rating The climate rating for your appliance is printed on the rating plate

#### Note

▶ To guarantee trouble-free operation, comply with the indicated ambient temperatures.

Climate rating	for ambient temperatures from
SN	10 °C (50 °F) to 32 °C (90 °F)
N	16 °C (61 °F) to 32 °C (90 °F)

Climate rating	for ambient temperatures from
ST	16 °C (61 °F) to 38 °C (100 °F)
Т	16 °C (61 °F) to 43 °C (109 °F)
SN-ST	10 °C (50 °F) to 38 °C (100 °F)
SN-T	10 °C (50 °F) to 43 °C (109 °F)

## 1.5 Conformity

The refrigerant circuit has been tested for leaks. When installed, the appliance complies with the applicable safety regulations and with the corresponding directives.

The BioFresh compartment meets the requirements of a cold storage compartment as set out in EN ISO 8561.

## 1.6 Spare parts

Spare parts for functional and storable parts of the equipment are available for 15 years.

## 2 General safety instructions

Please keep these operating instructions in a safe place so you can refer back to them at any time.

If you pass the appliance on, please hand these operating instructions to the new owner. Read and follow these instructions. They contain safety information which is important for safe and problem-free installation and operation. Always read and follow the safety information.

### Dangers for the user:

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance. Cleaning and user maintenance must not be performed by children unless they are supervised. Children between the ages of 3 and 8 may load and unload the appliance. Children under the age of 3 must be kept away from the appliance unless they are constantly supervised.

- **IMPORTANT:** The power plug must be easily accessible so that the appliance can be disconnected from the mains quickly in an emergency. It must not be behind the back of the appliance.
- The socket must be easily accessible so that the appliance can be disconnected quickly from the electricity in an emergency. It must not be located in the area behind the appliance.
- Always hold the appliance at the plug when disconnecting it from the household power.
   Do not pull on the cable.
- Disconnect the power plug or fuse if there is a malfunction.
- Do not damage the power cable. Do not operate the appliance with a faulty power cable. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard. For Plug and Play connections, the change may be carried out by the customer.
- Repairs and work on the appliance may only be carried out by Customer Service or other specifically trained qualified personnel.
- Only install, connect and dispose of the appliance in accordance with the instructions.
- Only operate the appliance after it has been installed.
- The manufacturer is not liable for damage arising from a defective fixed water connection.

#### **Risk of fire:**

- The refrigerant contained within the appliance (specifications on the identification plate) is environmentally friendly, but flammable. Leaking refrigerant can ignite.
  - WARNING: Do not damage the refrigerant circuit.
  - Do not handle ignition sources inside the appliance.
  - WARNING: Do not use electrical appliances inside the food storage compartments of the appliance, unless they are of the type recommended by the manufacturer (e.g. steam cleaning appliances, heating appliances, ice cream makers).
  - If refrigerant leaks: Remove naked flames or ignition sources located near the area

## **General safety instructions**

- of the leak. Ventilate the room well. Contact Customer Service.
- Do not operate the appliance near explosive gases.
- Do not store or use gasoline or other flammable gases and liquids near the appliance.
- Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance. You can recognize such spray cans by the printed list of contents or by a flame symbol. Any leaking gases can be ignited by electrical components.
- Alcoholic beverages or other containers holding alcohol must always be tightly sealed for storage purposes. Any leaking alcohol can be ignited by electrical components.

## Risk of falling or toppling over:

- WARNING: To avoid a hazard due to instability of the appliance, it must be fixed in accordance with the instructions.
- Do not stand on the base, drawers, doors etc. or use them as improper supports. This applies in particular to children.

## Danger of poisoning:

- Do not consume spoiled food.
- WARNING: Connect to potable water supply only.
- Do not use any old or already premounted water supply lines.

## Danger of frostbite, feeling of numbness and pain:

 Avoid prolonged skin contact with cold surfaces or chilled/frozen food or take protective measures, e.g. wear gloves.

## Risk of injury and damage:

- Hot steam may cause injuries. Do not use any electrical heating or steam cleaning equipment, naked flames or defrosting sprays for defrosting measures.
- WARNING: Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.
- Do not remove ice using sharp objects.

- WARNING: Keep clear of obstruction all ventilation openings in the appliance enclosure or in the structure for building-in.
- WARNING: Risk of child entrapment. Before you throw away your old refrigerator or freezer:
  - Take off the doors.
  - Leave the shelves in place so that children may not easily climb inside.

## Risk of crushing:

 Do not hold onto the hinge when opening and closing the door. Fingers may become trapped.

## California Proposition 65

- WARNING: This product can expose you to chemicals including Diisononyl Phthalate (DINP), which is known to the State of California to cause cancer, and Di-isodecyl Phthalate (DIDP), which is known to the State of California to cause birth defects or other reproductive harm. For more information, go to www.P65Warnings.ca.gov

## **FCC Warning**

 Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

#### **FCC** information

- This appliance has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference from an installation in residential areas. This appliance generates, uses and can radiate radio-frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this appliance does cause harmful interference to radio or television reception, which can be determined by switching the appliance on and off, the user should try to correct the interference by one or more of the following measures:
  - Reorient or relocate the receiving antenna.

- Increase the distance between the appliance and receiver.
- Connect the appliance to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

## **FCC Radio Frequency Exposure Statement**

- This appliance is found to comply with FCC radio frequency (RF) exposure limits set for an uncontrolled environment. This transmitter must not be set up or operated in conjunction with another antenna or another transmitter.
- This appliance should be installed and operated with a minimum space of 200 mm (7 7/8 in) between the antenna and your body. The user must follow the specific operating instructions to ensure compliance with RF exposure.

#### IC information

- This appliance has license-exempt transmitters/receivers, which comply with the license-exempt Radio Standards Specification (RSS) of Innovation, Science and Economic Development Canada. Operation is subject to the following two conditions:
  - This appliance may not cause interference.
  - This device must accept any interference, including interference that may cause undesired operation of the device.

#### IC Radio Frequency Exposure Statement

- This appliance meets the IC RSS-102 limits for radiation exposure, which were defined for an uncontrolled environment. This appliance should be installed and operated so that there is a minimum space of 200 mm (7 7/8 in) between the antenna and your body.

## Symbols on the device:



The symbol may be located on the compressor. It refers to the oil in the compressor and refers to the following danger: Can be fatal if swallowed or inhaled. This notice only applies for recycling. There is no danger during normal operation.



**WARNING**: Risk of fire / flammable materials. The symbol is located on the compressor and indicates the danger from flammable materials. Do not remove the label.



This label or a similar one may be located on the rear of the appliance. This label indicates that there are vacuum insulation panels (VIP) or perlite panels in the door and/or housing. This notice only applies for recycling. Do not remove the label.

## Observe the warning messages and other detailed information in the other sections:

A	DANGER	Indicates an immediately hazardous situation, which if not avoided, will result in death or serious injury.
<u> </u>	WARNING	Indicates a hazardous situation, which if not avoided, could result in death or serious injury.
A	CAUTION	Indicates a hazardous situation, which if not avoided, could result in minor or moderate injury.
	NOTICE	Indicates a hazardous situation, which if not avoided, could result in damage to property.
	Note	Indicates useful advice and tips.

# 3 Functionality of the Touch & Swipe display

You operate your appliance using the Touch & Swipe display. You select appliance functions in the Touch & Swipe display (hereafter referred to as display) by tapping them. If you do not perform any action on the display for 10 seconds, the display either jumps back to the higher-level menu or directly to the status display.

## 3.1 Navigation and symbol explanation

In the illustrations, different symbols are used to navigate the display. The following table describes these symbols.

## Functionality of the Touch & Swipe display

Symbol	Description				
57111500	Briefly touch the display:				
	Activates/deactivates function.				
	Confirms selection.				
	Opens submenu.				
	Touch the display for a specified				
	time (e.g. 3 seconds):				
33	Activates/deactivates function of				
(03)	value.				
	Swipe left or right:				
<b>→</b> 0→	Navigate in the menu.				
	Briefly touch the Back symbol:				
	Jumps back one menu level.				
Back					
	Press and hold the Back symbol for 3 seconds:				
	Jumps back to the status display.				
Back (3S)	campo dadit to une estastat anopsia,				
<b>→</b>	Arrow with clock:				
( <u>©</u>	It takes more than 10 seconds for				
	the following message to appear in the display.				
<b>→ →</b>	Arrow with a time indication:				
2s 5s 10s	It takes the specified amount of				
20 00 100	time until the following message				
	appears in the display.				
	"Open Settings menu" symbol:				
<u> -{O}</u>	Navigates to the Settings menu and opens the settings menu.				
	If necessary: Navigate to the				
	desired function in the Settings				
	menu.				
	(see 3.2.1 Opening the Settings menu)				
	"Open Advanced menu" symbol:				
$\parallel = 2$	Navigates to the Advanced menu				
	and opens the advanced menu.				
	If necessary: Navigate to the desired function in the Advanced				
	menu.				
	(see 3.2.2 Opening expanded menu)				
No action for	, , , , , , , , , , , , , , , , , , , ,				
10 seconds	the display for 10 seconds, the display either jumps back to the				
	higher-level menu or directly to the				
	status display.				

Symbol	Description
close it again.	If you open the door and immediately close it again, the display jumps directly back to the status display.

Note: Illustrations of the display are shown in the English version.

## 3.2 Menus

The appliance functions are distributed over various menus:

Menu	Description			
Main menu	When you switch the appliance on, you are automatically in the main menu.			
	From here you can navigate to the most important appliance functions, to the Settings menu and to the Advanced menu.			
€ Settings	The Settings menu contains additional appliance functions for setting up your appliance.			
Settings menu				
Advanced menu	The advanced menu contains special appliance functions for setting up your appliance. Access to the Advanced menu is protected by the numerical code <b>151</b> .			

## 3.2.1 Opening the Settings menu




Fig. 2 Example illustration

- ► Carry out action steps according to the illustration.
- Settings menu is open.
- ► If necessary: Navigate to the desired function.

## 3.2.2 Opening expanded menu



Fig. 3




Fig. 4 Example illustration, access with numerical code 151

- ► Carry out action steps according to the illustration.
- Expanded menu is open.
- ► If necessary: Navigate to the desired function.

## 3.3 Sleep mode

If you do not touch the display for 1 minute, the display switches to sleep mode. In sleep mode, the display brightness is dimmed.

## 3.3.1 Ending sleep mode

- ► Touch the display briefly with your finger.
- Sleep mode is ended.

## 4 Start-up

## 4.1 Switching on appliance (first use)

Make sure that the following requirements are fulfilled:

- ☐ The appliance is properly installed and connected according to the installation instructions.
- All adhesive strips, adhesive and protective films and transport locks are removed from inside and on the appliance.
- All marketing leaflets are removed from the drawers.
   You are familiar with the functionality of the Touch & Swipe display. (see 3 Functionality of the Touch & Swipe display)

## Switch on the appliance using the Touch & Swipe display.

- ► If the display is in sleep mode: Briefly touch the display.
- ► Carry out action steps according to the illustration.




Fig. 5 Example illustration

- > Status display appears.
- ▶ The appliance cools to the temperature set at the factory.
- The appliance starts in demo mode (status display with DEMO appears): If the appliance starts in demo mode, you can deactivate demo mode within the next 5 minutes. (see Demo mode)

#### More information:

- Start the InfinitySpring for the first time. (see 4.2 Putting InfinitySpring into operation)
- Start the SmartDevice for the first time. (see 1.3 SmartDevice) and (see WiFi)

#### Note

The manufacturer recommends:

- ► Stock with food: Wait for around 6 hours until the set temperature is reached.
- ▶ Observe the notes on storing food. (see 5.1 Information regarding storage)

#### Note

Accessories can be purchased from the Liebherr Service Center. The address for your respective country can be found on the back of the instructions.

## 4.2 Putting InfinitySpring into operation

If your appliance is equipped with an InfinitySpring, **before the first use** you must bleed the water system for the InfinitySpring and clean the InfinitySpring.

Make sure that the following requirements are fulfilled:

- ☐ The water supply is connected. See the Installation Guide or installation instructions.
- ☐ The water tank is fitted. See the Installation Guide or installation instructions.
- $\hfill \Box$  The water filter is fitted. See the Installation Guide or installation instructions.
- ☐ Appliance is fully installed and connected.

## 4.2.1 Vent the water system

- ► Open the appliance door.
- ▶ Push a glass against the lower part of the Infinity-Spring dispenser.
- > The upper part moves out and air escapes or water flows into the glass.
- ► Continue until the water flows evenly into the glass.
- ➤ The water system is now bled.

## 4.2.2 Cleaning the InfinitySpring

(see 9.6.4 Cleaning the InfinitySpring)

## 5 Storage

## 5.1 Information regarding storage



#### **WARNING**

Danger of fire

▶ Do not use electrical appliances inside the food storage compartments of the appliance, unless they are of the type recommended by the manufacturer.

#### Note

Insufficient ventilation results in an increase in energy consumption and reduction of the refrigerating performance

Always keep the air slots unobstructed.

Observe the following specifications for storage:

- Keep the air vents on the fan free.
- Package or cover foods that readily take on or give off odors or taste in closed containers.
- Package raw meat or fish in clean, closed containers. This will prevent meat or fish from touching or dripping onto other food.
- Keep liquids in closed containers.
- Leave space between goods to ensure good air circulation.
- Store food according to the instructions on the pack-
- Always observe the best-before date indicated on the packaging.

#### Note

Failure to follow these guidelines can lead to foodstuffs spoiling.

## 5.2 Fridge compartment

The air circulation in the appliance creates different temperature zones. You will find the different temperature zones in the appliance and equipment overview. (see 1.2 Overview of appliances and equipment)

## 5.2.1 Arranging your food properly

- ▶ Upper area and door: Store butter, cheese, canned food and tubes.
- ► Coldest temperature zone: Store perishable foods such as pre-cooked meals.

## 5.3 BioFresh

BioFresh will extend the storage time for some fresh foods compared to traditional refrigeration.

Taste, freshness and nutritional value (vitamin groups B and C) are largely retained. Less spoilage and shriveling of fruit and vegetables. The food keeps fresher and retains its natural goodness.

#### Note

The temperature can drop to 0 °C (32 °F) which means foods could easily freeze.

Store cold-sensitive produce such as cucumbers, eggplants, zucchinis and tropical fruit in the fridge compartment.

## 5.3.1 Fruit & Vegetable safe 🗇 🥒 🔘





This safe creates a storage climate of close to 0 °C (32 °F). The tight lid ensures constant levels of humidity. This storage climate is suitable for storing unpackaged food with high intrinsic moisture (for example, lettuce, vegetables, fruit).

The humidity in the compartment depends on the moisture content of the chilled goods placed in it, and also depends on how often the compartment is opened. You can regulate the humidity level. (see 8.10 Humidity control)

#### Arranging your food properly

- Store unpackaged fruit and vegetables. If the humidity is too high:
- ► Regulate the humidity. (see 8.10 Humidity control)

## 5.3.2 Meat & Dairy safe 🙉 🔎 🧇





This safe creates a storage climate of close to 0 °C (32 °F). This storage climate is suitable for more sensitive foods (e.g. dairy products, meat, fish, sausage).

#### Arranging your food properly

➤ Store dry or packaged food.

## 5.4 Storage times

The storage times given are guidelines

Food with a "use by" date must still be consumed by the date indicated on the package

## 5.4.1 Fridge

The best-before date stated on the packaging applies.

## 5.4.2 BioFresh

Guideline storage times for the Meat & Dairy-Safe					
Butter	at 1 (34 °F)	°C	up to 90 days		
Hard cheese	at 1 (34 °F)	°C	up to 110 days		
Milk	at 1 (34 °F)	°C	up to 12 days		
Sausage, cold cuts	at 1 (34 °F)	°C	up to 8 days		
Poultry	at 1 (34 °F)	°C	up to 6 days		
Pork	at 1 (34 °F)	°C	up to 6 days		
Beef	at 1 (34 °F)	°C	up to 6 days		
Game	at 1 (34 °F)	°C	up to 6 days		

#### Note

► Note that higher-protein foods spoil more quickly So, shellfish and crustaceans perish faster than fish, and fish perishes faster than meat.

Guideline storage times for the Fruit & Vegetable- Safe					
Vegetables, lettuce					
Artichokes	at 1 (34 °F)	°C	up to 14 days		
Celery	at 1 (34 °F)	°C	up to 28 days		
Cauliflower	at 1 (34 °F)	°C	up to 21 days		
Broccoli	at 1 (34 °F)	°C	up to 13 days		
Endives	at 1 (34 °F)	°C	up to 27 days		

Guideline storage times for the Fruit & Vegetable- Safe					
Mâche	at 1 (34 °F)	°C	up to 19 days		
Peas	at 1 (34 °F)	°C	up to 14 days		
Kale	at 1 (34 °F)	°C	up to 14 days		
Carrots	at 1 (34°F)	°C	up to 80 days		
Garlic	at 1 (34 °F)	°C	up to 160 days		
Cabbage turnip	at 1 (34 °F)	°C	up to 14 days		
Iceberg lettuce	at 1 (34 °F)	°C	up to 13 days		
Herbs	at 1 (34 °F)	°C	up to 13 days		
Leeks	at 1 (34 °F)	°C	up to 29 days		
Mushrooms	at 1 (34 °F)	°C	up to 7 days		
Radishes	at 1 (34 °F)	°C	up to 10 days		
Brussels sprouts	at 1 (34 °F)	°C	up to 20 days		
Asparagus	at 1 (34 °F)	°C	up to 18 days		
Spinach	at 1 (34 °F)	°C	up to 13 days		
Savoy cabbage	at 1 (34 °F)	°C	up to 20 days		
Fruit					

## **Energy saving**

Guideline storage times for the Fruit & Vegetable- Safe						
Apricots	at 1 (34 °F)	°C	up to 13 days			
Apples	at 1 (34 °F)	°C	up to 80 days			
Pears	at 1 (34 °F)	°C	up to 55 days			
Blackberries	at 1 (34 °F)	°C	up to 3 days			
Dates	at 1 (34 °F)	°C	up to 180 days			
Strawberries	at 1 (34 °F)	°C	up to 7 days			
Figs	at 1 (34 °F)	°C	up to 7 days			
Blueberries	at 1 (34 °F)	°C	up to 9 days			
Raspberries	at 1 (34 °F)	°C	up to 3 days			
Red currants	at 1 (34 °F)	°C	up to 7 days			
Cherries, sweet	at 1 (34 °F)	°C	up to 14 days			
Kiwi	at 1 (34 °F)	°C	up to 80 days			
Peaches	at 1 (34 °F)	°C	up to 13 days			
Plums	at 1 (34 °F)	°C	up to 20 days			
Cranberries	at 1 (34 °F)	°C	up to 60 days			
Rhubarb	at 1 (34 °F)	°C	up to 13 days			

Guideline storage times for the Fruit & Vegetable- Safe					
Gooseberries	at 1 (34 °F)	°C	up to 13 days		
Grapes	at 1 (34 °F)	°C	up to 29 days		

## 6 Energy saving

- Always ensure good ventilation. Keep clear of obstruction all ventilation openings in the appliance enclosure or in the structure for building-in.
- Never block air slits in the fan.
- Do no install the appliance in an area with direct sunlight, next to a heating unit or similar.
- If you install the appliance directly next to an oven, its energy consumption may increase slightly. This depends on the service life and how often the oven is used.
- Energy consumption depends on installation conditions such as the ambient temperature (see 1.4 Range of appliance use). A warmer ambient temperature can increase the energy consumption.
- Avoid opening the appliance door for any longer then necessary
- The lower the temperature is set the higher the energy consumption.
- Sort your food items: home.liebherr.com/food.
- All food stored in the appliance should be well wrapped and covered. This prevents frost buildup.
- Only take food out for as long as necessary so that it does not get too warm.
- Insertion of warm foods: first let the food cool down to room temperature.
- For longer periods of absence, use HolidayMode (see HolidayMode).

## 7 Use

## 7.1 Controls and displays

## 7.1.1 Status display




Fig. 6 Status display shows the actual temperature.

- (1) Fridge compartment temperature display
- (2) Temperature display BioFresh

The status display shows the actual temperature and is the initial display. You can navigate from there to the functions and settings.

## 7.1.2 Display symbols

The display symbols provide information about the current appliance status.

Symbol	Appliance status
$\bigcirc$	<b>Standby</b> The appliance or temperature zone is turned off.
-5 <del>-</del> 5 <del>- c</del>	<b>Flashing number</b> Appliance is working. Tempera-
=18 <sub>0</sub>	ture flashes until the set temperature is reached.
	Flashing symbol
	Appliance is working. Setting is made.

## 7.2 Appliance functions

## 7.2.1 Notes on the appliance functions

The appliance functions are set at the factory so that your appliance is fully functional.

Before you alter, activate or deactivate the appliance functions, make sure that the following requirements are met:

- ☐ You have read and understood the descriptions of how the display works. (see 3 Functionality of the Touch & Swipe display)
- ☐ You have familiarized yourself with the operating and display elements of your appliance.



## Switching appliance off and on

This function switches the entire appliance on and off.

#### Switching off the appliance

If you switch off the appliance, the settings that were made before remain stored.

Make sure that the following requirements are fulfilled:

☐ Handling instructions (see 11 Decommissioning) have been completed.



Fig. 7




Fig. 8

- ► Carry out action steps according to the illustration.
- ▶ Appliance is switched off.
- > Standby symbol appears in the display.
- Display turns black.

#### Switching on the appliance

If the display is in sleep mode:

► Briefly touch the display.




Fig. 9 Example illustration

- ► Carry out action steps according to the illustration. If the appliance starts in demo mode:
- ▶ Deactivate demo mode. (see Deactivating demo mode)
- ▷ Appliance is switched on.
- Previously made settings are re-established.
- ➤ The appliance cools to the set target temperature.



#### WiF

Use this function to connect your appliance to WiFi. You can then operate it via the SmartDevice app on a mobile device. You can also use this function to disconnect or reset the WiFi connection.

More information on the SmartDevice: (see 1.3 SmartDevice)

#### Note

The SmartDevice function is not available in the following countries: Russia, Belarus, Kazakhstan.

#### Establishing the WiFi connection for the first time

Make sure that the following requirements are fulfilled:

- ☐ You have installed the SmartDevice app (see apps.home.liebherr.com).
- ☐ Registration in the SmartDevice app is completed.



Fig. 10




Fig. 11

► Carry out action steps according to the illustration. ▷ Connection is established.

#### Disconnecting from the WiFi



Fig. 12




Fig. 13

► Carry out action steps according to the illustration. 

☐ There is no connection.

#### Resetting the WiFi connection



Fig. 14





Fig. 15

- ► Carry out action steps according to the illustration.

#### Showing information about the WiFi connection



Fig. 16



Fia. 17

► Carry out action steps according to the illustration.

## 5 Temperature

Use this function to set the temperature.

The temperature depends on the following factors:

- How often the door is opened
- How long the door is open
- The room temperature of the installation site
- Type, temperature and amount of food

Temperature zone	Factory-set temperature	Recommended setting	
5 ° Fridge section	5 °C (41 °F)	4 °C (39 °F)	
0 ° BioFresh	0 °C (32 °F)	B-Value (see BioFresh B- Value )	

#### Setting the temperature in the fridge section




Fig. 18 Example illustration

- ► Carry out action steps according to the illustration.
- > Temperature is set.

#### Setting the temperature in BioFresh

You set the temperature using the BioFresh B-Value. (see BioFresh B-Value)




## Temperature unit

Use this function to set the temperature unit. You can set the temperature unit in either degrees Celsius or degrees Fahrenheit.

#### Setting the temperature unit



Fig. 19



- Fig. 20 Example illustration: Switching between degrees Celsius or degrees Fahrenheit.
- ► Carry out action steps according to the illustration.
- ▶ Temperature unit is set.

### BioFresh B-Value

Use this function to set the BioFresh B-Value. Use the BioFresh B-Value to adjust BioFresh slightly warmer or colder if a higher or lower ambient temperature makes it necessary. Upon delivery, the BioFresh B-Value is set to the value B5. If you adjust the B-Value, please observe the following table:

Value	Description
B1	Lowest temperature
B1-B4	The temperature can drop to 0 °C (32 °F) which means foods could easily freeze.
B5	Pre-set temperature
В9	Highest temperature

## Setting the BioFresh B-Value



Fig. 21




Fig. 22 Example illustration: Switching from B5 to B6.

- ► Carry out action steps according to the illustration.
- The BioFresh B-Value is set.
- > Status display shows the target temperature.

## D1 <sub>D-Value</sub>

The D-Value is preset for your appliance and must not be changed.



## SuperCool

This function activates or deactivates SuperCool. If you activate SuperCool the appliance increases the cooling capacity. This allows you to achieve lower cooling temperatures. You can activate SuperCool if you want to quickly cool large volumes of food.

If the function is active, the appliance operates at a higher output. As a result, the operating noise of the appliance may be temporarily louder, while energy consumption increases.

#### **Activating SuperCool**

Time for activating the function:

- If you want to store fresh food in the fridge section: Activate the function when storing food.



Fig. 23




Fig. 24

- ► Carry out action steps according to the illustration.
- -or-
- ► Activating with the SmartDevice app.
- > SuperCool is activated.
- > Temperature display turns blue.

### **Deactivating SuperCool**

SuperCool is automatically deactivated after 18 hours. However, you can also manually deactivate SuperCool at any time:



Fig. 25




Fig. 26

- ► Carry out action steps according to the illustration. -or-
- ▶ Deactivating with the SmartDevice app.
- SuperCool is deactivated.
- ▶ Appliance continues to run in normal operation.
- $\triangleright$  The appliance first cools to the set temperature.



## **PartyMode**

This function activates and deactivates PartyMode. PartyMode activates different functions that are useful for a party.

PartyMode activates the following functions:

- SuperCool (see SuperCool)

You can set all listed functions individually and flexibly. By deactivating PartyMode all changes are discarded.

If the function is active, the appliance operates at a higher output. As a result, the operating noise of the appliance may be temporarily louder, while energy consumption increases.

#### **Activating PartyMode**



Fig. 27




Fig. 28

- ► Carry out action steps according to the illustration.
- > PartyMode and the corresponding functions are activated
- > Temperature display turns blue.
- The current temperature flashes until the target temperature is reached.

#### **Deactivating PartyMode**

PartyMode is automatically deactivated after 24 hours. However, you can also manually deactivate PartyMode at any time:



Fig. 29




Fig. 30

- ► Carry out action steps according to the illustration.
- ▶ PartyMode is deactivated.
- ➤ The appliance first cools to the set temperature: The current temperature flashes until the target temperature is reached.



# HolidayMode

Use this function to activate or deactivate Holiday-Mode. If you activate HolidayMode the fridge section is set to 15 °C (59 °F). This helps you save energy if you are away for a longer period of time and avoid bad smells and mold formation.

#### Appliance status with active HolidayMode

Fridge section cools to 15 °C (59 °F).

BioFresh cools down to 15 °C (59 °F).

PartyMode is deactivated.

SuperCool is deactivated.

#### Activating HolidayMode

- ► Empty the fridge section completely.
- ► Empty BioFresh completely.



Fig. 31




Fig. 32

- ► Carry out action steps according to the illustration.
- > Temperature display turns blue and shows the HolidayMode symbol.

#### Deactivating HolidayMode



Fig. 33




Fig. 34

- ► Carry out action steps according to the illustration.
- ➤ The appliance first cools to the set temperature.



# SabbathMode

This function activates and deactivates SabbathMode. If you activate this function, some electronic functions are switched off. Your appliance thereby meets the religious requirements of Jewish holidays such as the Sabbath and complies with STAR-K Kosher certifica-

#### Appliance status with active SabbathMode

The status display continuously shows SabbathMode.

All functions in the display except the **Deactivating** SabbathMode function are disabled.

Active functions remain active.

The display remains bright when you close the door.

The interior lighting is deactivated.

Memories are not listed. The set time interval is stopped.

Memories and warnings are not displayed.

There is no door alarm.

There is no temperature alarm.

The InfinitySpring is out of order.

The defrost cycle operates only for the specified time without taking into account the appliance usage.

After a power failure, the device returns to SabbathMode.

Appliance status

#### Note

This appliance has certification from the "Institute for Science and Halacha". (www.machonhalacha.co.il)

You can find a list of STAR-K-certified appliances at www.star-k.org/appliances.

#### **Activating SabbathMode**



#### WARNING

Danger of poisoning from spoiled food!

If you have SabbathMode activated and a power failure occurs, no message appears in the status display about the power failure. Once the power is restored, the appliance continues to operate in SabbathMode. The power failure may mean that food spoils and the consumption of this food could lead to food poisoning. After a power failure:

▶ Do not consume food that has been frozen and thawed.



Fig. 35




Fig. 36

- ► Carry out action steps according to the illustration.
- SabbathMode is activated.
- > Status display continuously shows SabbathMode.

#### **Deactivating SabbathMode**

SabbathMode is automatically deactivated after 80 hours. However, you can also manually deactivate SabbathMode at any time:




Fig. 37

- ► Carry out action steps according to the illustration.
- SabbathMode is deactivated.



## **EnergySaver**

Use this function to activate or deactivate energy saving mode. If you activate energy saving mode, energy consumption drops and the temperature in the appliance increases. Food remains fresh, but shelf life is reduced.

Temperature zone		Recommended setting (see Setting temperature in fridge section)		ure Ener- is
5 csection	Fridge	4 °C (39 °F)	7 °C (45 °	F)

Temperatures

#### **Activating EnergySaver**



Fig. 38



Fia. 39

► Carry out action steps according to the illustration.

Energy saving mode is activated.

#### Deactivating EnergySaver



Fig. 40




Fig. 41

- ► Carry out action steps according to the illustration.
- Energy saving mode is deactivated.

## Cl

## CleaningMode

This function activates and deactivates CleaningMode. CleaningMode enables you to comfortably clean the appliance.

This setting relates to the fridge compartment.

#### Application:

- Clean the fridge compartment. (see 9.6 Cleaning the appliance)
- Clean the InfinitySpring. (see 9.6.4 Cleaning the InfinitySpring)

#### Appliance status with active CleaningMode

The status display continuously shows CleaningMode.

The fridge section is switched off.

The interior lighting is activated.

Reminders and warnings are not displayed. No signal tone is sounded.

The InfinitySpring is out of order.

Appliance status

#### **Activating Cleaning Mode**



Fig. 42



Fig. 43

- Carry out action steps according to the illustration.
- CleaningMode is activated.

Status display continuously shows CleaningMode.

#### **Deactivating Cleaning Mode**

CleaningMode is automatically deactivated after 60 minutes. However, you can also manually deactivate CleaningMode at any time:




Fig. 44

- ► Carry out action steps according to the illustration.
- ▷ CleaningMode is deactivated.
- ➤ The appliance first cools to the set temperature.



## **Display Brightness**

Use this function to set the brightness of the display gradually.

You can set the following brightness levels:

- 40 %
- 60 %
- 80 %
- 100% (default setting)

#### Setting the brightness



Fig. 45




Fig. 46 Example illustration: Switching from 80 % to 60 %.

▶ Carry out action steps according to the illustration.

- ▶ Brightness is set.

## Door alarm

Use this function to activate or deactivate the door alarm. The door alarm sounds if the door is open for too long. The door alarm is activated upon delivery. You can set how long to door can remain open until the door alarm sounds.

You can set the following values:

- 1 minute

- 2 minutes
- 3 minutes
- Off

#### Setting the door alarm



Fig. 47




Fig. 48 Example illustration: Changing the door alarm from 1 minute to 3 minutes.

- ► Carry out action steps according to the illustration.
- Door alarm is set.

### **Deactivating door alarm**



Fig. 50




Fig. 51

- ► Carry out action steps according to the illustration.
- Door alarm is deactivated.

## Input lock

This function activates and deactivates the input lock. The input lock prevents the appliance from being operated accidentally, e. g. by children.

#### Application:

- Prevent unintentional changes of functions.
- Prevent switching off of the appliance.
- Prevent unintentional temperature setting.

#### Activating the input lock

If you activate the input lock, you can continue to navigate in the menus, however you cannot select or modify other functions.



Fig. 52



Fig. 53

► Carry out action steps according to the illustration. 

> Input lock is activated.

#### Deactivating the input lock



Fig. 54



Fig. 55

► Carry out action steps according to the illustration. > Input lock is deactivated.



## Language

Use this function to set the display language.

You can set the following languages:

- German
- English
- French
- Spanish
- Italian
- Dutch
- Czech
- Polish
- Portuguese
- Bulgarian
- Russian
- Chinese

#### Setting the language



Fig. 56




Fig. 57 Example illustration depending on the language and temperature

- ► Carry out action steps according to the illustration.
- ▶ Language is set.
- Display jumps back to the status display.



## **Appliance information**

Use this function to display the model name, index, serial number and service number of your appliance. You will need the appliance information when you contact customer service. (see 10.4 Customer Service)

You also use this function to open the expanded menu. (see 3 Functionality of the Touch & Swipe display)

#### Display appliance information



Fig. 58



Fig. 59

- ► Carry out action steps according to the illustration.
- Display shows the appliance information.



## Software

Use this function to display the software version of your appliance.

#### Display software version



Fig. 60




Fig. 61

► Carry out action steps according to the illustration. 
▷ Display indicates the software version.



#### Reminder

Use this function to activate or deactivate reminder. This function is activated upon delivery.

The following reminders will then appear if the function is activated:

- Replace water filter (see Replace water filter)
- Replace the FreshAir activated charcoal filter (see Replace FreshAir activated charcoal filter)

#### **Activating reminder**



Fig. 62




Fig. 63

- ► Carry out action steps according to the illustration. Reminder is activated.
- **Deactivating reminder**



Fig. 64



Fig. 65

- ► Carry out action steps according to the illustration.
- ▶ Reminder is deactivated.

## Demo

#### Demo mode

Demo mode is a special feature for dealers who want to demonstrate appliance features. If you activate demo mode, all refrigeration functions are deactivated. If you switch on your appliance and "Demo" appears in the status display, then demo mode is already activated.

If you activate and then deactivate demo mode, the appliance will be reset to factory defaults. (see Resetting to factory settings)

#### Activating demo mode



Fig. 66




Fig. 67

- ► Carry out action steps according to the illustration.
- $\triangleright$  Demo mode is activated.
- ▶ Appliance is switched off.
- Switch on the appliance. (see 4.1 Switching on appliance (first use))
- ▷ "DEMO" appears in the status display.

#### Deactivating demo mode



Fig. 68




Fig. 69

- ► Carry out action steps according to the illustration.
- Demo mode is deactivated.
- ▷ Appliance is switched off.
- ➤ Switch on the appliance. (see 4.1 Switching on appliance (first use))
- ▶ Appliance is reset to factory settings.



## Resetting to factory settings

Use this function to reset all settings to factory settings. All settings you have made so far are reset to their original settings.

#### Performing a reset



Fig. 70




Fig. 71

► Carry out action steps according to the illustration.

- $\triangleright$  Appliance is reset.
- > Appliance is switched off.
- ► Restart the appliance. (see 4.1 Switching on appliance (first use))

## 7.3 Messages

There are two categories of messages:

Category	Meaning
Warning	Warnings are displayed if there is a door alarm or a malfunction.
	You can easily end warnings yourself. For any major malfunction, you must contact Customer Service. (see 10.4 Customer Service)
Reminder	Reminders remind you of general processes. You can perform these processes and end the message doing so.

## 7.3.1 Overview of warnings

The appliance's behavior in the event of a warning:

- Warning appears in the display in red.
- Alarm sounds in increasing volume.
- For some warnings the interior lighting pulses.

Message	Cause	Ending the message
Close the door.  Door alarm	The message appears if the door is open for too long.	
Error	This message appears if there is an appliance error. An appliance module indicates an error.	action steps
WiFi Error WLAN error	This message appears if the appliance could not be connected to the WLAN. (see Establishing the WiFi connection for the first time)	action steps (see WLAN

## 7.3.2 Ending warnings

#### Door alarm




Fig. 72 Example illustration

► Carry out action steps according to the illustration.

#### -or-

Close the door.

Display skips to status display.

You can set how long to door may remain open until the door alarm sounds. (see Setting the door alarm)

#### **Error**




Fig. 73 Example illustration

- ► Briefly touch the display.
- ► Make a note of the error code.
- ▶ Briefly touch the display.
- Display skips to status display.
- ► Contact Customer Service. (see 10.4 Customer Service)

#### WLAN error

- ► Check the WLAN connection.
- ► Connect the appliance to the WLAN again. (see WiFi)

#### 7.3.3 Overview of reminders

The appliance's behavior in the event of a reminders:

- Reminder appears in the display in yellow.
- Alarm tone sounds.
- For some reminders the interior lighting pulses.

Message	Cause	Ending the message
Water filter  Replace water	This message appears if you have to replace the water filter.	steps (see Replace
filter		
FreshAir filter  Replace the FreshAir activated charcoal filter	This message appears if you have to replace the activated charcoal filter.	steps (see Replace FreshAir acti-

## 7.3.4 Ending reminders

#### Replace water filter

Liebherr recommends: Replace water filter of the InfinitySpring every 6 months.

#### Note

The water filter can be purchased from the Liebherr Service Center. The address for your respective country can be found on the back of the instructions.




Fig. 74 Example illustration

- ► Briefly touch the display.
- Display shows information about the reminder.
- ► Briefly touch the display.
- ► Replace water filter. (see 9.3 Water filter)
- ▶ Reminder appears again after 6 months.

If you no longer want to keep this reminder, you can deactivate the reminder. (see Deactivating reminder)

#### Replace FreshAir activated charcoal filter

Liebherr recommends: Replace the FreshAir activated charcoal filter every 6 months.

#### Note

FreshAir activated charcoal filters can be purchased from the Liebherr Service Center. The address for your respective country can be found on the back of the instructions.




Fig. 75 Example illustration

- ► Briefly touch the display.
- Display shows information about the reminder.
- ► Briefly touch the display.
- ► Replace activated charcoal filter. (see 9.1 FreshAir carbon filter)
- The activated charcoal filter ensures optimum air quality in the refrigerator.
- ▶ Reminder appears again after 6 months.

## **Equipment**

If you no longer want to keep this reminder, you can deactivate the reminder. (see Deactivating reminder)

## 8 Equipment

## 8.1 Door racks

## 8.1.1 Moving/removing door racks




Fig. 76

- ► Slide racks up.
- ▶ Pull to the front.
- ► Re-insert in reverse order.




Fig. 77

You can use just one or both VarioBoxes. To store oversized bottles, suspend just one box over the bottle rack.

#### Move the VarioBox shelf:




Fig. 78

- ▶ Pull up and out.
- ► Replace at any position.

#### Moving the VarioBoxes:




Fig. 79

If the door rack is removed:

► Remove boxes.





Fig. 80

▶ Place the shelf on the table.



Fia. 81

- ▶ Pull off the middle holder Fig. 81 (1).
- ▶ Insert the middle holder in the second position Fig. 81 (2).




Fig. 82

► Replacing boxes.

#### 8.1.2 To dismantle door racks

The door racks can be disassembled for cleaning.




Fig. 83




Fig. 84

▶ Disassemble the door racks.

#### 8.2 Shelves

## 8.2.1 Moving/removing shelves



#### CAUTION

Broken shelves!

Danger of cuts.

 Only remove storage shelves when there is nothing on them

Extension stops secure the shelves against being accidentally pulled out




Fig. 85

- ► Lift the shelf and pull to the front.
- Side recess to shelf position.
- ► Reposition the shelf: Lift up or lower to the desired height and insert.

-or-




Fig. 86

- ► Take out the shelf completely: Pull out to the front.
- ► Easier removal: Set the shelf at an angle.
- ► Reinsert the shelf: Push it in to its stop limit.
- ▶ Pull-out stoppers are pointing down.
- ▶ Pull-out stoppers are behind the front shelf.

## 8.3 Split shelf

## 8.3.1 Using the split shelf



## CAUTION

Broken shelves!

Danger of cuts.

▶ Only remove storage shelves when there is nothing on them

Extension stops secure the shelves against being accidentally pulled out




Fig. 87

▶ Push the split shelf underneath as in the illustration




Fig. 88

#### Adjusting heights:

- ▶ Pull the glass panels out Fig. 88 (1) from the front, one at a time.
- ► Pull the support rails out of their retainers and snap into place at the height you want them.
- ► Slide in the glass panels one at a time.

## **Equipment**

- > Flat pull-out stoppers at the front, right behind the support rail.
- > Taller pull-out stoppers at the back.

#### Using both shelves:

- ▶ Hold the bottom glass panel with one hand and pull it to the front.
- > The glass panel Fig. 88 (1) with the trim strip is at the front.
- ▶ The stops Fig. 88 (3) point downward.

## 8.4 VarioSafe

The VarioSafe offers space in the refrigerator compartment for small groceries, packages, tubes and jars, for example.




Fig. 89

- (1) VarioSafe drawer
- (3) Recesses on the left
- (2) Side panels with ribs for VarioSafe drawer
- and right side panel

## 8.4.1 Inserting the VarioSafe




Fig. 90

▶ Insert the VarioSafe into the refrigerator compartment at an angle Fig. 90 (1) until the recesses in the side Fig. 90 (2) of the VarioSafe are at the level of the support rib in the refrigerator compartment.




Fig. 91

- ► Set VarioSafe straight. Fig. 91 (1)
- ► Lift VarioSafe at the front. Fig. 91 (2)




Fig. 92

- Lift VarioSafe up toward the front.
- ► Push VarioSafe in to the rear.
- Lower VarioSafe.
- ∀arioSafe is inserted.

## 8.4.2 Repositioning the VarioSafe

You can move the VarioSafe as a whole in the refrigerator compartment.




Fig. 93

► Lift VarioSafe at the front.




Fig. 94

- ▶ Pull VarioSafe forwards until the recesses in the side of the VarioSafe are at the level of the support rib in the refrigerator compartment. Fig. 94 (1)
- ► Move VarioSafe up or down in the refrigerator compartment until the desired height is reached. Fig. 94 (2)




Fig. 95

- ► Lift VarioSafe at the front.
- ▶ Push VarioSafe in to the rear.

- ∀arioSafe audibly engages.
- ∇arioSafe is offset in height.

## 8.4.3 Moving the VarioSafe drawer

You can use the VarioSafe drawer at two different heights. If you would like to store taller foodstuffs in the VarioSafe drawer, slide the VarioSafe drawer in on the bottom rib. If you would like to store smaller foodstuffs in the VarioSafe drawer, slide the VarioSafe drawer in on the top rib.





Fig. 96

- ▶ Pull out the VarioSafe drawer as far as it will go.
- ► Lift the VarioSafe drawer up at the front.
- ► Remove the VarioSafe drawer to the front.



Fia 97

- ▶ Lift the VarioSafe drawer up at the front.
- ▶ Place the VarioSafe drawer behind the stoppers on desired rib Fig. 97 (1) or Fig. 97 (2).
- ▷ VarioSafe drawer is offset in height.

## 8.4.4 Removing the VarioSafe

You can remove the VarioSafe as a whole.

## **Equipment**




Fig. 98

► Lift VarioSafe at the front.




Fig. 99

▶ Pull VarioSafe forward Fig. 99 (1) until the recesses in the side of the VarioSafe are at the level of the support rib in the refrigerator compartment. Fig. 99 (2)




Fig. 100

- ► Set VarioSafe in refrigerator compartment at an angle. Fig. 100 (1)
- ► Take VarioSafe out to the front. Fig. 100 (2)
- ∀arioSafe is removed.

## 8.4.5 Disassembling the VarioSafe

You can disassemble the VarioSafe into its individual parts if you want to clean the VarioSafe or if you need to install or remove parts.




Fig. 101

- Remove VarioSafe as a whole. (see 8.4.4 Removing the VarioSafe )
- ▶ Disassemble VarioSafe according to the illustration.

## 8.5 InfinitySpring

The built-in water dispenser provides convenient drinking water. The water temperature depends on the temperature in the fridge.




Fig. 102

- ► Push the glass against the button pushbutton of the dispenser.
- The outlet unit moves out: water pours into the glass.
- Avoid splashes: Remove the glass slowly. If dispensing larger quantities of water:
- ▶ If the water flow stops, remove the water tank and push your container against the button push button of the dispenser again.

## 8.6 Space for baking tray

There is space for a baking tray Fig. 1 (7) above the drawers.




Fig. 103

Make sure that the following requirements are fulfilled

- ☐ Max. baking tray dimensions are adhered to (see 10.1 Technical specifications).
- ☐ Baking tray has cooled to room temperature.
- ☐ The bottom door stopper is set at least one position up.

When door 90° is open:

- ▶ Slide the baking tray onto the lower side runs.
- -or-

If baking tray is uneven:

▶ Use the supplied support rails.




Fig. 104

- ► Snap support rails into the lowest runs. When door 90° is open:
- ► Slide the baking tray in on the support rails.

### 8.7 Variable bottle shelf

## 8.7.1 Using the bottle shelf

Use the variable bottle shelf or the glass panel placed on the fridge floor.




Fig. 105

- ► Remove the glass shelf and store separately.
- ▶ Place the bottles with the base pointing backwards facing the rear wall

#### Note

If the bottles protrude over the front of the bottle shelf:

► Move the bottom door rack higher up.

## 8.7.2 Removing the bottle shelf

You can remove the bottle shelf for cleaning.

▶ Remove the glass panel above the bottle shelf.




Fig. 106

▶ Lift the bottle shelf at the front and pull out.

#### Note

Liebherr recommends the following:

Do not place any goods on the drawer cover below.

## 8.7.3 Inserting the bottle shelf




Fig. 107

- ► Slide in the bottle shelf until it engages and push down.
- > The lugs at the back of the bottle shelf are connected automatically.
- ▷ LED lights up.

### 8.8 Drawers

You can remove the drawers for cleaning.

The way to remove/insert the drawers varies depending on the pull-out system. Your appliance can contain a variety of pull-out systems.

#### Note

Insufficient ventilation results in an increase in energy consumption and reduction of the refrigerating performance.

▶ Never obstruct the vents on the interior rear wall!

## **Equipment**

## 8.8.1 Drawer on telescopic rails

The drawer runs on full-extension rails (telescopic rails). There are full-extension telescopic rails and telescopic rails with partial pull-out. Drawers which are full extension can be pulled out fully from the appliance. Drawers with partial pull-out cannot be pulled out fully from the appliance. The system in your appliance depends on the type of appliance.

#### Full extension\*

If you have full-extension rails, there is a clamp located at the back on the left and right of the rail.

#### Removing drawer




Fig. 108

- ▶ Pull out drawer as far as it will go.
- ► Lift left clamp and simultaneously pull drawer forwards on the left. Fig. 108 (1)
- ► Lift right clamp and simultaneously pull drawer forwards on the right. Fig. 108 (2)
- ▶ Remove drawer to the front. Fig. 108 (3)
- ► Slide rails in.

### Inserting drawer




Fig. 109

- ► Slide rails in.
- ▶ Place drawer on rails.
- ▶ Slide in drawer to the back.
- Drawer latches in audibly at the back.

### Partial pull-out fridge compartment\*

## Removing drawer




Fig. 110

- ▶ Pull out the drawer halfway. Fig. 110 (1)
- Press down the drawer on the front. Fig. 110 (2)
- ▶ Push in the left rail approximately 2 cm (13/16 in). Fig. 110 (3)

- ▶ Push in the right rail approximately 2 cm (13/16 in). Fig. 110 (4)
- ► Remove drawer to the front. Fig. 110 (5)




Fig. 111

If the rails are not yet fully pushed in after removing the drawer:

▶ Push the rails in completely.

#### Inserting drawer




Fig. 112

- ► Slide rails in.
- ▶ Place drawer on rails.
- ➤ Slide in drawer to the back.

## 8.9 Fruit & Vegetable-Safe cover

The compartment lid can be removed for cleaning.

## 8.9.1 Removing the compartment lid

Make sure that the following requirements are fulfilled 
☐ Bottle shelf is removed .




Fig. 113

If the drawers are removed:

- ▶ Pull the lid up at the front in the retaining parts to the opening Fig. 113 (1).
- ▶ Lift from the back and pull it up and out Fig. 113 (2).

## 8.9.2 Inserting the compartment lid




Fig. 114

If the text THIS SIDE UP is on top:

- ▶ Insert the lip of the cover over the opening of the rear bracket Fig. 114 (1) and click into place Fig. 114 (2).
- ► Position the cover where you want it (see 8.10 Humidity control).

## 8.10 Humidity control

You can regulate the moisture in the drawer yourself by adjusting the compartment cover.

The compartment cover is on the drawer itself and can be covered with shelves or additional drawers.




Fig. 115

#### Low air humidity

- ▶ Open the drawer.
- ▶ Pull the drawer cover to the front.
- ▷ If the drawer is closed: Gap between lid and compartment.

#### High air moisture:

- ▶ Open the drawer.
- ► Slide the compartment cover to the back.
- > If the drawer is closed: The cover seals the compartment.
- ► Choose a "low moisture setting".

#### -or-

► Remove the moisture with a cloth.

#### Note

With the "low humidity" setting, the Fruit & Vegetable-Safe can also be used as a Meat & Dairy-Safe.

► Choose a "low moisture" setting.

#### 8.11 Butter dish

## 8.11.1 Opening/closing the butter dish




Fig. 116

## 8.11.2 Dismantling the butter dish

You can disassemble the butter dish for cleaning.




Fig. 117

▶ Disassemble the butter dish.

## 8.12 Egg rack

You can pull out and turn the egg rack. You can use both sides of the egg rack so you can label specifics like the purchase date.

## **Equipment**

## 8.12.1 Using the egg rack




Fig. 118

- ► Top section: store hen eggs.
- ► Bottom section: store quail eggs.

## 8.13 Bottle rack

## 8.13.1 Using the bottle rack




Fig. 119

- ► Slide the bottle rack at the edges.
- Stops bottles from tipping over.

## 8.13.2 Removing the bottle rack




Fig. 120

- ▶ Slide the bottle rack all the way to the right edge.
- ► Remove to the back.

## 8.14 FlexSystem

## 8.14.1 Using the FlexSystem

The FlexSystem helps you store and arrange food clearly and in the way you want. It lets you clearly divide your food into fruit, vegetables or by use-by dates, for example.




Fig. 121

▶ Move the inside tray.

## 8.14.2 Removing the FlexSystem




Fig. 122

- ▶ Lift the FlexSystem at the back.
- Pull up and out.

## 8.14.3 Inserting the FlexSystem




Fig. 123

- ► Insert front of the FlexSystem first.
- ► Lower the back part.

## 8.14.4 Disassembling the FlexSystem

The FlexSystem can be dismantled for cleaning.




Fig. 124

▶ Dismantling the FlexSystem.

## 9 Maintenance

## 9.1 FreshAir carbon filter

The FreshAir carbon filter is located in the compartment above the fan.

It guarantees the best air quality.

- ☐ Change the carbon filter every 6 months.

  When the reminder is set, a message on the display prompts you to change it.
- ☐ You can dispose of the carbon filter with the regular household waste.

#### Note

FreshAir activated charcoal filters can be purchased from the Liebherr Service Center. The address for your respective country can be found on the back of the instructions.

## 9.1.1 Removing the FreshAir carbon filter




Fig. 125

- ▶ Pull out the compartment Fig. 125 (1).
- ▶ Remove the carbon filter Fig. 125 (2).

## 9.1.2 Inserting the FreshAir carbon filter




Fig. 126

- ► Insert the carbon filter as shown in the diagram Fig. 126 (1).
- ▶ The carbon filter clicks into place.
  If the carbon filter is pointing downwards:
- ▶ Push the compartment in Fig. 126 (2).
- The carbon filter is now ready for use.

### 9.2 Water tank

The InfinitySpring water tank is located behind the lowest drawer.

## 9.2.1 Removing the water tank

- ► Turn off the water tap.
- ► Run the InfinitySpring for 30 seconds and collect the remaining water in a glass.
- ▶ Remove the drawer.
- ► Turn the water tank all the way to the left and pull it
- > Water dripping out is collected in the drip tray.
- ▶ Drain the water from the drip tray.
- ► Clean the drip tray with a cloth or in the dishwasher.

## 9.2.2 Inserting the water tank




Fig. 127

- ► Remove the drawer.
- ► Insert the water tank and turn approx. 90° to the right until it engages.
- Check that the water tank is sealed and no water leaks out.

## Maintenance

- ► Insert the drawer.
- Turn on the water tap.
- ▶ Bleed the water system. (see 4.2.1 Vent the water system)

Instead of the water filter, you can use an additional water tank.

#### Note

The water tank is available as a spare part.

## 9.2.3 Removing / inserting the drip tray

You can remove the drip tray for cleaning.




Fig. 128

▶ Pull out the drip tray to the front.

## 9.3 Water filter

The water filter is located behind the lowest drawer. It absorbs deposits in the water and reduces the taste of chlorine.

- □ Replace the water filter at least every 6 months under the specified usage conditions or if the flow rate drops significantly.
- ☐ The water filter contains carbon and can be disposed of with the regular household waste.

#### Note

The water filter can be purchased from the Liebherr Service Center. The address for your respective country can be found on the back of the instructions.

## 9.3.1 Removing the water filter

- ► Remove the drawer.
- ► Turn the water filter all the way counterclockwise and pull it out.
- ▶ Water dripping out is collected in the drip tray.
- ► Clean the drip tray with a cloth or in the dishwasher.

## 9.3.2 Installing the water filter




Fig. 129

Make sure that the following conditions are fulfilled

- Water pressure is maintained (see Installation Instructions, Water Connection).
- ► Remove the drawer.
- ► Insert the water filter and turn clockwise approx. 90° until it engages.
- ► Make sure the filter does not leak and no water is coming out.
- ► Insert the drawer.



#### **CAUTION**

Risk of infection due to potential suspended matter in new water filters!

Nausea and vomiting.

► After changing the filter: Draw and dispose of 3 l (3 qt) water at the InfinitySpring.

The water filter is now ready for use.

## 9.4 Disassembling / assembling pullout systems

## 9.4.1 Notes on disassembly

You can disassemble some of the pull-out systems for cleaning. Your appliance can contain a variety of pull-out systems.

The following pull-out systems can be disassembled or cannot be disassembled:

Pull-out system		can be disassembled /
		cannot be disassembled
Full extension*		cannot be disassembled*
Partial extension section*	fridge	cannot be disassembled*

## 9.5 Defrosting the appliance



#### WARNING

Appliance incorrectly defrosted! Injuries and damage.

- ▶ Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.
- ▶ Do not use any electrical heating or steam cleaning equipment, naked flames or defrosting sprays.
- ▶ Do not remove ice with sharp objects.

Defrosting is performed automatically. The water from the thawing process runs out via the drain opening and is evaporated.

► Clean the drain hole regularly. (see 9.6 Cleaning the appliance)

## 9.6 Cleaning the appliance

## 9.6.1 Preparation



## WARNING

Danger of electric shock.

Unplug refrigerator or disconnect power.



#### WARNING

Danger of fire

- ▶ Do not damage the refrigerant circuit.
- ► Empty appliance.
- ▶ Pull out the power plug.
- -or-
- ► Activate CleaningMode. (see CleaningMode)

## 9.6.2 Cleaning the interior

#### NOTICE

Improper cleaning!

Damage to the appliance.

- ➤ Only use soft cleaning cloths and ph-neutral allpurpose cleaners.
- ▶ Do not use steel wool or sponges that scour or scratch.
- ▶ Do not use caustic or abrasive cleaning materials or those containing sand, chloride, or acids.
- ▶ Plastic surfaces: clean by hand with a soft clean cloth, lukewarm water and a little detergent.
- ► Metal surfaces: clean by hand with a soft clean cloth, lukewarm water and a little detergent.
- ▶ Drain hole: remove any deposits with a thin item such as a cotton bud.

## 9.6.3 Cleaning the equipment

#### NOTICE

Improper cleaning!

Damage to the appliance.

- ➤ Only use soft cleaning cloths and ph-neutral allpurpose cleaners.
- ▶ Do not use steel wool or sponges that scour or scratch.
- ▶ Do not use caustic or abrasive cleaning materials or those containing sand, chloride, or acids.

## Clean with a soft, clean cloth, lukewarm water and a little washing up liquid:

- VarioSafe
- Fruit & Vegetable-Safe cover
- Drawer
- Variable bottle shelf
- FlexSystem

#### Clean with a damp cloth:

- Retracting rails

Please note: the grease in the tracks is there for lubrication purposes and must not be removed!

#### Clean in the dishwasher up to 60 °C (140 °F):

- Door racks
- VarioBox
- Bottle rack
- Shelf
- Split shelf
- Holder for the split shelf
- Drip tray
- Egg rack
- Butter dish
- ▶ Disassemble the equipment: see the relevant section.
- Clean the equipment.

## 9.6.4 Cleaning the InfinitySpring

You can clean the InfinitySpring outlet and around it without disconnecting the appliance from the mains.

We recommend cleaning in the following situations:

- Initial commissioning
- $\square$  If out of use for longer than 5 days.
- ▶ Press the bottom pushbutton of the dispenser.
- ➤ The outlet unit moves out.
- ► Clean the water outlet and around it with a soft, damp cloth, lukewarm water and a little washing up liquid.
- ► Release the bottom pushbutton.
- ▶ Draw and dispose of 2 l (2.11 qt) water at the Infinity-Spring.

## 9.6.5 After cleaning

- ► Wipe dry the appliance and items of equipment
- Connect and switch on the appliance. When the temperature is sufficiently cold
- ▶ Place the food inside.

## **Customer support**

► Repeat cleaning regularly.

## 10 Customer support

## 10.1 Technical specifications

Temperature zone	
Cool:	3 °C (36 °F) to 9 °C (46 °F)
BioFresh	0 °C (32 °F) to 3 °C (37 °F)

Max. door capacity		
Appliance height (see Installation Guide, Appliance Dimensions)	Door	
1022 mm (40 1/4 in)	8 kg (17.64 lb)	
1218 mm (47 15/16 in)	14 kg (30.86 lb)	
1395 mm (54 15/16 in)	14 kg (30.86 lb)	
1572 mm (61 7/8 in)	18 kg (39.68 lb)	
1770 mm (69 11/16 in)	18 kg (39.68 lb)	
1850 mm (72 13/16 in)	19 kg (41.89 lb)	

Max. size baking tray	
Width	466 mm (18 3/8 in)
Depth	386 mm (15 3/16 in)
Height	50 mm (1 15/16 in)

For appliances with a WiFi connection:

Frequency specification		
Frequency band	2.4 GHz	
Maximum radi- ated power	< 100 mW	
	Integration in the local WiFi network for data communication	

## 10.2 Operating noises

The appliance makes noises while in operation.

- At **less cooling output** the appliance saves energy but takes longer to cool items. The volume is **lower**.
- At **a higher cooling output** the food cools more quickly. The volume is **higher**.

#### Examples:

- Activated functions (see 7.2 Appliance functions)
- Running fan
- Freshly sorted food
- · High ambient temperature
- · Door opened for long periods

Noise	Possible cause	Type of noise
Bubbling and splashing	Coolant is flowing into the cooling circuit.	Normal noise
Spitting and hissing	Coolant is spraying into the cooling circuit.	Normal noise
Humming	The appliance cools. The volume depends on the cooling output.	Normal noise
Sipping noises	The self-closing door is being opened and closed.	Normal noise
Whirring and murmuring	The fan is running.	Normal oper- ating noise
Clicking	Components are being switched on and off.	
Rattling or humming	Valves are active.	Normal switching noise

Noise	Possible cause	Type of noise	How to resolve
Vibration	Unsuitable installation	Error noise	Check installation. Set up the appliance.
Clattering	Equipment, Objects inside the appliance	Error noise	Secure equipment parts. Leave a gap between
			items.

## 10.3 Technical faults

Your appliance is designed and manufactured for reliable operation and a long service life. If a malfunction nonetheless occurs during operation, please check whether the malfunction is due to an operating error. In

this case, you will have to be charged for the costs incurred, even during the warranty period.

You may be able to rectify the following faults yourself.

## 10.3.1 Appliance function

Defect	Cause	Remedy
The appliance does not work.	The appliance is not switched on.	► Switch on the appliance.
	The power plug is not properly inserted in the wall socket.	► Check the power plug.
	The powerfuse in the wall socket is not OK.	► Check the fuse.
	Power failure.	► Keep the appliance closed.
	The IEC socket is not correctly plugged into the appliance.	► Check the IEC socket.
The temperature is not cold	This means that the door of the appliance is not closed properly	► Close the appliance door
enough	Insufficient ventilation	Clear and clean the ventilation grille.
	The ambient temperature is too high	▶ Problem solution: (see 1.4 Range of appliance use)
	The appliance was opened too frequently or for too long	► Wait to see if the required temperature corrects itself. If not, contact Customer Service. (see 10.4 Customer Service)
	The temperature is incorrectly set	► Set to a colder temperature and check after 24 hours.
	The appliance is too near to a heat source (stove, heater etc).	► Change location of appliance or the heat source.
	The appliance was not properly installed in the recess.	► Make sure the appliance was installed correctly and the door closes properly.
The door seal is defective or should be replaced for other reasons.	The door seal is interchangeable. You can replace it without the use of any special tools.	► Contact Customer Service. (see 10.4 Customer Service)
The appliance is iced up or condensation is building.	The door seal may have slipped out of its groove.	► Check the door seal is well placed in the groove.

## 10.3.2 Equipment

Defect	Cause	Remedy
The Infinity- Spring is not	There is air in the system.	► Vent the water system. (see 4.2 Putting Infinity-Spring into operation)
working.	The water connection is not open	▶ Open the water connection

## **Decommissioning**

Defect	Cause	Remedy	
The water flow at the Infinity-Spring is irregular.	The aerator is not clean.	► Replace aerator. Contact Customer Service. (see 10.4 Customer Service)	
The interior light does not turn on.	The appliance is not switched on.	► Switch on the appliance.	
	The door was open for more than 15 minutes.	▶ If the door is open, the interior lighting switches off automatically after about 15 minutes.	
	The LED interior light is faulty or the lid is damaged.	► Contact Customer Service. (see 10.4 Customer Service)	

### 10.4 Customer Service

First check whether you can rectify the fault yourself (see 10 Customer support) . If you cannot rectify the problem, contact Customer Service.

You can find the address in the enclosed brochure "Liebherr-Service" or at home.liebherr.com/service.



## WARNING

Unprofessional repair! Injuries.

- ► A damaged power cable may only be replaced by the manufacturer, the manufacturer's Customer Service or a similarly qualified person.
- ► For appliances with plug and play connection cables, the change can be made by the customer.

## 10.4.1 Contacting Customer Service

Make sure that the following appliance information is available:

- Appliance name (model and index)
- ☐ Service no. (service)
- ☐ Serial no. (S no.)
- ► Call up the appliance information via the display. (see Appliance information)

-or

- ► Refer to the type plate for appliance information. (see 10.5 Rating plate)
- ► Take note of the appliance information.
- Notify customer service: Report errors and the appliance information.
- This will help us give you fast and accurate support.
- ► Follow further instructions from Customer Service.

## 10.5 Rating plate

The nameplate is located behind the drawers on the inside of the appliance.




Fig. 130

- (1) Appliance name
- (3) Serial no.
- (2) Service no.
- ▶ Information from the nameplate.

## 11 Decommissioning

- Empty appliance.
- ➤ Switch off appliance. (see Switching appliance off and on)
- ▶ Pull the power plug from the outlet.
- ▶ If necessary, remove the IEC socket: Pull the IEC socket out of the appliance plug while turning it to the left and right at the same time.
- ► Clean appliance. (see 9.6 Cleaning the appliance)
- ► Leave the door open to prevent unpleasant odors.

## 12 Disposal

# 12.1 Preparing the appliance for disposal



#### WARNING

Risk of child entrapment!

Before you throw away your old refrigerator or freezer:

- ► Take off the doors.
- ▶ Leave the shelves in place so that children may not easily climb inside.



Liebherr uses batteries in some of its appliances. You should remove these before disposal of the old appliance for environmental reasons. If your appliance contains batteries, a corresponding notice is attached to the appliance.

Lamps

If you can remove the lamps yourself without destroying them, also remove these before disposal.

► Take the appliance out of operation.

▶ If possible: Remove lamps without destroying them.

## 12.2 Disposing of the appliance in an environmentally friendly manner



The appliance still contains it can be recycled.





valuable materials and must be collected separately from unsorted municipal waste so

Dispose of batteries separately from the old appliance. Certain batteries should NOT go in household garbage or recycling bins. Waste batteries can always be recycled or taken to household hazardous waste collection points. To prevent fires from lithium-ion batteries, tape battery terminals and/or place batteries in separate plastic bags and never put these batteries in household garbage or recycling bins.

Lamps

Dispose of removed lamps via respective collection

systems.

For USA:

Check the Responsible Appliance Disposal (RAD) program to find a RAD partner near you.

For Canada:

Follow your local guidance about recycling and disposal

capabilities near you.



# WARNING

Leaking refrigerant and oil!

Fire. The refrigerant contained within the appliance is environmentally friendly, but flammable. The oil contained within the appliance is flammable. Escaping refrigerant and oil can ignite if they are of high enough concentration and are exposed to an external heat source.

- ▶ Do not damage the pipelines of the coolant circuit and the compressor.
- Observe the notes on appliance transport.
- Transport the appliance away without damaging it.
- ▶ Dispose of batteries, lamps, and the appliance according to the above specifications.



home.liebherr.com/fridge-manuals

Built-in refrigerator with BioFresh

Part number index: 7088423-00

For Service in the U.S.: Liebherr Service Center
Toll Free: 1-866-LIEBHER or 1-866-543-2437
Service-appliances.us@liebherr.com
PlusOne Solutions, Inc.
3501 Quadrangle Blvd, Suite 120
Orlando, FL 32817

Issue date: 20241105

For Service in Canada: Liebherr Service Center
Toll Free: 1-888-LIEBHER or 1-888-543-2437
www.euro-parts.ca
EURO-PARTS CANADA
39822 Belgrave Road, Belgrave, Ontario, NOG 1E0
Phone: (519) 357-3320 | Fax: (519) 357-1326