


Installation Guide

decor fridges and freezers

EN



20241118 **7086315 - 00**

UK/ UG

LIEBHERR

General safety instructions

Contents

1	General safety instructions.....	2
2	Transporting the appliance.....	2
3	Installing the appliance.....	2
4	Changing over door hinges.....	3
5	Decor panel assembly.....	4
6	Under-worktop.....	4
7	Disposing of packaging.....	5
8	Connecting the appliance.....	5

The manufacturer works constantly on the further development of all the types and models. Therefore please understand that we have to reserve the right to make design, equipment and technical modifications.


To get to know all the benefits of your new appliance, please read the information contained in these instructions carefully.

The instructions apply to several models. Differences may occur. Text relating only to specific appliances is marked with an asterisk (*).

Instructions are marked with a ►, and results are marked with a ▷.

1 General safety instructions

- Please keep this assembly manual in a safe place so you can refer back to it at any time.
- If you pass the appliance on, please hand this assembly manual to the next user.
- Read this assembly manual carefully before installation and use to ensure safe and correct use of the appliance. Follow the instructions, safety instructions and warning messages included at all times. They are important for ensuring you can operate and install the appliance safely and without any problems.
- First read the general safety instructions in the “General safety instructions” section of the **operating instructions**, which accompany these installation instructions, and follow them. If you cannot find the **operating instructions**, you can download the **operating instructions** from the internet by entering the service number at home.liebherr.com/fridge-manuals. The service number can be found on the serial



- Observe the warning messages and other detailed information in the other sections when installing the appliance:

	DANGER	identifies a situation involving direct danger which, if not obviated, may result in death or severe bodily injury.
	WARNING	identifies a dangerous situation which, if not obviated, may result in death or severe bodily injury.
	CAUTION	identifies a dangerous situation which, if not obviated, may result in minor or medium bodily injury.
	NOTICE	identifies a dangerous situation which, if not obviated, may result in damage to property.
	Note	identifies useful instructions and tips.

2 Transporting the appliance

- Transport the appliance only in suitable packaging.
- Transport the appliance upright.
- Do not transport the appliance on your own.

3 Installing the appliance



WARNING

Danger of fire due to incorrect positioning!

If the mains cable or plug touches the back of the appliance, the vibration can damage the mains cable or the plug resulting in a short circuit.

- Make sure the mains cable is not trapped under the appliance when you position the appliance.
- Stand the appliance so that it is not touched by connectors or main cables.
- Do not connect any appliances to sockets in the area of the back of the appliance.
- Do **not** place and operate multi-sockets/power distributors and other electronic devices (such as halogen transformers) at the back of the appliances.



WARNING

Fire hazard due to dampness!

If live parts or the mains lead become damp this may cause short circuits.

- The appliance is designed for use in enclosed areas. Do not operate the appliance outdoors or in areas where it is exposed to splash water or damp conditions.
- Only use the appliance when it is installed.



WARNING

Leaking coolant and oil!

Fire. The coolant contained in the appliance is eco-friendly, but also flammable. The oil contained in the appliance is flammable. Escaping coolant and oil can ignite if the concentration is high enough and in contact with an external heat source.

- Do not damage the pipelines of the coolant circuit and the compressor.



WARNING

Fire hazard and danger of damage!

- ▶ Do not place appliances emitting heat e.g. microwaves, toasters etc. on the appliance!

NOTICE

Covered vents!

Damage. Appliance can overheat, which can reduce the service life of various parts of the appliance and lead to operational impairments.

- ▶ Always make sure there is good ventilation.
- ▶ Always keep vents or ventilation grids in the appliance housing and in the kitchen furniture (fully integrated appliance) unobstructed.
- ▶ Always keep the fan air vents unobstructed.

If your appliance is not a side-by-side (SBS) appliance:*

NOTICE

Risk of damage due to condensate!*

- ▶ Do not install the appliance directly alongside a further refrigerator/freezer.

- ☐ Before you connect the appliance, report any damage immediately to the delivery company.
- ☐ The floor of the installation site must be horizontal and even.
- ☐ Do not install the appliance in direct sunlight, next to an oven, radiator or similar.
- ☐ The appliance is suitable for use as an integrated base unit, ventilated at the feet.
- ☐ Do not install the appliance on your own.
- ☐ The more refrigerant there is in the appliance, the larger the space that it is installed in must be. If the space is too small, any leak may create a flammable mixture of gas and air. For every 8 g of refrigerant, the installation space must be at least 1 m³. Information regarding the coolant can be found on the type plate inside the appliance.
- ▶ Detach the connecting cable from the rear of the appliance, removing the cable holder at the same time because otherwise there will be vibratory noise!

After installation:

- ▶ Remove the protective film from the decorative trims.*
- ▶ Remove all transit supports.
- ▶ Dispose of packaging material (see 7 Disposing of packaging).
- For Side-by-Side installation, freezer and refrigerator side by side:*
- ▶ Always install the freezer on the right of the refrigerator, as seen from the front.*
- ▶ No condensate forms between the appliances thanks to the side wall heating system foamed in on the left.*

Note

- ▶ Clean the appliance.

If the appliance is installed in a very damp environment, condensate may form on the outside of the appliance.

- ▶ Always see to good ventilation at the installation site.

4 Changing over door hinges

All the assembly components accompany the appliance.





Fig. 1

Ensure that the following tools are to hand:

- ☐ Akku-Schrauber Torx® 10, 15, 20
- ☐ Spanner 19
- ☐ Screwdriver

The appliance is supplied with the hinges on the right-hand side - door handle on the left-hand side of the door. The door hinges can be changed over if necessary.

- ▶ Close the door and unscrew the turn hinge Fig. 2 (1).



Torx® 20 Fig. 2



CAUTION

Risk of injury if the door tips!

- ▶ Take good hold of the door.
- ▶ Set down the door carefully.

- ▶ Lower the door for removal.
- ▶ Transfer the hinge pin Fig. 2 (2) and tighten firmly (with 4 Nm).
- ▶ Unscrew the top hinge pin Fig. 3 (3) and firmly screw it in on the opposite side (with 4 Nm).




Fig. 3

- ▶ Remove the cover Fig. 4 (4) and use it to close the vacated fastening holes.




Fig. 4

- ▶ Transfer the stopper Fig. 5 (5).




Fig. 5

For appliances with freezer compartment:

- ▶ Now transfer the hinge of the compartment door:

Decor panel assembly




Fig. 6 *

- Fold away the cover of the turn hinge Fig. 6 (10)*
- Unscrew turn hinge Fig. 6 (10) together with compartment door.*
- Unscrew closing element Fig. 6 (11)*
- Close the vacated holes using the accompanying cover Fig. 6 (12)*




Fig. 7 *

- Fit the closing element Fig. 7 (11)*
- Fit the compartment door at the top*
- Fit the turn hinge Fig. 7 (10) and fold the cover.*

All appliances: Re-fit the door.

The cam Fig. 8 (13) has to be situated on the side of the light housing Fig. 8 (14).

- Attach the door to the upper hinge pin Fig. 3 (3) and close it.




Fig. 8

- Place the hinge pin Fig. 9 (2), which is in the bearing bracket Fig. 9 (1) with the washer, inside the lower door bearing.




Fig. 9

- Screw the turn hinge Fig. 9 (1) firmly into place (with 4 Nm).

Note

- If necessary, e.g. to align the door, the second slot hole can be used for the screw fastening, instead of the circular hole.



WARNING

Risk of injury due to the door dropping out!
If the bearing parts are not screwed into place firmly enough, the door may drop out. This may lead to severe injuries. What is more, the door may not close and therefore the appliance may fail to cool properly.

- Screw the turn hinge and bearing pins firmly into place (with 4 Nm).
- Check all of the screws and retighten if necessary.

5 Decor panel assembly

Using a decor frame and decor panel allows the appliances to be matched in colour to or contrasted from the kitchen units.

The following table shows the panel dimensions for your appliance:

Decor panel dimensions (mm)

Recess width	Width	Height	Max. thickness
600	585	678	4
500	485	678	4




Fig. 10

- For thicker decor panels Fig. 10 (2), reduce their thickness to max. 4 mm, as illustrated.




Fig. 11

- Mount the decor frame and the decor panel as follows. Do not tighten the screws until the end.
- Screw on decor frame (1) loosely at the bottom and slide forwards.
- Loosely screw side part on the hinge side (2) of the decor frame at the bottom and push forward.
- Slide in decor panel (3).
- Screw on the decor frame side part on handle side (4) together with the handle.
- Slide back parts of the decor frame and screw firmly into place.
- Finally fit decor frame top part (6) and screw on tight.
- Snap cover caps (7) onto all screw heads.

6 Under-worktop

Ensure that the following tools are to hand:

- ☐ Spanner 19
- ☐ Cordless screwdriver Torx® 15
- ☐ The socket outlet Fig. 12 (1) must be adjacent to the appliance and readily accessible.
- ☐ Check the recess dimensions:

Recess dimensions		Appliance dimensions (mm)		
Width	Min. depth	Width	Depth	Door width
A	B	C	D	E
500	min. 570, recom- mended: 580	497	569	495
600	min. 570, recom- mended: 580	597	569	595




Fig. 12

- ▶ Detach the connecting cable from the rear of the appliance, removing the cable holder at the same time because otherwise there will be vibratory noise!
- ▶ Lay the connecting cable with the help of a string in such a way that the appliance can be easily connected after fitting.



Fig. 13

- ▶ Slide the appliance into the recess.
- ▶ Align the appliance to the kitchen units, align the front of the appliance so that it is flush with the kitchen units at the sides.
- ▶ Align the appliance by applying the accompanying opened spanner Fig. 12 (15) to the height-adjustable feet.

Note

- ▶ Pay attention that air intake at the bottom is not obstructed. Under no circumstances should you fit any covers or close the air gap! This is essential for ventilation and proper operation of the appliance.
- ▶ Fasten the top of the appliance to the worktop or to the furniture unit using the accompanying screws Fig. 12 (16).

7 Disposing of packaging



WARNING

Danger of suffocation due to packing material and plastic film!

- ▶ Do not allow children to play with packing material.

The packaging is made of recyclable materials:

- corrugated board/cardboard
- expanded polystyrene parts
- polythene bags and sheets
- polypropylene straps
- nailed wooden frame with polyethylene panel*

- ▶ Take the packaging material to an official collecting point.

8 Connecting the appliance

NOTICE

Danger of damage to incorrect connection!
Damage to the appliance.

- ▶ Do not connect the appliance to a stand-alone inverter, e.g. solar power systems and petrol generators.



WARNING

Danger of fire due to incorrect connection!
Burns.

Damage to the appliance.

- ▶ Do not use an extension cable.
- ▶ Do not use distributor blocks.

The type of current (alternating current) and voltage at the installation site have to conform with the data on the type plate.

The socket must be properly earthed and fused. The tripping current for the fuse must be between 10 A and 16 A.

The socket must be easily accessible so that the appliance can be quickly disconnected from the supply in an emergency. It must be outside the area of the rear of the appliance.

- ▶ Check the electrical connection.
- ▶ Plug in the power plug.





Liebherr-Hausgeräte Marica EOOD

4202 Radinovo

Bezirk Plovdiv

Bulgarien

home.liebherr.com